



Operating Instructions

VLT[®] AutomationDrive FC 302

90–1200 kW





Danfoss A/S

6430 Nordborg
Denmark
CVR nr.: 20 16 57 15

Telephone: +45 7488 2222
Fax: +45 7449 0949

EU DECLARATION OF CONFORMITY

Danfoss A/S

Danfoss Drives A/S

declares under our sole responsibility that the

Product category: Frequency Converter

Type designation(s): FC-302XXXXZZ*****

Character X: N or P

Character YYY: K25, K37, K55, K75, 1K1, 1K5, 2K2, 3K0, 3K7, 4K0, 5K5, 7K5, 11K, 15K, 18K, 22K, 30K, 37K, 45K, 55K, 75K, 90K, 110, 132, 150, 160, 200, 250, 315, 355, 400, 450, 500, 560, 630, 710, 800, 900, 1M0, 1M2

Character ZZ: T2, T5, T6, T7

* may be any number or letter indicating drive options which do not impact this DoC.

The meaning of the 39 characters in the type code string can be found in appendix 00729776.

Covered by this declaration is in conformity with the following directive(s), standard(s) or other normative document(s), provided that the product is used in accordance with our instructions.

Low Voltage Directive 2014/35/EU

EN61800-5-1:2007 + A1:2017

Adjustable speed electrical power drive systems – Part 5-1: Safety requirements – Electrical, thermal and energy.

EMC Directive 2014/30/EU

EN61800-3:2004 + A1:2012

Adjustable speed electrical power drive systems – Part 3: EMC requirements and specific test methods.

RoHS Directive 2011/65/EU including amendment 2015/863.

EN63000:2018

Technical documentation for the assessment of electrical and electronic products with respect to the restriction of

| | | | |
|-------------------------------------|--|-------------------------------------|---|
| Date: 2020.09.15 Place of issue: | Issued by Signature: Name: Gert Kjær Title: Senior Director, GDE | Date: 2020.09.15 Place of issue: | Approved by Signature: Name: Michael Termansen Title: VP, PD Center Denmark |
| Graasten, DK | | Graasten, DK | |

Danfoss only vouches for the correctness of the English version of this declaration. In the event of the declaration being translated into any other language, the translator concerned shall be liable for the correctness of the translation

hazardous substances

For products including available Safe Torque Off (STO) function according to unit typecode on the nameplate: **X, B or R at character 18 of the typecode.**

Machine Directive 2006/42/EC

EN/IEC 61800-5-2:2007
(Safe Stop function conforms with STO – Safe Torque Off, SIL 2 Capability)

Adjustable speed electrical power drive systems – Part 5-2: Safety requirements – Functional

Other standards considered:

EN ISO 13849-1:2015
(Safe Stop function, PL d
(MTTFd=14000 years, DC=90%, Category 3)
EN/IEC 61508-1:2011, EN/IEC 61508-2:2011
(Safe Stop function, SIL 2 (PFH = 1E-10/h, 1E-8/h for specific variants, PFD = 1E-10, 1E-4 for specific variants, SFF>99%, HFT=0))

Safety of machinery - Safety-related parts of control systems - Part 1: General principles for design

Functional safety of electrical/electronic/ programmable electronic safety-related systems
Part 1: General requirements

Part 2: Requirements for electrical/ electronic / programmable electronic safety-related systems
Safety of machinery - Functional safety of safety-related electrical, electronic and programmable electronic control systems

EN/IEC 62061:2005 + A1:2013
(Safe Stop function, SILCL 2)

Safety of machinery - Electrical equipment of machines - Part 1: General requirements


EN/IEC 60204-1:2006 + A1:2009
(Stop Category 0)

For products including ATEX option, it requires STO function in the products. The products can have the VLT PTC Thermistor Card MCB112 installed from factory (**2 at character 32 in the typecode**), or it can be separately installed as an additional part.

2014/34/EU - Equipment for explosive atmospheres (ATEX)

Based on EU harmonized standard:
EN 50495: 2010

Safety devices required for safe functioning of equipment with respect to explosion risks.



Notified Body:

PTB Physikalisch-Technische Bundesanstalt, Bundesallee 100, 38116 Braunschweig, has assessed the conformity of the "ATEX certified motor thermal protection systems" of Danfoss FC VLT Drives with Safe Torque Off function and has issued the certificate PTB 14 ATEX 3009.

Contents

| | |
|---|----------|
| 1 Introduction | 4 |
| 1.1 How to Read these Operating Instructions | 4 |
| 1.1.1 Approvals | 4 |
| 2 Safety Instructions and General Warning | 6 |
| 2.1 Safety Regulations | 6 |
| 2.1.1 Disposal Instruction | 6 |
| 2.1.2 Caution | 6 |
| 2.1.3 Software Version | 6 |
| 2.1.4 High Voltage | 6 |
| 2.1.5 Safety Instructions | 6 |
| 2.1.6 General Warning | 7 |
| 2.1.7 Before Commencing Repair Work | 7 |
| 2.1.8 Avoid Unintended Start | 7 |
| 2.1.9 Safe Torque Off (STO) | 7 |
| 2.1.10 IT Mains | 7 |
| 3 How to Install | 8 |
| 3.1 Pre-installation | 8 |
| 3.1.1 Planning the Installation Site | 8 |
| 3.1.2 Receiving the Frequency Converter | 8 |
| 3.1.3 Transportation and Unpacking | 8 |
| 3.1.4 Lifting | 8 |
| 3.1.5 Mechanical Dimensions | 11 |
| 3.1.6 Rated Power | 18 |
| 3.2 Mechanical Installation | 19 |
| 3.2.1 Tools Needed | 19 |
| 3.2.2 General Considerations | 19 |
| 3.2.3 Terminal Locations - Enclosure Type D | 20 |
| 3.2.4 Terminal Locations - E Enclosures | 23 |
| 3.2.5 Terminal Locations - Frame size F | 28 |
| 3.2.6 Cooling and Airflow | 32 |
| 3.2.7 Installation on the Wall - IP21 (NEMA 1) and IP54 (NEMA 12) Units | 34 |
| 3.2.8 Gland/Conduit Entry - IP21 (NEMA 1) and IP54 (NEMA12) | 34 |
| 3.2.9 IP21 Drip Shield Installation (Enclosure Types D1 and D2) | 36 |
| 3.3 Field Installation of Options | 36 |
| 3.3.1 Installation of Duct Cooling Kit in Rittal Enclosures | 36 |
| 3.3.2 Installation of Top-only Duct Cooling Kit | 37 |
| 3.3.3 Installation of Top and Bottom Covers for Rittal Enclosures | 37 |
| 3.3.4 Installation of Top and Bottom Covers | 38 |

| | |
|--|----|
| 3.3.5 Outside Installation/NEMA 3R Kit for Rittal Enclosures | 38 |
| 3.3.6 Outside Installation/NEMA 3R Kit of Industrial Enclosures | 39 |
| 3.3.7 Installation of IP00 to IP20 Kits | 39 |
| 3.3.8 Installation of IP00s D3, D4, & E2 Cable Clamp Bracket | 39 |
| 3.3.9 Installation on Pedestal | 39 |
| 3.3.10 Installation of Mains Shield for Frequency Converters | 40 |
| 3.3.11 Installation of Input Plate Options | 40 |
| 3.3.12 Installation of D or E Loadshare Option | 41 |
| 3.4 F Enclosure Panel Options | 41 |
| 3.4.1 Enclosure Type F Options | 41 |
| 3.5 Electrical Installation | 43 |
| 3.5.1 Power Connections | 43 |
| 3.5.2 Grounding | 54 |
| 3.5.3 Extra Protection (RCD) | 54 |
| 3.5.4 RFI Switch | 54 |
| 3.5.5 Torque | 54 |
| 3.5.6 Shielded Cables | 55 |
| 3.5.7 Motor Cable | 55 |
| 3.5.8 Brake Cable for Frequency Converters with Factory Installed Brake Chopper Option | 56 |
| 3.5.9 Load Sharing | 56 |
| 3.5.10 Shielding against Electrical Noise | 56 |
| 3.5.11 Mains Connection | 56 |
| 3.5.12 External Fan Supply | 57 |
| 3.5.13 Fuses | 57 |
| 3.5.14 Mains Disconnectors - Frame Size D, E and F | 69 |
| 3.5.15 F-Frame Circuit Breakers | 69 |
| 3.5.16 F-Frame Mains Contactors | 69 |
| 3.5.17 Motor Insulation | 70 |
| 3.5.18 Motor Bearing Currents | 70 |
| 3.5.19 Brake Resistor Temperature Switch | 70 |
| 3.5.20 Control Cable Routing | 70 |
| 3.5.21 Access to Control Terminals | 72 |
| 3.5.22 Electrical Installation, Control Terminals | 72 |
| 3.5.23 Electrical Installation, Control Cables | 73 |
| 3.5.24 Switches S201, S202, and S801 | 75 |
| 3.6 Connection Examples | 76 |
| 3.6.1 Start/Stop | 76 |
| 3.6.2 Pulse Start/Stop | 76 |
| 3.7 Final Set-Up and Test | 77 |

| | |
|---|------------|
| 3.8 Additional Connections | 78 |
| 3.8.1 Mechanical Brake Control | 78 |
| 3.8.2 Parallel Connection of Motors | 78 |
| 3.8.3 Motor Thermal Protection | 79 |
| 4 How to Programme | 80 |
| 4.1 The Graphical and Numerical LCP | 80 |
| 4.1.1 How to Programme on the Numerical Local Control Panel | 81 |
| 4.1.2 Initial Commissioning | 82 |
| 4.2 Quick Setup | 83 |
| 4.3 Parameter Menu Structure | 85 |
| 5 General Specifications | 90 |
| 6 Warnings and Alarms | 105 |
| 6.1 Status Messages | 105 |
| 6.1.1 Warnings/Alarm Messages | 105 |
| Index | 117 |

1 Introduction

1.1 How to Read these Operating Instructions

The frequency converter is designed to provide high shaft performance on electrical motors. Read this manual carefully for proper use. Incorrect handling of the frequency converter may cause improper operation of the frequency converter or related equipment, shorten lifetime or cause other troubles.

These Operating Instructions help starting, installing, programming, and troubleshooting the frequency converter.

Chapter 1 Introduction introduces the manual and informs you about the approvals, symbols, and abbreviations used in this literature.

Chapter 2 Safety Instructions and General Warning entails instructions on how to handle the frequency converter correctly.

Chapter 3 How to Install guides through mechanical and technical installation.

Chapter 4 How to Programme shows how to operate and programme the frequency converter via the LCP.

Chapter 5 General Specifications contains technical data about the frequency converter.

Chapter 6 Warnings and Alarms assists in solving problems that may occur when using the frequency converter.

Available literature

- The *VLT AutomationDrive 90-1200 kW Operating Instructions* provide the necessary information for getting the frequency converter up and running.
- The *VLT AutomationDrive FC 301/302 Design Guide* entails all technical information about the frequency converter and customer design and applications.
- The *VLT AutomationDrive Programming Guide* provides information on how to programme and includes complete parameter descriptions.
- The *VLT AutomationDrive Profibus Operating Instructions* provide the information required for controlling, monitoring and programming the frequency converter via a Profibus fieldbus.
- The *VLT AutomationDrive DeviceNet Operating Instructions* provide the information required for

controlling, monitoring and programming the frequency converter via a DeviceNet fieldbus.

Danfoss technical literature is also available online at www.danfoss.com/drives.

1.1.1 Approvals



Table 1.1

The frequency converter complies with UL508C thermal memory retention requirements. For more information, refer to the section *Motor Thermal Protection* in the *Design Guide*.

NOTICE

Imposed limitations on the output frequency (due to export control regulations):

From software version 6.72 the output frequency of the frequency converter is limited to 590 Hz. Software versions 6x.xx also limit the maximum output frequency to 590 Hz, but these versions cannot be flashed, i.e. neither downgraded nor upgraded.

The following symbols are used in this document:



Indicates a potentially hazardous situation which could result in death or serious injury.



Indicates a potentially hazardous situation which could result in minor or moderate injury. It may also be used to alert against unsafe practices.

NOTICE

Indicates important information, including situations that may result in damage to equipment or property.

Conventions

Numbered lists indicate procedures.

Bullet lists indicate other information and description of illustrations.

Italicised text indicates

- cross reference
- link
- footnote
- parameter name, parameter group name, parameter option

| | |
|----------------------|--|
| 60° AVM | 60° Asynchronous Vector Modulation |
| A | Ampere/AMP |
| AC | Alternating current |
| AD | Air discharge |
| AI | Analog Input |
| AMA | Automatic Motor Adaptation |
| AWG | American wire gauge |
| °C | Degrees Celsius |
| CD | Contant discharge |
| CM | Common mode |
| CT | Constand Torque |
| DC | Direct current |
| DI | Digital Input |
| DM | Differential mode |
| D-TYPE | Drive Dependent |
| EMC | Electro Magnetic Compatibility |
| ETR | Electronic Thermal Relay |
| f _{JOG} | Motor frequency when jog function is activated |
| f _M | Motor frequency |
| f _{MAX} | The maximum output frequency the frequency converter applies on its output |
| f _{MIN} | The minimum motor frequency from frequency converter |
| f _{M,N} | Nominal motor frequency |
| FC | Frequency converter |
| g | Gram |
| Hiperface® | Hiperface® is a registered trademark by Stegmann |
| hp | Horsepower |
| HTL | HTL encoder (10-30 V) pulses - High-voltage Transistor Logic |
| Hz | Hertz |
| I _{INV} | Rated Inverter Output Current |
| I _{LIM} | Current limit |
| I _{M,N} | Nominal motor current |
| I _{VLT,MAX} | The maximum output current |
| I _{VLT,N} | The rated output current supplied by the frequency converter |
| kHz | Kilohertz |
| LCP | Local Control Panel |
| lsb | Least significant bit |

| | |
|-----------------------------|---|
| m | Meter |
| mA | Milliampere |
| MCM | Mille Circular Mil |
| MCT | Motion Control Tool |
| mH | Millihenry Inductance |
| min | Minute |
| ms | Millisecond |
| msb | Most significant bit |
| η _{VLT} | Efficiency of the frequency converter defined as ratio between power output and power input |
| nF | Nanofarad |
| NLCP | Numerical Local Control Panel |
| Nm | Newton Meters |
| n _s | Synchronous Motor Speed |
| On-line/Off-line Parameters | Changes to on-line parameters are activated immediately after the data value is changed. |
| P _{br,cont.} | Rated power of the brake resistor (average power during continuous braking) |
| PCB | Printed Circuit Board |
| PCD | Process Data |
| PELV | Protective Extra Low Voltage |
| P _m | Frequency converter nominal output power as HO |
| P _{M,N} | Nominal motor power |
| PM motor | Permanent Magnet motor |
| Process PID | The PID regulator maintains the desired speed, pressure, temperature, etc. |
| R _{br,nom} | The nominal resistor value that ensures a brake power on motor shaft of 150/160% for 1 minute |
| RCD | Residual Current Device |
| Regen | Regenerative terminals |
| R _{min} | Minimum permissible brake resistor value by frequency converter |
| RMS | Root Mean Square |
| RPM | Revolutions Per Minute |
| R _{rec} | Resistor value and resistance of the brake resistor |
| s | Second |
| SFAVM | Stator Flux oriented Asynchronous Vector Modulation |
| STW | Status Word |
| SMPS | Switch Mode Power Supply |
| THD | Total Harmonic Distortion |
| T _{LIM} | Torque limit |
| TTL | TTL encoder (5 V) pulses - Transistor Transistor Logic |
| U _{M,N} | Nominal motor voltage |
| V | Volts |
| VT | Variable Torque |
| VVC ^{plus} | Voltage Vector Control |


Table 1.2 Abbreviations

2

2 Safety Instructions and General Warning

2.1 Safety Regulations

2.1.1 Disposal Instruction



Equipment containing electrical components may not be disposed of together with domestic waste. It must be separately collected with electrical and electronic waste according to local and currently valid legislation.

2.1.2 Caution

▲WARNING

The frequency converter DC link capacitors remain charged after power has been disconnected. To avoid electrical shock hazard, disconnect the frequency converter from the mains before carrying out maintenance. Before doing service on the frequency converter wait at least the amount of time indicated below

| | | |
|-----------|------------|------------|
| 380-500 V | 90-200kW | 20 minutes |
| | 250-800kW | 40 minutes |
| 525-690V | 37-315kW | 20 minutes |
| | 355-1200kW | 30 minutes |

Table 2.1 Discharge Time

2.1.3 Software Version

VLT AutomationDrive
Operating Instructions
Software version: 7.1x

These Operating Instructions can be used for all VLT AutomationDrive frequency converters with software version 7.1x.
 The software version number can be seen from *15-43 Software Version*.

2.1.4 High Voltage

▲WARNING

The voltage of the frequency converter is dangerous whenever the frequency converter is connected to mains. Incorrect installation or operation of the motor or frequency converter may cause damage to the equipment, serious personal injury or death. The instructions in this manual must consequently be observed, as well as applicable local and national rules and safety regulations.

▲WARNING

Installation in high altitudes

380-500 V: At altitudes above 3,000 m, contact Danfoss regarding PELV.

525-690 V: At altitudes above 2,000 m, contact Danfoss regarding PELV.

2.1.5 Safety Instructions

- Make sure the frequency converter is properly connected to earth.
- Protect users against supply voltage.
- Protect the motor against overloading according to national and local regulations.
- Motor overload protection is not included in the default settings. To add this function, set *1-90 Motor Thermal Protection* to value *ETR trip* or *ETR warning*. For the North American market: ETR functions provide class 20 motor overload protection, in accordance with NEC.
- The earth leakage current exceeds 3.5 mA.
- The [Off] key is not a safety switch. It does not disconnect the frequency converter from mains.

2.1.6 General Warning

⚠ WARNING

Touching the electrical parts may be fatal - even after the equipment has been disconnected from mains. Also make sure that other voltage inputs have been disconnected, such as load-sharing (linkage of DC intermediate circuit), as well as the motor connection for kinetic back-up.

When using the frequency converter: wait at least 40 minutes.

Shorter time is allowed only if indicated on the nameplate for the specific unit.

⚠ CAUTION

The earth leakage current from the frequency converter exceeds 3.5 mA. To ensure that the earth cable has a good mechanical connection to the earth connection (terminal 95), the cable cross section must be at least 10 mm² or 2 rated earth wires terminated separately. For proper earthing for EMC, see *chapter 3.5.2 Grounding. Residual Current Device*

This product can cause a D.C. current in the protective conductor. Where a residual current device (RCD) is used for extra protection, only an RCD of Type B (time delayed) shall be used on the supply side of this product. See also *RCD Application Note MN90GX02* (x=version number).

Protective earthing of the frequency converter and the use of RCDs must always follow national and local regulations.

2.1.7 Before Commencing Repair Work

1. Disconnect the frequency converter from mains.
2. Disconnect DC bus terminals 88 and 89 from load share applications.
3. Wait for discharge of the DC-link. See period of time on the warning label.
4. Remove motor cable.

2.1.8 Avoid Unintended Start

While the frequency converter is connected to mains, the motor can be started/stopped using digital commands, bus commands, references or via the Local Control Panel (LCP):

- Disconnect the frequency converter from mains whenever personal safety considerations make it necessary to avoid unintended start.
- To avoid unintended start, always activate the [Off] key before changing parameters.

- An electronic fault, temporary overload, a fault in the mains supply, or lost motor connection may cause a stopped motor to start. The frequency converter with Safe Stop provides protection against unintended start, if the Safe Stop Terminal 37 is deactivated or disconnected.

2.1.9 Safe Torque Off (STO)

To run Safe Torque Off, additional wiring for the frequency converter is required, refer to *Safe Torque Off Operating Instructions for Danfoss VLT® Frequency Converters* for further information.

2.1.10 IT Mains

Parameter *14-50 RFI Filter* can be used to disconnect the internal RFI capacitors from the RFI filter to ground in the 380-500 V frequency converters. This reduces the RFI performance to A2 level. For the 525-690 V frequency converters, *14-50 RFI Filter* has no function. The RFI switch cannot be opened.

3 How to Install

3

3.1 Pre-installation

3.1.1 Planning the Installation Site

CAUTION

Before performing the installation it is important to plan the installation of the frequency converter. Neglecting this may result in extra work during and after installation.

Select the best possible operation site by considering the following (see details on the following pages, and the respective Design Guides)

- Ambient operating temperature
- Installation method
- How to cool the unit
- Position of the frequency converter
- Cable routing
- Ensure the power source supplies the correct voltage and necessary current
- Ensure that the motor current rating is within the maximum current from the frequency converter
- If the frequency converter is without built-in fuses, ensure that the external fuses are rated correctly.

3.1.2 Receiving the Frequency Converter

When receiving the frequency converter, make sure that the packaging is intact, and be aware of any damage that might have occurred to the unit during transport. In case damage has occurred, contact immediately the shipping company to claim the damage.

3.1.3 Transportation and Unpacking

Before unpacking the frequency converter it is recommended that it is located as close as possible to the final installation site.

Remove the box and handle the frequency converter on the pallet, as long as possible.

3.1.4 Lifting

Always lift the frequency converter in the dedicated lifting eyes. For all D and E2 (IP00) enclosures, use a bar to avoid bending the lifting holes of the frequency converter.




Illustration 3.1 Recommended Lifting Method, Enclosure Types D and E

WARNING

The lifting bar must be able to handle the weight of the frequency converter. See *Mechanical Dimensions* for the weight of the different enclosure type. Maximum diameter for bar is 2.5 cm (1 inch). The angle from the top of the frequency converter to the lifting cable should be 60° or greater.




Illustration 3.2 Recommended Lifting Method, Enclosure Type F1 (460 V, 600 to 900 HP, 575/690 V, 900 to 1150 HP)




Illustration 3.3 Recommended Lifting Method, Enclosure Type F2 (460 V, 1000 to 1200 HP, 575/690 V, 1250 to 1350 HP)




Illustration 3.6 Recommended lifting method, Enclosure Type F8




Illustration 3.4 Recommended Lifting Method, Enclosure Type F3 (460 V, 600 to 900 HP, 575/690 V, 900 to 1150 HP)




Illustration 3.7 Recommended lifting method, Enclosure Type F9/F10




Illustration 3.5 Recommended Lifting Method, Enclosure Type F4 (460 V, 1000 to 1200 HP, 575/690 V, 1250 to 1350 HP)

3

3






Illustration 3.8 Recommended lifting method, Enclosure Type F11/F12/F13/F14

NOTICE


The plinth is provided in the same packaging as the frequency converter but is not attached to enclosure types F1-F4 during shipment. The plinth is required to allow airflow to the frequency converter to provide proper cooling. The F enclosures should be positioned on top of the plinth in the final installation location. The angle from the top of the frequency converter to the lifting cable should be 60° or greater.

In addition to the drawings above a spreader bar is an acceptable way to lift the F enclosures.






* Please note airflow directions



3



| Frame size | | D1 | | D2 | | D3 | D4 |
|--------------------------------|-----------------|--|---------|--|---------|--|--|
| | | 90-110 kW (380-500 V) 37-132 kW (525-690 V) | | 132-200 kW (380-500 V) 160-315 kW (525-690 V) | | 90-110 kW (380-500 V) 37-132 kW (525-690 V) | 132-200 kW (380-500 V) 160-315 kW (525-690 V) |
| IP | | 21 | 54 | 21 | 54 | 00 | 00 |
| NEMA | | Type 1 | Type 12 | Type 1 | Type 12 | Chassis | Chassis |
| Shipping dimensions | Height | 650 | 650 | 650 | 650 | 650 | 650 |
| | Width | 1730 | 1730 | 1730 | 1730 | 1220 | 1490 |
| | Depth | 570 | 570 | 570 | 570 | 570 | 570 |
| Frequency converter dimensions | Height | 1209 | 1209 | 1589 | 1589 | 1046 | 1327 |
| | Width | 420 | 420 | 420 | 420 | 408 | 408 |
| | Depth | 380 | 380 | 380 | 380 | 375 | 375 |
| | Max weight [kg] | 104 | 104 | 151 | 151 | 91 | 138 |

Table 3.1 Mechanical dimensions [mm], frame size D

| Frame size | | E1 | E2 | F1 | F2 | F3 | F4 |
|--------------------------------|------------|--|--|--|---|--|---|
| | | 250-400 kW (380-500 V) 355-560 kW (525-690 V) | 250-400 kW (380-500 V) 355-560 kW (525-690 V) | 450-630 kW (380-500 V) 630-800 kW (525-690 V) | 710-800 kW (380-500 V) 900-1200 kW (525-690 V) | 450-630 kW (380-500 V) 630-800 kW (525-690 V) | 710-800 kW (380-500 V) 900-1200 kW (525-690 V) |
| IP | | 21, 54 | 00 | 21, 54 | 21, 54 | 21, 54 | 21, 54 |
| NEMA | | Type 12 | Chassis | Type 12 | Type 12 | Type 12 | Type 12 |
| Shipping dimensions | Height | 840 | 831 | 2324 | 2324 | 2324 | 2324 |
| | Width | 2197 | 1705 | 1569 | 1962 | 2159 | 2559 |
| | Depth | 736 | 736 | 1130 | 1130 | 1130 | 1130 |
| Frequency converter dimensions | Height | 2000 | 1547 | 2204 | 2204 | 2204 | 2204 |
| | Width | 600 | 585 | 1400 | 1800 | 2000 | 2400 |
| | Depth | 494 | 498 | 606 | 606 | 606 | 606 |
| | Max weight | 313 | 277 | 1004 | 1246 | 1299 | 1541 |

Table 3.2 Mechanical dimensions [mm], frame sizes E and F

3.1.6 Rated Power

3





| Frame size | | D1 | D2 | D3 | D4 |
|--|------|--|--|---|--|
| | |  130BA816.10 |  130BA817.10 |  130BA819.10 |  130BA820.10 |
| Enclosure protection | IP | 21/54 | 21/54 | 00 | 00 |
| | NEMA | Type 1/Type 12 | Type 1/Type 12 | Chassis | Chassis |
| High overload rated power - 160% overload torque | | 90-110 kW at 400 V (380-500 V) 37-132 kW at 690 V (525-690 V) | 132-200 kW at 400 V (380-500 V) 160-315 kW at 690 V (525-690 V) | 90-110 kW at 400 V (380-500 V) 37-132 kW at 690 V (525-690 V) | 132-200 kW at 400 V (380-500 V) 160-315 kW at 690 V (525-690 V) |

Table 3.3 Rated Power, Enclosure Type D





| Frame size | | E1 | E2 | F1/F3 | F2/F4 |
|--|------|--|--|---|--|
| | |  130BA818.10 |  130BA821.10 |  130BA959.10 |  130BB092.11 |
| Enclosure protection | IP | 21/54 | 00 | 21/54 | 21/54 |
| | NEMA | Type 1/Type 12 | Chassis | Type 1/Type 12 | Type 1/Type 12 |
| High overload rated power - 160% overload torque | | 250-400 kW at 400 V (380-500 V) 355-560 kW at 690 V (525-690 V) | 240-400 kW at 400 V (380-500 V) 355-560 kW at 690 V (525-690 V) | 450-630 kW at 400 V (380-500 V) 630-800 kW at 690 V (525-690 V) | 710-800 kW at 400 V (380-500 V) 900-1200 kW at 690 V (525-690 V) |

Table 3.4 Rated Power, Enclosure Types E and F

NOTICE

The F enclosures have 4 different sizes, F1, F2, F3 and F4. The F1 and F2 consist of an inverter cabinet on the right and rectifier cabinet on the left. The F3 and F4 have an additional options cabinet left of the rectifier cabinet. The F3 is an F1 with an additional options cabinet. The F4 is an F2 with an additional options cabinet.

3.2 Mechanical Installation

Preparation of the mechanical installation of the frequency converter must be done carefully to ensure a proper result and to avoid additional work during installation. Start taking a close look at the mechanical drawings at the end of this instruction to become familiar with the space demands.

3.2.1 Tools Needed

To perform the mechanical installation the following tools are needed:

- Drill with 10 or 12 mm drill
- Tape measure
- Wrench with relevant metric sockets (7-17mm)
- Extensions to wrench
- Sheet metal punch for conduits or cable glands in IP21/Nema 1 and IP54 units
- Lifting bar to lift the unit (rod or tube max. Ø 5 mm (1 inch), able to lift minimum 400 kg (880 lbs)).
- Crane or other lifting aid to place the frequency converter in position
- A Torx T50 tool is needed to install the E1 in IP21 and IP54 enclosure types.

3.2.2 General Considerations

Wire access

Ensure that proper cable access is present including necessary bending allowance. As the IP00 enclosure is open to the bottom cables must be fixed to the back panel of the enclosure where the frequency converter is mounted, i.e. by using cable clamps.

CAUTION

All cable lugs/shoes must mount within the width of the terminal bus bar.

Space

Ensure proper space above and below the frequency converter to allow airflow and cable access. In addition space in front of the unit must be considered to enable opening of the door of the panel.




Illustration 3.9 Space in Front of IP21/IP54 Rated Enclosure Types D1 and D2




Illustration 3.10 Space in Front of IP21/IP54 Rated Enclosure Type E1




Illustration 3.11 Space in Front of IP21/IP54 Rated Enclosure Type F1




Illustration 3.12 Space in Front of IP21/IP54 Rated Enclosure Type F3




Illustration 3.13 Space in Front of IP21/IP54 Rated Enclosure Type F2

3




Illustration 3.14 Space in Front of IP21/IP54 Rated Enclosure Type F4

3.2.3 Terminal Locations - Enclosure Type D

Consider the following terminal positions when designing for cables access.





Illustration 3.15 Position of Power Connections, Enclosure Types D3 and D4



3

Illustration 3.16 Position of Power Connections with Disconnect Switch, Enclosure Types D1 and D2

Be aware that the power cables are heavy and hard to bend. Consider the optimum position of the frequency converter for ensuring easy installation of the cables.

NOTICE

All D enclosures are available with standard input terminals or disconnect switch. All terminal dimensions can be found in *Table 3.5*.

3


| | IP21 (NEMA 1)/IP54 (NEMA 12) | | IP00/Chassis | |
|---|------------------------------|------------|--------------|------------|
| | D1 | D2 | D3 | D4 |
| A | 277 (10.9) | 379 (14.9) | 119 (4.7) | 122 (4.8) |
| B | 227 (8.9) | 326 (12.8) | 68 (2.7) | 68 (2.7) |
| C | 173 (6.8) | 273 (10.8) | 15 (0.6) | 16 (0.6) |
| D | 179 (7.0) | 279 (11.0) | 20.7 (0.8) | 22 (0.8) |
| E | 370 (14.6) | 370 (14.6) | 363 (14.3) | 363 (14.3) |
| F | 300 (11.8) | 300 (11.8) | 293 (11.5) | 293 (11.5) |
| G | 222 (8.7) | 226 (8.9) | 215 (8.4) | 218 (8.6) |
| H | 139 (5.4) | 142 (5.6) | 131 (5.2) | 135 (5.3) |
| I | 55 (2.2) | 59 (2.3) | 48 (1.9) | 51 (2.0) |
| J | 354 (13.9) | 361 (14.2) | 347 (13.6) | 354 (13.9) |
| K | 284 (11.2) | 277 (10.9) | 277 (10.9) | 270 (10.6) |
| L | 334 (13.1) | 334 (13.1) | 326 (12.8) | 326 (12.8) |
| M | 250 (9.8) | 250 (9.8) | 243 (9.6) | 243 (9.6) |
| N | 167 (6.6) | 167 (6.6) | 159 (6.3) | 159 (6.3) |
| O | 261 (10.3) | 260 (10.3) | 261 (10.3) | 261 (10.3) |
| P | 170 (6.7) | 169 (6.7) | 170 (6.7) | 170 (6.7) |
| Q | 120 (4.7) | 120 (4.7) | 120 (4.7) | 120 (4.7) |
| R | 256 (10.1) | 350 (13.8) | 98 (3.8) | 93 (3.7) |
| S | 308 (12.1) | 332 (13.0) | 301 (11.8) | 324 (12.8) |
| T | 252 (9.9) | 262 (10.3) | 245 (9.6) | 255 (10.0) |
| U | 196 (7.7) | 192 (7.6) | 189 (7.4) | 185 (7.3) |
| V | 260 (10.2) | 273 (10.7) | 260 (10.2) | 273 (10.7) |

Table 3.5 Cable Positions Dimensions in mm (inch)

3.2.4 Terminal Locations - E Enclosures

Terminal Locations - E1

Take the following position of the terminals into consideration when designing the cable access.



176FA278.10

3

Illustration 3.17 IP21 (NEMA Type 1) and IP54 (NEMA Type 12) Enclosure Power Connection Positions

3





Illustration 3.18 IP21 (NEMA type 1) and IP54 (NEMA type 12)
Enclosure Power Connection Positions (Detail B)



3

Illustration 3.19 IP21 (NEMA type 1) and IP54 (NEMA type 12) Enclosure Power Connection Position of Disconnect Switch

| Enclosure types | Unit type | Dimensions [mm]/(inch) | | | | | |
|-----------------|---|------------------------|------------|------------|------------|------------|------------|
| E1 | IP54/IP21 UL AND NEMA1/NEMA12 | | | | | | |
| | 250/315 kW (400 V) AND 355/450-500/630 KW (690 V) | 396 (15.6) | 267 (10.5) | 332 (13.1) | 397 (15.6) | 528 (20.8) | N/A |
| | 315/355-400/450 kW (400 V) | 408 (16.1) | 246 (9.7) | 326 (12.8) | 406 (16.0) | 419 (16.5) | 459 (18.1) |

Table 3.6 Dimensions for Disconnect Terminal

3

Terminal locations - enclosure type E2

Take the following position of the terminals into consideration when designing the cable access.




Illustration 3.20 IP00 Enclosure Power Connection Positions




Illustration 3.21 IP00 Enclosure Power Connection Positions




Illustration 3.22 IP00 Enclosure Power Connections Positions of Disconnect Switch

NOTICE

The power cables are heavy and difficult to bend. Consider the optimum position of the frequency converter for ensuring easy installation of the cables.

Each terminal allows use of up to 4 cables with cable lugs or use of standard box lug. Earth is connected to relevant termination point in the frequency converter.

If lugs are wider than 39 mm, install supplied barriers on the mains input side of the disconnect.




Illustration 3.23 Terminal in Details

NOTICE

Power connections can be made to positions A or B

3

| Enclosure type | Unit type | Dimensions [mm]/(inch) | | | | | |
|----------------|---|------------------------|------------|------------|------------|-----------|-----------|
| | | A | B | C | D | E | F |
| E2 | IPOO/CHASSIS | | | | | | |
| | 250/315 kW (400 V) AND 355/450-500/630 kW (690 V) | 396 (15.6) | 268 (10.6) | 333 (13.1) | 398 (15.7) | 221 (8.7) | N/A |
| | 315/355-400/450 kW (400 V) | 408 (16.1) | 239 (9.4) | 319 (12.5) | 399 (15.7) | 113 (4.4) | 153 (6.0) |

Table 3.7 Dimensions for Disconnect Terminal

3.2.5 Terminal Locations - Frame size F

NOTICE

The F frames have 4 different sizes, F1, F2, F3 and F4. The F1 and F2 consist of an inverter cabinet on the right and rectifier cabinet on the left. The F3 and F4 have an additional options cabinet left of the rectifier cabinet. The F3 is an F1 with an additional options cabinet. The F4 is an F2 with an additional options cabinet.

Terminal locations - Frame size F1 and F3




Illustration 3.24 Terminal locations - Inverter Cabinet - F1 and F3 (front, left and right side view). The gland plate is 42 mm below .0 level.

- 1) Earth ground bar
- 2) Motor terminals
- 3) Brake terminals




Illustration 3.25 Terminal Locations - Regen Terminals - F1 and F3

Terminal locations - Frame size F2 and F4




Illustration 3.26 Terminal locations - Inverter Cabinet - F2 and F4 (front, left and right side view). The gland plate is 42 mm below .0 level.

1) Earth ground bar

3




Illustration 3.27 Terminal Locations - Regen Terminals - F2 and F4

Terminal locations - Rectifier (F1, F2, F3 and F4)




Illustration 3.28 Terminal locations - Rectifier (Left side, front and right side view). The gland plate is 42 mm below .0 level.

- 1) Loadshare Terminal (-)
- 2) Earth ground bar
- 3) Loadshare Terminal (+)

Terminal locations - Options Cabinet (F3 and F4)




Illustration 3.29 Terminal locations - Options Cabinet (Left side, front and right side view). The gland plate is 42 mm below .0 level.

1) Earth ground bar

Terminal locations - Options Cabinet with circuit breaker/ molded case switch (F3 and F4)




Illustration 3.30 Terminal locations - Options Cabinet with circuit breaker/ molded case switch (Left side, front and right side view). The gland plate is 42 mm below .0 level.

1) Earth ground bar

| Power size | 2 | 3 | 4 | 5 |
|---|------|------|-------|-------|
| 450 kW (480 V), 630-710 kW (690 V) | 34.9 | 86.9 | 122.2 | 174.2 |
| 500-800 kW (480 V), 800-1000 kW (690 V) | 46.3 | 98.3 | 119.0 | 171.0 |

Table 3.8 Dimension for Terminal

3.2.6 Cooling and Airflow

Cooling

Cooling can be obtained in different ways, by using the cooling ducts in the bottom and the top of the unit, by taking air in and out the back of the unit or by combining the cooling possibilities.

Duct cooling

A dedicated option has been developed to optimize installation of IP00/chassis frequency converters in Rittal TS8 enclosures utilizing the fan of the frequency converter for forced air cooling of the backchannel. The air out the top of the enclosure could but ducted outside a facility so the heat losses from the backchannel are not dissipated within the control room reducing air-conditioning requirements of the facility.

Please see *Installation of Duct Cooling Kit in Rittal enclosures*, for further information.

Back cooling

The backchannel air can also be ventilated in and out the back of a Rittal TS8 enclosure. This offers a solution where the backchannel could take air from outside the facility

and return the heat losses outside the facility thus reducing air-conditioning requirements.

NOTICE

A door fan(s) is required on the enclosure to remove the heat losses not contained in the backchannel of the frequency converter and any additional losses generated from other components installed inside the enclosure. The total required air flow must be calculated so that the appropriate fans can be selected. Some enclosure manufacturers offer software for performing the calculations (i.e. Rittal Therm software). If the frequency converter is the only heat generating component in the enclosure, the minimum airflow required at an ambient temperature of 45 °C for the D3 and D4 frequency converters is 391 m³/h (230 cfm). The minimum airflow required at an ambient temperature of 45 °C for the E2 frequency converter is 782 m³/h (460 cfm).

Airflow

The necessary airflow over the heat sink must be secured. The flow rate is shown below.

| Enclosure protection | Frame size | Door fan(s)/Top fan airflow | Heat sink fan(s) |
|-----------------------------|-----------------------------|----------------------------------|----------------------------------|
| IP21/NEMA 1 IP54/NEMA 12 | D1 and D2 | 170 m ³ /h (100 cfm) | 765 m ³ /h (450 cfm) |
| | E1 P250T5, P355T7, P400T7 | 340 m ³ /h (200 cfm) | 1105 m ³ /h (650 cfm) |
| | E1P315-P400T5, P500-P560T7 | 340 m ³ /h (200 cfm) | 1445 m ³ /h (850 cfm) |
| IP21/NEMA 1 | F1, F2, F3 and F4 | 700 m ³ /h (412 cfm)* | 985 m ³ /h (580 cfm)* |
| IP54/NEMA 12 | F1, F2, F3 and F4 | 525 m ³ /h (309 cfm)* | 985 m ³ /h (580 cfm)* |
| IP00/Chassis | D3 and D4 | 255 m ³ /h (150 cfm) | 765 m ³ /h (450 cfm) |
| | E2 P250T5, P355T7, P400T7 | 255 m ³ /h (150 cfm) | 1105 m ³ /h (650 cfm) |
| | E2 P315-P400T5, P500-P560T7 | 255 m ³ /h (150 cfm) | 1445 m ³ /h (850 cfm) |

* Airflow per fan. Frame size F contain multiple fans.

Table 3.9 Heat sink Air Flow

NOTICE

The fan runs for the following reasons:

- AMA
- DC Hold
- Pre-Mag
- DC Brake
- 60% of nominal current is exceeded
- Specific heatsink temperature exceeded (power size dependent).
- Specific Power Card ambient temperature exceeded (power size dependent)
- Specific Control Card ambient temperature exceeded

Once the fan is started it runs for minimum 10 minutes.

External ducts

If additional duct work is added externally to the Rittal cabinet the pressure drop in the ducting must be calculated. Use the charts below to derate the frequency converter according to the pressure drop.




Illustration 3.31 D frame Derating vs. Pressure Change
Drive air flow: 450 cfm (765 m³/h)




Illustration 3.32 E frame Derating vs. Pressure Change (Small Fan), P250T5 and P355T7-P400T7
Drive air flow: 650 cfm (1105 m³/h)




Illustration 3.33 E frame Derating vs. Pressure Change (Large Fan), P315T5-P400T5 and P500T7-P560T7
Drive air flow: 850 cfm (1445 m³/h)




Illustration 3.34 F1, F2, F3, F4 frame Derating vs. Pressure Change
Drive air flow: 580 cfm (985 m³/h)

3

3.2.7 Installation on the Wall - IP21 (NEMA 1) and IP54 (NEMA 12) Units

This only applies to enclosure types D1 and D2. It must be considered where to install the unit.

Take the relevant points into consideration before selecting the final installation site:

- Free space for cooling
- Access to open the door
- Cable entry from the bottom

Mark the mounting holes carefully using the mounting template on the wall and drill the holes as indicated. Ensure proper distance to the floor and the ceiling for cooling. A minimum of 225 mm (8.9 inch) below the frequency converter is needed. Mount the bolts at the bottom and lift the frequency converter up on the bolts. Tilt the frequency converter against the wall and mount the upper bolts. Tighten all 4 bolts to secure the frequency converter against the wall.




Illustration 3.35 Lifting Method for Mounting Frequency Converter on Wall




Illustration 3.36 Example of Proper Installation of Gland Plate.

Cable entries viewed from the bottom of the frequency converter - 1) Mains side 2) Motor side




Illustration 3.37 Enclosure Types D1 + D2

3.2.8 Gland/Conduit Entry - IP21 (NEMA 1) and IP54 (NEMA12)

Cables are connected through the gland plate from the bottom. Remove the plate and plan where to place the entry for the glands or conduits. Prepare holes in the marked area on the drawing.

NOTICE

The gland plate must be fitted to the frequency converter to ensure the specified protection degree, as well as ensuring proper cooling of the unit. If the gland plate is not mounted, the frequency converter may trip on Alarm 69, Pwr. Card Temp




Illustration 3.38 Enclosure Type E1




Illustration 3.40 Enclosure Type F2

Enclosure types F1-F4: Cable entries viewed from the bottom of the frequency converter - 1) Place conduits in marked areas




Illustration 3.39 Enclosure Type F1




Illustration 3.41 Enclosure Type F3





Illustration 3.42 Enclosure Type F4

3

3.2.9 IP21 Drip Shield Installation (Enclosure Types D1 and D2)

To comply with the IP21 rating, a separate drip shield is to be installed as explained below:

- Remove the 2 front screws
- Insert the drip shield and replace screws
- Tighten the screws to 5.6 Nm (50 in-lbs)




176FA285.10

Illustration 3.43 Drip Shield Installation.

3.3 Field Installation of Options

3.3.1 Installation of Duct Cooling Kit in Rittal Enclosures

This section deals with the installation of IP00/chassis enclosed frequency converters with duct work cooling kits in Rittal enclosures. In addition to the enclosure a 200 mm base/plinth is required.



176FA252.10

Illustration 3.44 Installation of IP00 in Rittal TS8 Enclosure.

The minimum enclosure dimension is:

- D3 and D4 enclosures: Depth 500 mm and width 600 mm.
- E2 enclosure: Depth 600 mm and width 800 mm.

The maximum depth and width are as required by the installation. When using multiple frequency converters in one enclosure, it is recommended that each frequency converter is mounted on its own back panel and

supported along the mid-section of the panel. These duct work kits do not support the “in frame” mounting of the panel (see Rittal TS8 catalogue for details). The duct work cooling kits listed in *Table 3.10* are suitable for use only with IP00/Chassis frequency converters in Rittal TS8 IP 20 and UL and NEMA 1 and IP 54 and UL and NEMA 12 enclosures.

CAUTION

For the E2 enclosures it is important to mount the plate at the absolute rear of the Rittal enclosure due to the weight of the frequency converter.

CAUTION

A doorfan(s) is required on the enclosure to remove the heat losses not contained in the backchannel of the frequency converter and any additional losses generated from other components installed inside the enclosure. The total required airflow must be calculated so that the appropriate fans can be selected. Some enclosure manufacturers offer software for performing the calculations (i.e. Rittal Therm software). If the frequency converter is the only heat generating component in the enclosure, the minimum airflow required at an ambient temperature of 45 °C for the D3 and D4 frequency converters is 391 m³/h (230 cfm). The minimum airflow required at an ambient temperature of 45 °C for the E2 frequency converter is 782 m³/h (460 cfm).

| Rittal TS-8 Enclosure | Enclosure type D3 Kit Part No. | Enclosure type D4 Kit Part No. | Enclosure type E2 Part No. |
|-----------------------|--------------------------------|--------------------------------|----------------------------|
| 1800 mm | 176F1824 | 176F1823 | Not possible |
| 2000 mm | 176F1826 | 176F1825 | 176F1850 |
| 2200 mm | | | 176F0299 |

Table 3.10 Ordering Information

NOTICE

See the instruction *Duct Work Cooling Kit Instruction for Frames D3, D4 and E2* for further information.

External ducts

If additional duct work is added externally to the Rittal cabinet the pressure drop in the ducting must be calculated. See *chapter 3.2.6 Cooling and Airflow* for further information.

3.3.2 Installation of Top-only Duct Cooling Kit

This description is for the installation of the top section only of the back-channel cooling kits available for frame sizes D3, D4 and E2. In addition to the enclosure a 200 mm vented pedestal is required.

The minimum enclosure depth is 500 mm (600 mm for E2 frame) and the minimum enclosure width is 600 mm (800 mm for E2 frame). The maximum depth and width are as required by the installation. When using multiple frequency converters in one enclosure mount each frequency converter on its own back panel and support along the mid-section of the panel. The back-channel cooling kits are very similar in construction for all frames. The D3 and D443 and 44 kits do not support “in frame” mounting of the frequency converters. The E2 kit is mounted “in frame” for additional support of the frequency converter.

Using these kits as described removes 85% of the losses via the back channel using the frequency converter’s main heat sink fan. The remaining 15% must be removed via the door of the enclosure.

NOTICE

See the *Top-Only Back-Channel Cooling Kit Instruction, 175R1107*, for further information.

Ordering information

Frame size D3 and D4: 176F1775

Frame size E2: 176F1776

3.3.3 Installation of Top and Bottom Covers for Rittal Enclosures

The top and bottom covers, installed onto IP00 frequency converters, direct the heat sink cooling air in and out the back of the frequency converter. The kits are applicable to IP00 frequency converterframes D3, D4 and E2. These kits are designed and tested to be used with IP00/Chassis frequency converters in Rittal TS8 enclosures.

Notes:

1. If external duct work is added to the exhaust path of the frequency converter, additional back pressure reduces the cooling of the frequency converter. The frequency converter must be derated to accommodate the reduced cooling. First, the pressure drop must be calculated, then refer to the derating tables located earlier in this section.
2. A doorfan(s) is required on the enclosure to remove the heat losses not contained in the backchannel of the frequency converter and any

additional losses generated from other components installed inside the enclosure. The total required airflow must be calculated so that the appropriate fans can be selected. Some enclosure manufacturers offer software for performing the calculations (i.e. Rittal Therm software).

If the frequency converter is the only heat generating component in the enclosure, the minimum airflow required at an ambient temperature of 45 °C for the D3 and D4 frame frequency converter is 391 m³/h (230 cfm). The minimum airflow required at an ambient temperature of 45 °C for the E2 frame frequency converter is 782 m³/h (460 cfm).

NOTICE

See the instruction for *Top and Bottom Covers - Rittal Enclosure, 177R0076*, for further information.

Ordering information

Frame size D3: 176F1781

Frame size D4: 176F1782

Frame size E2: 176F1783

3.3.4 Installation of Top and Bottom Covers

Top and bottom covers can be installed on frame sizes D3, D4 and E2. These kits are designed to be used to direct the back-channel airflow in and out the back of the frequency converter as opposed to in the bottom and out the top of the frequency converter (when the frequency converters are being mounted directly on a wall or inside a welded enclosure).

Notes:

1. If external duct work is added to the exhaust path of the frequency converter, additional back pressure reduces the cooling of the frequency converter. The frequency converter must be derated to accommodate the reduced cooling. First, the pressure drop must be calculated, then refer to the derating tables located earlier in this section.
2. A doorfan(s) is required on the enclosure to remove the heat losses not contained in the backchannel of the frequency converter and any additional losses generated from other components installed inside the enclosure. The total required airflow must be calculated so that the appropriate fans can be selected. Some enclosure manufacturers offer software for performing the calculations (i.e. Rittal Therm software).

If the frequency converter is the only heat generating component in the enclosure, the minimum airflow required at an ambient temperature of 45 °C for the D3 and D4 frame frequency converters is 391 m³/h (230 cfm). The minimum airflow required at an ambient temperature of 45 °C for the E2 frame frequency converter is 782 m³/h (460 cfm).

NOTICE

See the *Top and Bottom Covers Only Instruction, 175R1106*, for further information.

Ordering information

Frame size D3 and D4: 176F1862

Frame size E2: 176F1861

3.3.5 Outside Installation/NEMA 3R Kit for Rittal Enclosures




Illustration 3.45

This section is for the installation of NEMA 3R kits available for the frequency converter enclosure types D3, D4 and E2. These kits are designed and tested to be used with IP00/Chassis versions of these enclosure types in Rittal TS8 NEMA 3R or NEMA 4 enclosures. The NEMA-3R enclosure is an outdoor enclosure that provides a degree of protection against rain and ice. The NEMA-4 enclosure is an outdoor

enclosure that provides a greater degree of protection against weather and hosed water. The minimum enclosure depth is 500 mm (600 mm for enclosure type E2) and the kit is designed for a 600 mm (800 mm for enclosure type E2) wide enclosure. Other enclosure widths are possible, however additional Rittal hardware is required. The maximum depth and width are as required by the installation.

NOTICE

The current rating of frequency converters in enclosure types D3 and D4 are de-rated by 3%, when adding the NEMA 3R kit. Frequency converters in enclosure type E2 require no derating.

NOTICE

A doorfan(s) is required on the enclosure to remove the heat losses not contained in the backchannel of the frequency converter and any additional losses generated from other components installed inside the enclosure. The total required airflow must be calculated so that the appropriate fans can be selected. Some enclosure manufacturers offer software for performing the calculations (i.e. Rittal Therm software). If the frequency converter is the only heat generating component in the enclosure, the minimum airflow required at an ambient temperature of 45 °C for the D3 and D4 frequency converters is 391 m³/h (230 cfm). The minimum airflow required at an ambient temperature of 45 °C for the E2 frequency converter is 782 m³/h (460 cfm).

Ordering information

Enclosure type D3: 176F4600

Enclosure type D4: 176F4601

Enclosure type E2: 176F1852

NOTICE

See the instructions *Installation of NEMA 3R Kit for IP00 Frames D3, D4 & E2* for further information.

3.3.6 Outside Installation/NEMA 3R Kit of Industrial Enclosures

The kits are available for the frame sizes D3, D4 and E2. These kits are designed and tested to be used with IP00/Chassis frequency converters in welded box construction enclosures with an environmental rating of NEMA-3R or NEMA-4. The NEMA-3R enclosure is a dust tight, rain tight, ice resistant, outdoor enclosure. The NEMA-4 enclosure is a dust tight and water tight enclosure. This kit has been tested and complies with UL environmental rating Type-3R.

Note: The current rating of D3 and D4 frame frequency converters are de-rated by 3% when installed in a NEMA-3R enclosure. E2 frame frequency converters require no derating when installed in a NEMA-3R enclosure.

NOTICE

See the instruction for *Outside Installation/NEMA 3R kit of industrial enclosures, 175R1068*, for further information.

Ordering information

Frame size D3: 176F0296

Frame size D4: 176F0295

Frame size E2: 176F0298

3.3.7 Installation of IP00 to IP20 Kits

The kits can be installed on frame sizes D3, D4, and E2 (IP00).

CAUTION

See the instruction for *Installation of IP20 Kits, 175R1108*, for further information.

Ordering information

Frame size D3/D4: 176F1779

Frame size E2: 176FXXXX

3.3.8 Installation of IP00s D3, D4, & E2 Cable Clamp Bracket

The motor cable clamp brackets can be installed on frame sizes D3 and D4 (IP00).

NOTICE

See the instruction for *Cable Clamp Bracket Kit, 175R1109*, for further information.

Ordering information

Frame size D3: 176F1774

Frame size D4: 176F1746

Frame size E2: 176F1745

3.3.9 Installation on Pedestal

This section describes the installation of a pedestal unit available for the frequency converters enclosure types D1 and D2. This is a 200 mm high pedestal that allows these enclosure types to be floor mounted. The front of the pedestal has openings for input air to the power components.

The frequency converter gland plate must be installed to provide adequate cooling air to the control components of

the frequency converter via the door fan and to maintain the IP21/NEMA 1 or IP54/NEMA 12 degrees of enclosure protections.

3




Illustration 3.46 Frequency Converter on Pedestal

There is one pedestal that fits both enclosure types D1 and D2. Its ordering number is 176F1827. The pedestal is standard for enclosure type E1.




Illustration 3.47 Mounting of Frequency Converter to Pedestal

NOTICE

See the *Pedestal Kit Instruction Manual*, for further information.

3.3.10 Installation of Mains Shield for Frequency Converters

This section is for the installation of a mains shield for the frequency converter series with enclosure types D1, D2 and E1. It is not possible to install in the IP00/Chassis versions as these have included as standard a metal cover. These shields satisfy VBG-4 requirements.

Ordering numbers:

- Enclosure types D1 and D2: 176F0799
- Enclosure type E1: 176F1851

NOTICE

For further information, see the *Instruction Sheet, 175R5923*

3.3.11 Installation of Input Plate Options

This section is for the field installation of input option kits available for frequency converters in all enclosure types D and E.

Do not attempt to remove RFI filters from input plates. Damage may occur to RFI filters if they are removed from the input plate.

NOTICE

Where RFI filters are available, there are 2 different type of RFI filters depending on the input plate combination and the RFI filters interchangeable. Field installable kits in certain cases are the same for all voltages.

| | 380-480 V 380-500 V | Fuses | Disconnect Fuses | RFI | RFI Fuses | RFI Disconnect Fuses |
|----|--|----------|------------------|----------|-----------|----------------------|
| D1 | All D1 power sizes | 176F8442 | 176F8450 | 176F8444 | 176F8448 | 176F8446 |
| D2 | All D2 power sizes | 176F8443 | 176F8441 | 176F8445 | 176F8449 | 176F8447 |
| E1 | FC 102/ FC 202: 315 kW FC 302: 250 kW | 176F0253 | 176F0255 | 176F0257 | 176F0258 | 176F0260 |
| | FC 102/ FC 202: 355 - 450 kW FC 302: 315 - 400 kW | 176F0254 | 176F0256 | 176F0257 | 176F0259 | 176F0262 |

Table 3.11 Fuses

| | 525 - 690 V | Fuses | Disconnect Fuses | RFI | RFI Fuses | RFI Disconnect Fuses |
|----|--|----------|------------------|----------|-----------|----------------------|
| D1 | FC 102/ FC 202: 45-90 kW FC 302: 37-75 kW | 175L8829 | 175L8828 | 175L8777 | NA | NA |
| | FC 102/ FC 202: 110-160 kW FC 302: 90-132 kW | 175L8442 | 175L8445 | 175L8777 | NA | NA |
| D2 | All D2 power sizes | 175L8827 | 175L8826 | 175L8825 | NA | NA |
| E1 | FC 102/ FC 202: 450-500 kW FC 302: 355-400 kW | 176F0253 | 176F0255 | NA | NA | NA |
| | FC 102/ FC 202: 560-630 kW FC 302: 500-560 kW | 176F0254 | 176F0258 | NA | NA | NA |

Table 3.12

NOTICE

For further information, see the Instruction *Installation of Field Installable Kits for VLT Drives*

3.3.12 Installation of D or E Loadshare Option

The loadshare option can be installed on frame sizes D1, D2, D3, D4, E1 and E2.

NOTICE

See the *Loadshare Terminal Kit Instructions, 175R5637 (D frames) or 177R1114 (E frames)*, for further information.

Ordering information

- Frame size D1/D3: 176F8456
- Frame size D2/D4: 176F8455
- Frame size E1/E2: 176F1843

3.4 F Enclosure Panel Options

3.4.1 Enclosure Type F Options

Space Heaters and Thermostat

Mounted on the cabinet interior of enclosure type F frequency converters, space heaters controlled via automatic thermostat help control humidity inside the enclosure, extending the lifetime of frequency converter components in damp environments. The thermostat default settings turn on the heaters at 10 °C (50 °F) and turn them off at 15.6 °C (60 °F).

Cabinet Light with Power Outlet

A light mounted on the cabinet interior of enclosure type F frequency converters increase visibility during servicing and maintenance. The housing the light includes a power outlet for temporarily powering tools or other devices, available in two voltages:

- 230 V, 50 Hz, 2.5 A, CE/ENEC
- 120 V, 60 Hz, 5 A, UL/cUL

Transformer Tap Setup

If the cabinet light & outlet and/or the space heaters & thermostat are installed Transformer T1 requires it taps to be set to the proper input voltage. A 380-480/500 V frequency converter is set initially to the 525 V tap and a 525-690 V frequency converter is set to the 690 V tap to insure no overvoltage of secondary equipment occurs if the tap is not changed before power is applied. See *Table 3.13* to set the proper tap at terminal T1 located in the rectifier cabinet. For location in the frequency converter, see *Illustration 3.48*.

| Input Voltage Range [V] | Tap to Select |
|-------------------------|---------------|
| 380-440 | 400 V |
| 441-490 | 460 V |
| 491-550 | 525 V |
| 551-625 | 575 V |
| 626-660 | 660 V |
| 661-690 | 690 V |

Table 3.13

NAMUR Terminals

NAMUR is an international association of automation technology users in the process industries, primarily chemical and pharmaceutical industries in Germany. Selection of this option provides terminals organized and labeled to the specifications of the NAMUR standard for frequency converter input and output terminals. This requires MCB 112 PTC Thermistor Card and MCB 113 Extended Relay Card.

RCD (Residual Current Device)

Uses the core balance method to monitor ground fault currents in grounded and high-resistance grounded systems (TN and TT systems in IEC terminology). There is a pre-warning (50% of main alarm set-point) and a main alarm set-point. Associated with each set-point is an SPDT alarm relay for external use. Requires an external "window-type" current transformer (supplied and installed by customer).

- Integrated into the frequency converter's safe-stop circuit
- IEC 60755 Type B device monitors AC, pulsed DC, and pure DC ground fault currents
- LED bar graph indicator of the ground fault current level from 10–100% of the set-point
- Fault memory
- [TEST/RESET]

Insulation Resistance Monitor (IRM)

Monitors the insulation resistance in ungrounded systems (IT systems in IEC terminology) between the system phase conductors and ground. There is an ohmic pre-warning and a main alarm set-point for the insulation level. Associated with each set-point is an SPDT alarm relay for external use. Note: only one insulation resistance monitor can be connected to each ungrounded (IT) system.

- Integrated into the frequency converter's safe-stop circuit
- LCD display of the ohmic value of the insulation resistance
- Fault Memory
- [INFO], [TEST], and [RESET]

IEC Emergency Stop with Pilz Safety Relay

Includes a redundant 4-wire emergency-stop push-button mounted on the front of the enclosure and a Pilz relay that monitors it in conjunction with the frequency converter's safe-stop circuit and the mains contactor located in the options cabinet.

Safe Stop + Pilz Relay

Provides a solution for the "Emergency Stop" option without the contactor in F-Enclosure frequency converters.

Manual Motor Starters

Provides 3-phase power for electric blowers often required for larger motors. Power for the starters is provided from the load side of any supplied contactor, circuit breaker, or disconnect switch. Power is fused before each motor starter, and is off when the incoming power to the frequency converter is off. Up to 2 starters are allowed (one if a 30 A, fuse-protected circuit is ordered). Integrated into the frequency converter's safe-stop circuit.

Unit features include:

- Operation switch (on/off)
- Short-circuit and overload protection with test function
- Manual reset function

30 A, Fuse-Protected Terminals

- 3-phase power matching incoming mains voltage for powering auxiliary customer equipment
- Not available if 2 manual motor starters are selected
- Terminals are off when the incoming power to the frequency converter is off
- Power for the fused protected terminals will be provided from the load side of any supplied contactor, circuit breaker, or disconnect switch.

24 V DC Power Supply

- 5 A, 120 W, 24 V DC
- Protected against output over-current, overload, short circuits, and over-temperature
- For powering customer-supplied accessory devices such as sensors, PLC I/O, contactors, temperature probes, indicator lights, and/or other electronic hardware
- Diagnostics include a dry DC-ok contact, a green DC-ok LED, and a red overload LED

External Temperature Monitoring

Designed for monitoring temperatures of external system components, such as the motor windings and/or bearings. Includes five universal input modules. The modules are integrated into the frequency converter's safe-stop circuit and can be monitored via a fieldbus network (requires the purchase of a separate module/bus coupler).

Universal inputs (5)

Signal types:

- RTD inputs (including PT100), 3-wire or 4-wire
- Thermocouple
- Analog current or analog voltage

Additional features:

- One universal output, configurable for analog voltage or analog current
- Two output relays (N.O.)
- Dual-line LC display and LED diagnostics
- Sensor lead wire break, short-circuit, and incorrect polarity detection
- Interface setup software

3.5 Electrical Installation

3.5.1 Power Connections

Cabling and Fusing

NOTICE

Cables General

All cabling must comply with national and local regulations on cable cross-sections and ambient temperature. UL applications require 75 °C copper conductors. 75 and 90 °C copper conductors are thermally acceptable for the frequency converter to use in non UL applications.

The power cable connections are situated as shown below. Dimensioning of cable cross section must be done in accordance with the current ratings and local legislation. See the *Specifications* section for details.

For protection of the frequency converter, the recommended fuses must be used or the unit must be with built-in fuses. Recommended fuses can be seen in the tables of the fuse section. Always ensure that proper fusing is made according to local regulation.

The mains connection is fitted to the mains switch if this is included.




Illustration 3.48 Power Cable Connections

NOTICE

The motor cable must be screened/armoured. If an unscreened/unarmoured cable is used, some EMC requirements are not complied with. Use a screened/armoured motor cable to comply with EMC emission specifications. For more information, see *EMC specifications* in the *Design Guide*.

See section *General Specifications* for correct dimensioning of motor cable cross-section and length.

Screening of cables

Avoid installation with twisted screen ends (pigtailed). They spoil the screening effect at higher frequencies. If it is necessary to break the screen to install a motor isolator or motor contactor, the screen must be continued at the lowest possible HF impedance.

Connect the motor cable screen to both the de-coupling plate of the frequency converter and to the metal housing of the motor.

Make the screen connections with the largest possible surface area (cable clamp). This is done by using the supplied installation devices within the frequency converter.

Cable-length and cross-section

The frequency converter has been EMC tested with a given length of cable. Keep the motor cable as short as possible to reduce the noise level and leakage currents.

Switching frequency

When frequency converters are used together with Sine-wave filters to reduce the acoustic noise from a motor, the switching frequency must be set according to the instruction in *14-01 Switching Frequency*.

3

| Term. no. | 96 | 97 | 98 | 99 | |
|-----------|----|----|----|------------------|---|
| | U | V | W | PE ¹⁾ | Motor voltage 0-100% of mains voltage. |
| | | | | | 3 wires out of motor |
| | U1 | V1 | W1 | PE ¹⁾ | Delta-connected |
| | W2 | U2 | V2 | | 6 wires out of motor |
| | U1 | V1 | W1 | PE ¹⁾ | Star-connected U2, V2, W2 U2, V2 and W2 to be interconnected separately. |

Table 3.14

¹⁾Protected Earth Connection

NOTICE

In motors without phase insulation paper or other insulation reinforcement suitable for operation with voltage supply (such as a frequency converter), fit a Sine-wave filter on the output of the frequency converter.




Illustration 3.49 Star/Delta Connections




Illustration 3.50 Compact IP21 (NEMA 1) and IP54 (NEMA 12), Enclosure Type D1




Illustration 3.51 Compact IP21 (NEMA 1) and IP54 (NEMA 12) with Disconnect, Fuse and RFI Filter, Enclosure Type D2

| | | | |
|----|--------------|-----|---|
| 1) | AUX Relay | 5) | Brake |
| | 01 02 03 | | -R +R |
| | 04 05 06 | | 81 82 |
| 2) | Temp Switch | 6) | SMPS Fuse (see fuse tables for part number) |
| | 106 104 105 | 7) | AUX Fan |
| 3) | Mains | | 100 101 102 103 |
| | R S T | | L1 L2 L1 L2 |
| | 91 92 93 | 8) | Fan Fuse (see fuse tables for part number) |
| | L1 L2 L3 | 9) | Mains ground |
| 4) | Load sharing | 10) | Motor |
| | -DC +DC | | U V W |
| | 88 89 | | 96 97 98 |
| | | | T1 T2 T3 |

Table 3.15 Legend to Illustration 3.50 and Illustration 3.51

3




Illustration 3.52 Compact IP00 (Chassis), Enclosure Type D3

130BB017.10




Illustration 3.53 Compact IP00 (Chassis) with Disconnect, Fuse and RFI Filter, Enclosure Type D4

130BB018.10

| | | | | | |
|----|-------------|----|---|-----|--|
| 1) | AUX Relay | 4) | Load sharing | 8) | Fan Fuse (see fuse tables for part number) |
| | 01 02 03 | | -DC +DC | 9) | Mains ground |
| | 04 05 06 | | 88 89 | 10) | Motor |
| 2) | Temp Switch | 5) | Brake | | U V W |
| | 106 104 105 | | -R +R | | 96 97 98 |
| 3) | Mains | | 81 82 | | T1 T2 T3 |
| | R S T | 6) | SMPS Fuse (see fuse tables for part number) | | |
| | 91 92 93 | 7) | AUX Fan | | |
| | L1 L2 L3 | | 100 101 102 103 | | |
| | | | L1 L2 L1 L2 | | |

Table 3.16 Legend to Illustration 3.52 and Illustration 3.53




Illustration 3.54 Position of Earth Terminals IP00, Enclosure Type D




Illustration 3.55 Position of Earth Terminals IP21 (NEMA type 1) and IP54 (NEMA type 12)

NOTICE

D2 and D4 shown as examples. D1 and D3 are equivalent.

3




Illustration 3.56 Compact IP21 (NEMA 1) and IP54 (NEMA 12) Enclosure Type E1




Illustration 3.57 Compact IP00 (Chassis) with Disconnect, Fuse and RFI Filter, Enclosure Type E2

| | | | |
|----|-------------|-----|---|
| 1) | AUX Relay | 5) | Load sharing |
| | 01 02 03 | | -DC +DC |
| | 04 05 06 | | 88 89 |
| 2) | Temp Switch | 6) | SMPS Fuse (see fuse tables for part number) |
| | 106 104 105 | 7) | Fan Fuse (see fuse tables for part number) |
| 3) | Mains | 8) | AUX Fan |
| | R S T | | 100 101 102 103 |
| | 91 92 93 | | L1 L2 L1 L2 |
| | L1 L2 L3 | 9) | Mains ground |
| 4) | Brake | 10) | Motor |
| | -R +R | | U V W |
| | 81 82 | | 96 97 98 |
| | | | T1 T2 T3 |

Table 3.17 Legend to Illustration 3.56 and Illustration 3.57






Illustration 3.58 Position of Earth Terminals IP00, Enclosure Type E

3



| | | | |
|----|-------------------------------------|-----|--|
| 1) | 24 V DC, 5 A | 5) | Loadsharing |
| | T1 Output Taps | | -DC +DC |
| | Temp Switch | | 88 89 |
| | 106 104 105 | 6) | Control Transformer Fuses (2 or 4 pieces). See fuse tables for part numbers |
| 2) | Manual Motor Starters | 7) | SMPS Fuse. See fuse tables for part numbers |
| 3) | 30 A Fuse Protected Power Terminals | 8) | Manual Motor Controller fuses (3 or 6 pieces). See fuse tables for part numbers |
| 4) | Mains | 9) | Line Fuses, enclosure types F1 and F2 (3 pieces). See fuse tables for part numbers |
| | R S T | 10) | 30 Amp Fuse Protected Power fuses |
| | L1 L2 L3 | | |


Illustration 3.59 Rectifier Cabinet, Enclosure Types F1, F2, F3 and F4



| | | | |
|----|---------------------------------|----|--|
| 1) | External Temperature Monitoring | 6) | Motor |
| 2) | AUX Relay | | U V W |
| | 01 02 03 | | 96 97 98 |
| | 04 05 06 | | T1 T2 T3 |
| 3) | NAMUR | 7) | NAMUR Fuse. See fuse tables for part numbers |
| 4) | AUX Fan | 8) | Fan Fuses. See fuse tables for part numbers |
| | 100 101 102 103 | 9) | SMPS Fuses. See fuse tables for part numbers |
| | L1 L2 L1 L2 | | |
| 5) | Brake | | |
| | -R +R | | |
| | 81 82 | | |


Illustration 3.60 Inverter Cabinet, Enclosure Types F1 and F3

3



| | | | |
|----|---------------------------------|----|--|
| 1) | External Temperature Monitoring | 6) | Motor |
| 2) | AUX Relay | | U V W |
| | 01 02 03 | | 96 97 98 |
| | 04 05 06 | | T1 T2 T3 |
| 3) | NAMUR | 7) | NAMUR Fuse. See fuse tables for part numbers |
| 4) | AUX Fan | 8) | Fan Fuses. See fuse tables for part numbers |
| | 100 101 102 103 | 9) | SMPS Fuses. See fuse tables for part numbers |
| | L1 L2 L1 L2 | | |
| 5) | Brake | | |
| | -R +R | | |
| | 81 82 | | |

Illustration 3.61 Inverter Cabinet, Enclosure Types F2 and F4



| | | | |
|----|---------------------|----|--|
| 1) | Pilz Relay Terminal | 4) | Safety Relay Coil Fuse with PILZ Relay |
| 2) | RCD or IRM Terminal | | See fuse tables for part numbers |
| 3) | Mains | 5) | Line Fuses, F3 and F4 (3 pieces) |
| | R S T | | See fuse tables for part numbers |
| | 91 92 93 | 6) | Contactor Relay Coil (230 VAC), N/C and N/O Aux Contacts (customer supplied) |
| | L1 L2 L3 | 7) | Circuit Breaker Shunt Trip Control Terminals (230 V AC or 230 V DC) |

Illustration 3.62 Options Cabinet, Enclosure Types F3 and F4

3.5.2 Grounding

The following basic issues need to be considered when installing a frequency converter, so as to obtain electro-magnetic compatibility (EMC).

- Safety grounding: The frequency converter has a high leakage current and must be grounded appropriately for safety reasons. Apply local safety regulations.
- High-frequency grounding: Keep the ground wire connections as short as possible.

Connect the different ground systems at the lowest possible conductor impedance. The lowest possible conductor impedance is obtained by keeping the conductor as short as possible and by using the greatest possible surface area.

The metal cabinets of the different devices are mounted on the cabinet rear plate using the lowest possible HF impedance. This avoids having different HF voltages for the individual devices and avoids the risk of radio interference currents running in connection cables that may be used between the devices. The radio interference has been reduced.

To obtain a low HF impedance, use the fastening bolts of the devices as HF connection to the rear plate. It is necessary to remove insulating paint or similar from the fastening points.

3.5.3 Extra Protection (RCD)

ELCB relays, multiple protective earthing or earthing can be used as extra protection, provided that local safety regulations are complied with.

In case of a ground fault, a DC component may develop in the fault current.

If ELCB relays are used, local regulations must be observed. Relays must be suitable for protection of 3-phase equipment with a bridge rectifier and for a brief discharge on power-up.

See also *Special Conditions* in the *Design Guide*.

3.5.4 RFI Switch

Mains supply isolated from earth

If the frequency converter is supplied from an isolated mains source (IT mains, floating delta and grounded delta) or TT/TN-S mains with grounded leg, the RFI switch is recommended to be turned off (OFF) via *14-50 RFI Filter* on the frequency converter and *14-50 RFI Filter* on the filter. For further reference, see IEC 364-3. In case optimum EMC performance is needed, parallel motors are connected or the motor cable length is above 25 m, it is recommended to set *14-50 RFI Filter* to [ON].

In OFF, the internal RFI capacities (filter capacitors) between the chassis and the intermediate circuit are cut off to avoid damage to the intermediate circuit and to reduce the earth capacity currents (according to IEC 61800-3).

Also refer to the application note *VLT on IT Mains* It is important to use isolation monitors that are capable for use together with power electronics (IEC 61557-8).

3.5.5 Torque

When tightening all electrical connections it is very important to tighten with the correct torque. Too low or too high torque results in a bad electrical connection. Use a torque wrench to ensure correct torque.




Illustration 3.63 Tightening Bolts with a Torque Wrench

| Enclosure types | Terminal | Torque [Nm] (in-lbs) | Bolt size |
|-----------------|--------------------------------|----------------------|-----------|
| D | Mains Motor | 19-40 (168-354) | M10 |
| | Load sharing Brake | 8.5-20.5 (75-181) | M8 |
| E | Mains Motor Load sharing | 19-40 (168-354) | M10 |
| | Brake | 8.5-20.5 (75-181) | M8 |

| Enclosure types | Terminal | Torque [Nm] (in-lbs) | Bolt size |
|-----------------|----------------------|----------------------|-----------------|
| F | Mains | 19-40 | M10 |
| | Motor | (168-354) | |
| | Load sharing | 19-40 | M10 M8 M8 |
| | Brake | (168-354) | |
| Regen | 8.5-20.5 (75-181) | | |
| | | 8.5-20.5 (75-181) | |

Table 3.18 Torque for Terminals

3.5.6 Shielded Cables

WARNING

Danfoss recommends to use shielded cables between the LCL filter and the AFE unit. Unshielded cables can be between transformer and LCL filter input side.

It is important that shielded and armoured cables are connected in a proper way to ensure the high EMC immunity and low emissions.

The connection can be made using either cable glands or clamps

- EMC cable glands: Generally available cable glands can be used to ensure an optimum EMC connection.
- EMC cable clamp: Clamps allowing easy connection are supplied with the frequency converter.

3.5.7 Motor Cable

The motor must be connected to terminals U/T1/96, V/T2/97, W/T3/98. Earth to terminal 99. All types of 3-phase asynchronous standard motors can be used with a frequency converter unit. The factory setting is for clockwise rotation with the frequency converter output connected as follows:

| Terminal No. | Function |
|----------------|---------------------------------|
| 96, 97, 98, 99 | Mains U/T1, V/T2, W/T3 Earth |

Table 3.19 Mains Terminals

- Terminal U/T1/96 connected to U-phase
- Terminal V/T2/97 connected to V-phase
- Terminal W/T3/98 connected to W-phase

Table 3.20

The direction of rotation can be changed by switching 2 phases in the motor cable or by changing the setting of 4-10 Motor Speed Direction.

Motor rotation check can be performed using 1-28 Motor Rotation Check and following the steps shown in the display.

F enclosure requirements

F1/F3 requirements: Motor phase cable quantities must be multiples of 2, resulting in 2, 4, 6, or 8 (1 cable is not allowed) to obtain equal amount of wires attached to both inverter module terminals. The cables are required to be equal length within 10% between the inverter module terminals and the first common point of a phase. The recommended common point is the motor terminals.

F2/F4 requirements: Motor phase cable quantities must be multiples of 3, resulting in 3, 6, 9, or 12 (1 or 2 cables are not allowed) to obtain equal amount of wires attached to each inverter module terminal. The wires are required to be equal length within 10% between the inverter module terminals and the first common point of a phase. The recommended common point is the motor terminals.

Output junction box requirements: The length, minimum 2.5 m, and quantity of cables must be equal from each inverter module to the common terminal in the junction box.

NOTICE

If a retrofit application requires unequal amount of wires per phase, consult the factory for requirements and documentation or use the top/bottom entry side cabinet option.

3

3.5.8 Brake Cable for Frequency Converters with Factory Installed Brake Chopper Option

(Only standard with letter B in position 18 of typecode).

The connection cable to the brake resistor must be screened and the max. length from frequency converter to the DC bar is limited to 25 m (82 ft).

| Terminal No. | Function |
|--------------|--------------------------|
| 81, 82 | Brake resistor terminals |

Table 3.21 Terminals for Brake Resistor

The connection cable to the brake resistor must be screened. Connect the screen with cable clamps to the conductive back plate at the frequency converter and to the metal cabinet of the brake resistor. Size the brake cable cross-section to match the brake torque. See also the instructions *Brake Resistor* and *Brake Resistors for Horizontal Applications* for further information regarding safe installation.

⚠ WARNING

Note that voltages up to 1099 V DC, depending on the supply voltage, may occur on the terminals.

F enclosure requirements

The brake resistor(s) must be connected to the brake terminals in each inverter module.

3.5.9 Load Sharing

| Terminal No. | Function |
|--------------|-------------|
| 88, 89 | Loadsharing |

Table 3.22 Terminals for Load Sharing

The connection cable must be screened and the max. length from the frequency converter to the DC bar is limited to 25 m (82 ft). Load sharing enables linking of the DC intermediate circuits of several frequency converters.

⚠ WARNING

Voltages up to 1099 V DC may occur on the terminals. Load Sharing calls for extra equipment and safety considerations. For further information, see the instructions *Load Sharing*.

⚠ WARNING

Mains disconnect may not isolate the frequency converter due to DC-link connection.

3.5.10 Shielding against Electrical Noise

Before mounting the mains power cable, mount the EMC metal cover to ensure best EMC performance.

NOTICE

The EMC metal cover is only included in units with an RFI filter.




Illustration 3.64 Mounting of EMC Shield.

3.5.11 Mains Connection

Mains must be connected to terminals 91, 92 and 93. Earth is connected to the terminal to the right of terminal 93.

| Terminal No. | Function |
|--------------|------------------------|
| 91, 92, 93 | Mains R/L1, S/L2, T/L3 |
| 94 | Earth |

Table 3.23 Mains Terminals Connection

⚠ CAUTION

Check the name plate to ensure that the mains voltage of the frequency converter matches the power supply of the plant.

Ensure that the power supply can supply the necessary current to the frequency converter.

If the unit is without built-in fuses, ensure that the appropriate fuses have the correct current rating.

3.5.12 External Fan Supply

In case the frequency converter is supplied by DC or if the fan must run independently of the power supply, an external power supply can be applied. The connection is made on the power card.

| Terminal No. | Function |
|--------------|-----------------------|
| 100, 101 | Auxiliary supply S, T |
| 102, 103 | Internal supply S, T |

Table 3.24 External Fan Supply Terminals

The connector located on the power card provides the connection of line voltage for the cooling fans. The fans are connected from factory to be supplied from a common AC line (jumpers between 100-102 and 101-103). If external supply is needed, the jumpers are removed and the supply is connected to terminals 100 and 101. Use a 5 A fuse for protection. In UL applications, use a Littelfuse KLK-5 or equivalent.

3.5.13 Fuses

It is recommended to use fuses and/or circuit breakers on the supply side as protection in case of component break-down inside the frequency converter (first fault).

NOTICE

This is mandatory to ensure compliance with IEC 60364 for CE or NEC 2009 for UL.

WARNING

Personnel and property must be protected against the consequence of component break-down internally in the frequency converter.

Branch circuit protection

To protect the installation against electrical and fire hazard, all branch circuits in an installation, switch gear, machines etc., must be protected against short-circuit and overcurrent according to national/international regulations.

NOTICE

The recommendations given do not cover branch circuit protection for UL.

Short-circuit protection:

Danfoss recommends using the fuses/circuit breakers mentioned below to protect service personnel and property in case of component break-down in the frequency converter.

Non UL compliance

If UL/cUL is not to be complied with, Danfoss recommends using the following fuses, which ensure compliance with EN50178:

In case of malfunction, not following the recommendation may result in unnecessary damage to the frequency converter.

| | | |
|-------------|-------------|---------|
| P90 - P200 | 380 - 500 V | type gG |
| P250 - P400 | 380 - 500 V | type gR |

Table 3.25 Recommended EN 50178 Fuses

UL compliance

| Enclosure | FC 300 power | Recommended fuse size | Recommended max. fuse | Recommended circuit breaker | Max trip level |
|-----------|--------------|--|---------------------------------|-----------------------------|----------------|
| Size | [kW] | | | Moeller | [A] |
| A1 | 0.25-1.5 | gG-10 | gG-25 | PKZM0-16 | 16 |
| A2 | 0.25-2.2 | gG-10 (0.25-1.5) gG-16 (2.2) | gG-25 | PKZM0-25 | 25 |
| A3 | 3.0-3.7 | gG-16 (3) gG-20 (3.7) | gG-32 | PKZM0-25 | 25 |
| B3 | 5.5 | gG-25 | gG-63 | PKZM4-50 | 50 |
| B4 | 7.5-15 | gG-32 (7.5) gG-50 (11) gG-63 (15) | gG-125 | NZMB1-A100 | 100 |
| C3 | 18.5-22 | gG-80 (18.5) aR-125 (22) | gG-150 (18.5) aR-160 (22) | NZMB2-A200 | 150 |
| C4 | 30-37 | aR-160 (30) aR-200 (37) | aR-200 (30) aR-250 (37) | NZMB2-A250 | 250 |
| A4 | 0.25-2.2 | gG-10 (0.25-1.5) gG-16 (2.2) | gG-32 | PKZM0-25 | 25 |
| A5 | 0.25-3.7 | gG-10 (0.25-1.5) gG-16 (2.2-3) gG-20 (3.7) | gG-32 | PKZM0-25 | 25 |
| B1 | 5.5-7.5 | gG-25 (5.5) gG-32 (7.5) | gG-80 | PKZM4-63 | 63 |
| B2 | 11 | gG-50 | gG-100 | NZMB1-A100 | 100 |
| C1 | 15-22 | gG-63 (15) gG-80 (18.5) gG-100 (22) | gG-160 (15-18.5) aR-160 (22) | NZMB2-A200 | 160 |
| C2 | 30-37 | aR-160 (30) aR-200 (37) | aR-200 (30) aR-250 (37) | NZMB2-A250 | 250 |

Table 3.26 200-240 V, Frame Sizes A, B, and C

| Enclosure | FC 300 power | Recommended fuse size | Recommended Max. fuse | Recommended circuit breaker | Max trip level |
|-----------|--------------|---|---|-----------------------------|----------------|
| Size | [kW] | | | Moeller | [A] |
| A1 | 0.37-1.5 | gG-10 | gG-25 | PKZM0-16 | 16 |
| A2 | 0.37-4.0 | gG-10 (0.37-3) gG-16 (4) | gG-25 | PKZM0-25 | 25 |
| A3 | 5.5-7.5 | gG-16 | gG-32 | PKZM0-25 | 25 |
| B3 | 11-15 | gG-40 | gG-63 | PKZM4-50 | 50 |
| B4 | 18.5-30 | gG-50 (18.5) gG-63 (22) gG-80 (30) | gG-125 | NZMB1-A100 | 100 |
| C3 | 37-45 | gG-100 (37) gG-160 (45) | gG-150 (37) gG-160 (45) | NZMB2-A200 | 150 |
| C4 | 55-75 | aR-200 (55) aR-250 (75) | aR-250 | NZMB2-A250 | 250 |
| A4 | 0.37-4 | gG-10 (0.37-3) gG-16 (4) | gG-32 | PKZM0-25 | 25 |
| A5 | 0.37-7.5 | gG-10 (0.37-3) gG-16 (4-7.5) | gG-32 | PKZM0-25 | 25 |
| B1 | 11-15 | gG-40 | gG-80 | PKZM4-63 | 63 |
| B2 | 18.5-22 | gG-50 (18.5) gG-63 (22) | gG-100 | NZMB1-A100 | 100 |
| C1 | 30-45 | gG-80 (30) gG-100 (37) gG-160 (45) | gG-160 | NZMB2-A200 | 160 |
| C2 | 55-75 | aR-200 (55) aR-250 (75) | aR-250 | NZMB2-A250 | 250 |
| D | 90-200 | gG-300 (90) gG-350 (110) gG-400 (132) gG-500 (160) gG-630 (200) | gG-300 (90) gG-350 (110) gG-400 (132) gG-500 (160) gG-630 (200) | - | - |
| E | 250-400 | aR-700 (250) aR-900 (315-400) | aR-700 (250) aR-900 (315-400) | - | - |
| F | 450-800 | aR-1600 (450-500) aR-2000 (560-630) aR-2500 (710-800) | aR-1600 (450-500) aR-2000 (560-630) aR-2500 (710-800) | - | - |

Table 3.27 380-500 V, Frame Sizes A, B, C, D, E, and F

| Enclosure | FC 300 power | Recommended fuse size | Recommended Max. fuse | Recommended circuit breaker | Max trip level |
|-----------|--------------|--|-------------------------------|-----------------------------|----------------|
| Size | [kW] | | | Moeller | [A] |
| A2 | 0-7.5-4.0 | gG-10 | gG-25 | PKZM0-25 | 25 |
| A3 | 5.5-7.5 | gG-10 (5.5) gG-16 (7.5) | gG-32 | PKZM0-25 | 25 |
| B3 | 11-15 | gG-25 (11) gG-32 (15) | gG-63 | PKZM4-50 | 50 |
| B4 | 18.5-30 | gG-40 (18.5) gG-50 (22) gG-63 (30) | gG-125 | NZMB1-A100 | 100 |
| C3 | 37-45 | gG-63 (37) gG-100 (45) | gG-150 | NZMB2-A200 | 150 |
| C4 | 55-75 | aR-160 (55) aR-200 (75) | aR-250 | NZMB2-A250 | 250 |
| A5 | 0.75-7.5 | gG-10 (0.75-5.5) gG-16 (7.5) | gG-32 | PKZM0-25 | 25 |
| B1 | 11-18 | gG-25 (11) gG-32 (15) gG-40 (18.5) | gG-80 | PKZM4-63 | 63 |
| B2 | 22-30 | gG-50 (22) gG-63 (30) | gG-100 | NZMB1-A100 | 100 |
| C1 | 37-55 | gG-63 (37) gG-100 (45) aR-160 (55) | gG-160 (37-45) aR-250 (55) | NZMB2-A200 | 160 |
| C2 | 75 | aR-200 (75) | aR-250 | NZMB2-A250 | 250 |

Table 3.28 525-600 V, Frame Sizes A, B, and C

| Enclosure | Power [kW] | Recommended fuse size | Recommended Max. fuse | Recommended circuit breaker Moeller | Max trip level [A] |
|-----------|------------|---|---|-------------------------------------|--------------------|
| A3 | 1.1-7.5 | gG-6 (3) gG-10 (2) gG-16 (2) | gG-25 | | |
| B2 | 22-30 | gG-25 (11) gG-32 (15) gG-32 (18) gG-40 (22) | gG-63 | - | - |
| C2 | 75-90 | gG-63 (30) gG-63 (37) gG-80 (45) gG-100 (55) gG-125 (75) | gG-80 (30) gG-100 (37) gG-125 (45) gG-160 (55-75) | - | - |
| C3 | 44-55 | gG-80 gG-100 | gG-100 gG-125 | | |
| D | - | gG-125 (37) gG-160 (45) gG-200 (55-75) aR-250 (90) aR-315 (110) aR-350 (132-160) aR-400 (200) aR-500 (250) aR-550 (315) | gG-125 (37) gG-160 (45) gG-200 (55-75) aR-250 (90) aR-315 (110) aR-350 (132-160) aR-400 (200) aR-500 (250) aR-550 (315) | - | - |
| E | - | aR-700 (355-400) aR-900 (500-560) | aR-700 (355-400) aR-900 (500-560) | - | - |
| F | - | aR-1600 (630-900) aR-2000 (1000) aR-2500 (1200) | aR-1600 (630-900) aR-2000 (1000) aR-2500 (1200) | - | - |

Table 3.29 525-690 V, Frame Sizes A, B, C, D, E and F

UL Compliance

Fuses or circuit breakers are mandatory to comply with NEC 2009. Danfoss recommends using a selection of the following.

The fuses below are suitable for use on a circuit capable of delivering 100,000 A_{rms} (symmetrical), 240 V, or 480 V, or 500 V, or 600 V depending on the frequency converter voltage rating. With the proper fusing the drive Short Circuit Current Rating (SCCR) is 100,000 A_{rms}.

3

| FC 300 Power [kW] | Recommended max. fuse | | | | | |
|-------------------|------------------------|----------|----------|----------|----------|----------|
| | Bussmann | Bussmann | Bussmann | Bussmann | Bussmann | Bussmann |
| | Type RK1 ¹⁾ | Type J | Type T | Type CC | Type CC | Type CC |
| 0.25-0.37 | KTN-R-05 | JKS-05 | JJN-05 | FNQ-R-5 | KTK-R-5 | LP-CC-5 |
| 0.55-1.1 | KTN-R-10 | JKS-10 | JJN-10 | FNQ-R-10 | KTK-R-10 | LP-CC-10 |
| 1.5 | KTN-R-15 | JKS-15 | JJN-15 | FNQ-R-15 | KTK-R-15 | LP-CC-15 |
| 2.2 | KTN-R-20 | JKS-20 | JJN-20 | FNQ-R-20 | KTK-R-20 | LP-CC-20 |
| 3.0 | KTN-R-25 | JKS-25 | JJN-25 | FNQ-R-25 | KTK-R-25 | LP-CC-25 |
| 3.7 | KTN-R-30 | JKS-30 | JJN-30 | FNQ-R-30 | KTK-R-30 | LP-CC-30 |
| 5.5 | KTN-R-50 | KS-50 | JJN-50 | - | - | - |
| 7.5 | KTN-R-60 | JKS-60 | JJN-60 | - | - | - |
| 11 | KTN-R-80 | JKS-80 | JJN-80 | - | - | - |
| 15-18.5 | KTN-R-125 | JKS-125 | JJN-125 | - | - | - |
| 22 | KTN-R-150 | JKS-150 | JJN-150 | - | - | - |
| 30 | KTN-R-200 | JKS-200 | JJN-200 | - | - | - |
| 37 | KTN-R-250 | JKS-250 | JJN-250 | - | - | - |

Table 3.30 200-240 V, Frame Sizes A, B, and C

| FC 300 Power [kW] | Recommended max. fuse | | | |
|-------------------|-----------------------|-------------|----------------|------------------------|
| | SIBA | Littel fuse | Ferraz-Shawmut | Ferraz-Shawmut |
| | Type RK1 | Type RK1 | Type CC | Type RK1 ³⁾ |
| 0.25-0.37 | 5017906-005 | KLN-R-05 | ATM-R-05 | A2K-05-R |
| 0.55-1.1 | 5017906-010 | KLN-R-10 | ATM-R-10 | A2K-10-R |
| 1.5 | 5017906-016 | KLN-R-15 | ATM-R-15 | A2K-15-R |
| 2.2 | 5017906-020 | KLN-R-20 | ATM-R-20 | A2K-20-R |
| 3.0 | 5017906-025 | KLN-R-25 | ATM-R-25 | A2K-25-R |
| 3.7 | 5012406-032 | KLN-R-30 | ATM-R-30 | A2K-30-R |
| 5.5 | 5014006-050 | KLN-R-50 | - | A2K-50-R |
| 7.5 | 5014006-063 | KLN-R-60 | - | A2K-60-R |
| 11 | 5014006-080 | KLN-R-80 | - | A2K-80-R |
| 15-18.5 | 2028220-125 | KLN-R-125 | - | A2K-125-R |
| 22 | 2028220-150 | KLN-R-150 | - | A2K-150-R |
| 30 | 2028220-200 | KLN-R-200 | - | A2K-200-R |
| 37 | 2028220-250 | KLN-R-250 | - | A2K-250-R |

Table 3.31 200-240 V, Frame Sizes A, B, and C

| FC 300 Power [kW] | Recommended max. fuse | | | |
|-------------------|-----------------------------------|-------------------|------------------------------------|------------------|
| | Bussmann Type JFHR2 ²⁾ | Littel fuse JFHR2 | Ferraz-Shawmut JFHR2 ⁴⁾ | Ferraz-Shawmut J |
| 0.25-0.37 | FWX-5 | - | - | HSJ-6 |
| 0.55-1.1 | FWX-10 | - | - | HSJ-10 |
| 1.5 | FWX-15 | - | - | HSJ-15 |
| 2.2 | FWX-20 | - | - | HSJ-20 |
| 3.0 | FWX-25 | - | - | HSJ-25 |
| 3.7 | FWX-30 | - | - | HSJ-30 |
| 5.5 | FWX-50 | - | - | HSJ-50 |
| 7.5 | FWX-60 | - | - | HSJ-60 |
| 11 | FWX-80 | - | - | HSJ-80 |
| 15-18.5 | FWX-125 | - | - | HSJ-125 |
| 22 | FWX-150 | L25S-150 | A25X-150 | HSJ-150 |
| 30 | FWX-200 | L25S-200 | A25X-200 | HSJ-200 |
| 37 | FWX-250 | L25S-250 | A25X-250 | HSJ-250 |

Table 3.32 200-240 V, Frame Sizes A, B, and C

- 1) KTS-fuses from Bussmann may substitute KTN for 240 V frequency converters.
- 2) FWH-fuses from Bussmann may substitute FWX for 240 V frequency converters.
- 3) A6KR fuses from FERRAZ SHAWMUT may substitute A2KR for 240 V frequency converters.
- 4) A50X fuses from FERRAZ SHAWMUT may substitute A25X for 240 V frequency converters.

| FC 300 Power [kW] | Recommended max. fuse | | | | | |
|-------------------|-----------------------|-----------------|-----------------|------------------|------------------|------------------|
| | Bussmann Type RK1 | Bussmann Type J | Bussmann Type T | Bussmann Type CC | Bussmann Type CC | Bussmann Type CC |
| 0.37-1.1 | KTS-R-6 | JKS-6 | JJS-6 | FNQ-R-6 | KTK-R-6 | LP-CC-6 |
| 1.5-2.2 | KTS-R-10 | JKS-10 | JJS-10 | FNQ-R-10 | KTK-R-10 | LP-CC-10 |
| 3 | KTS-R-15 | JKS-15 | JJS-15 | FNQ-R-15 | KTK-R-15 | LP-CC-15 |
| 4 | KTS-R-20 | JKS-20 | JJS-20 | FNQ-R-20 | KTK-R-20 | LP-CC-20 |
| 5.5 | KTS-R-25 | JKS-25 | JJS-25 | FNQ-R-25 | KTK-R-25 | LP-CC-25 |
| 7.5 | KTS-R-30 | JKS-30 | JJS-30 | FNQ-R-30 | KTK-R-30 | LP-CC-30 |
| 11 | KTS-R-40 | JKS-40 | JJS-40 | - | - | - |
| 15 | KTS-R-50 | JKS-50 | JJS-50 | - | - | - |
| 18 | KTS-R-60 | JKS-60 | JJS-60 | - | - | - |
| 22 | KTS-R-80 | JKS-80 | JJS-80 | - | - | - |
| 30 | KTS-R-100 | JKS-100 | JJS-100 | - | - | - |
| 37 | KTS-R-125 | JKS-125 | JJS-125 | - | - | - |
| 45 | KTS-R-150 | JKS-150 | JJS-150 | - | - | - |
| 55 | KTS-R-200 | JKS-200 | JJS-200 | - | - | - |
| 75 | KTS-R-250 | JKS-250 | JJS-250 | - | - | - |

Table 3.33 380-500 V, Frame Sizes A, B, and C

| FC 302 Power | Recommended max. fuse | | | |
|-----------------|-----------------------|-------------|--------------------|--------------------|
| | SIBA | Littel fuse | Ferraz- Shawmut | Ferraz- Shawmut |
| [kW] | Type RK1 | Type RK1 | Type CC | Type RK1 |
| 0.37-1.1 | 5017906-006 | KLS-R-6 | ATM-R-6 | A6K-6-R |
| 1.5-2.2 | 5017906-010 | KLS-R-10 | ATM-R-10 | A6K-10-R |
| 3 | 5017906-016 | KLS-R-15 | ATM-R-15 | A6K-15-R |
| 4 | 5017906-020 | KLS-R-20 | ATM-R-20 | A6K-20-R |
| 5.5 | 5017906-025 | KLS-R-25 | ATM-R-25 | A6K-25-R |
| 7.5 | 5012406-032 | KLS-R-30 | ATM-R-30 | A6K-30-R |
| 11 | 5014006-040 | KLS-R-40 | - | A6K-40-R |
| 15 | 5014006-050 | KLS-R-50 | - | A6K-50-R |
| 18 | 5014006-063 | KLS-R-60 | - | A6K-60-R |
| 22 | 2028220-100 | KLS-R-80 | - | A6K-80-R |
| 30 | 2028220-125 | KLS-R-100 | - | A6K-100-R |
| 37 | 2028220-125 | KLS-R-125 | - | A6K-125-R |
| 45 | 2028220-160 | KLS-R-150 | - | A6K-150-R |
| 55 | 2028220-200 | KLS-R-200 | - | A6K-200-R |
| 75 | 2028220-250 | KLS-R-250 | - | A6K-250-R |

Table 3.34 380-500 V, Frame Sizes A, B, and C

| | Recommended max. fuse | | | |
|--------------|-----------------------|-----------------|---------------------|-------------|
| FC 302 Power | Bussmann | Ferraz- Shawmut | Ferraz- Shawmut | Littel fuse |
| [kW] | JFHR2 | J | JFHR2 ¹⁾ | JFHR2 |
| 0.37-1.1 | FWH-6 | HSJ-6 | - | - |
| 1.5-2.2 | FWH-10 | HSJ-10 | - | - |
| 3 | FWH-15 | HSJ-15 | - | - |
| 4 | FWH-20 | HSJ-20 | - | - |
| 5.5 | FWH-25 | HSJ-25 | - | - |
| 7.5 | FWH-30 | HSJ-30 | - | - |
| 11 | FWH-40 | HSJ-40 | - | - |
| 15 | FWH-50 | HSJ-50 | - | - |
| 18 | FWH-60 | HSJ-60 | - | - |
| 22 | FWH-80 | HSJ-80 | - | - |
| 30 | FWH-100 | HSJ-100 | - | - |
| 37 | FWH-125 | HSJ-125 | - | - |
| 45 | FWH-150 | HSJ-150 | - | - |
| 55 | FWH-200 | HSJ-200 | A50-P-225 | L50-S-225 |
| 75 | FWH-250 | HSJ-250 | A50-P-250 | L50-S-250 |

Table 3.35 380-500 V, Frame Sizes A, B, and C

¹⁾ Ferraz-Shawmut A50QS fuses may substitute for A50P fuses.

| | Recommended max. fuse | | | | | |
|--------------|-----------------------|----------|----------|----------|----------|----------|
| FC 302 Power | Bussmann | Bussmann | Bussmann | Bussmann | Bussmann | Bussmann |
| [kW] | Type RK1 | Type J | Type T | Type CC | Type CC | Type CC |
| 0.75-1.1 | KTS-R-5 | JKS-5 | JJS-6 | FNQ-R-5 | KTK-R-5 | LP-CC-5 |
| 1.5-2.2 | KTS-R-10 | JKS-10 | JJS-10 | FNQ-R-10 | KTK-R-10 | LP-CC-10 |
| 3 | KTS-R15 | JKS-15 | JJS-15 | FNQ-R-15 | KTK-R-15 | LP-CC-15 |
| 4 | KTS-R20 | JKS-20 | JJS-20 | FNQ-R-20 | KTK-R-20 | LP-CC-20 |
| 5.5 | KTS-R-25 | JKS-25 | JJS-25 | FNQ-R-25 | KTK-R-25 | LP-CC-25 |
| 7.5 | KTS-R-30 | JKS-30 | JJS-30 | FNQ-R-30 | KTK-R-30 | LP-CC-30 |
| 11 | KTS-R-35 | JKS-35 | JJS-35 | - | - | - |
| 15 | KTS-R-45 | JKS-45 | JJS-45 | - | - | - |
| 18 | KTS-R-50 | JKS-50 | JJS-50 | - | - | - |
| 22 | KTS-R-60 | JKS-60 | JJS-60 | - | - | - |
| 30 | KTS-R-80 | JKS-80 | JJS-80 | - | - | - |
| 37 | KTS-R-100 | JKS-100 | JJS-100 | - | - | - |
| 45 | KTS-R-125 | JKS-125 | JJS-125 | - | - | - |
| 55 | KTS-R-150 | JKS-150 | JJS-150 | - | - | - |
| 75 | KTS-R-175 | JKS-175 | JJS-175 | - | - | - |

Table 3.36 525-600 V, Frame Sizes A, B, and C

| FC 302 Power | Recommended max. fuse | | | |
|-----------------|-----------------------|-------------|--------------------|--------------------|
| | SIBA | Littel fuse | Ferraz- Shawmut | Ferraz- Shawmut |
| [kW] | Type RK1 | Type RK1 | Type RK1 | J |
| 0.75-1.1 | 5017906-005 | KLS-R-005 | A6K-5-R | HSJ-6 |
| 1.5-2.2 | 5017906-010 | KLS-R-010 | A6K-10-R | HSJ-10 |
| 3 | 5017906-016 | KLS-R-015 | A6K-15-R | HSJ-15 |
| 4 | 5017906-020 | KLS-R-020 | A6K-20-R | HSJ-20 |
| 5.5 | 5017906-025 | KLS-R-025 | A6K-25-R | HSJ-25 |
| 7.5 | 5017906-030 | KLS-R-030 | A6K-30-R | HSJ-30 |
| 11 | 5014006-040 | KLS-R-035 | A6K-35-R | HSJ-35 |
| 15 | 5014006-050 | KLS-R-045 | A6K-45-R | HSJ-45 |
| 18 | 5014006-050 | KLS-R-050 | A6K-50-R | HSJ-50 |
| 22 | 5014006-063 | KLS-R-060 | A6K-60-R | HSJ-60 |
| 30 | 5014006-080 | KLS-R-075 | A6K-80-R | HSJ-80 |
| 37 | 5014006-100 | KLS-R-100 | A6K-100-R | HSJ-100 |
| 45 | 2028220-125 | KLS-R-125 | A6K-125-R | HSJ-125 |
| 55 | 2028220-150 | KLS-R-150 | A6K-150-R | HSJ-150 |
| 75 | 2028220-200 | KLS-R-175 | A6K-175-R | HSJ-175 |

Table 3.37 525-600 V, Frame Sizes A, B, and C

¹⁾ 170M fuses shown from Bussmann use the -/80 visual indicator. -TN/80 Type T, -/110 or TN/110 Type T indicator fuses of the same size and amperage may be substituted.

| Power [kW] | Recommended max. fuse | | | | | |
|---------------|-----------------------|--------------------|--------------------|---------------------|---------------------|---------------------|
| | Bussmann Type RK1 | Bussmann Type J | Bussmann Type T | Bussmann Type CC | Bussmann Type CC | Bussmann Type CC |
| 1.1 | KTS-R-5 | JKS-5 | JJS-6 | FNQ-R-5 | KTK-R-5 | LP-CC-5 |
| 1.5-2.2 | KTS-R-10 | JKS-10 | JJS-10 | FNQ-R-10 | KTK-R-10 | LP-CC-10 |
| 3 | KTS-R15 | JKS-15 | JJS-15 | FNQ-R-15 | KTK-R-15 | LP-CC-15 |
| 4 | KTS-R20 | JKS-20 | JJS-20 | FNQ-R-20 | KTK-R-20 | LP-CC-20 |
| 5.5 | KTS-R-25 | JKS-25 | JJS-25 | FNQ-R-25 | KTK-R-25 | LP-CC-25 |
| 7.5 | KTS-R-30 | JKS-30 | JJS-30 | FNQ-R-30 | KTK-R-30 | LP-CC-30 |
| 11 | KTS-R-35 | JKS-35 | JJS-35 | - | - | - |
| 15 | KTS-R-45 | JKS-45 | JJS-45 | - | - | - |
| 18 | KTS-R-50 | JKS-50 | JJS-50 | - | - | - |
| 22 | KTS-R-60 | JKS-60 | JJS-60 | - | - | - |
| 30 | KTS-R-80 | JKS-80 | JJS-80 | - | - | - |
| 37 | KTS-R-100 | JKS-100 | JJS-100 | - | - | - |
| 45 | KTS-R-125 | JKS-125 | JJS-125 | - | - | - |
| 55 | KTS-R-150 | JKS-150 | JJS-150 | - | - | - |
| 75 | KTS-R-175 | JKS-175 | JJS-175 | - | - | - |

Table 3.38 525-690V, Frame Sizes A, B, and C

| FC 302 [kW] Power | Max. prefuse | Recommended max. fuse | | | | | | |
|-------------------------|-----------------|--------------------------------|-----------------------------|-----------------------------|-----------------------------|----------------------------------|---|--------------------------------------|
| | | Bussmann E52273 RK1/JDDZ | Bussmann E4273 J/JDDZ | Bussmann E4273 T/JDDZ | SIBA E180276 RK1/JDDZ | Littelfuse E81895 RK1/JDDZ | Ferraz- Shawmut E163267/E2137 RK1/JDDZ | Ferraz- Shawmut E2137 J/HSJ |
| 11 | 30 A | KTS-R-30 | JKS-30 | JKJS-30 | 5017906-030 | KLS-R-030 | A6K-30-R | HST-30 |
| 15-18.5 | 45 A | KTS-R-45 | JKS-45 | JJS-45 | 5014006-050 | KLS-R-045 | A6K-45-R | HST-45 |
| 22 | 60 A | KTS-R-60 | JKS-60 | JJS-60 | 5014006-063 | KLS-R-060 | A6K-60-R | HST-60 |
| 30 | 80 A | KTS-R-80 | JKS-80 | JJS-80 | 5014006-080 | KLS-R-075 | A6K-80-R | HST-80 |
| 37 | 90 A | KTS-R-90 | JKS-90 | JJS-90 | 5014006-100 | KLS-R-090 | A6K-90-R | HST-90 |
| 45 | 100 A | KTS-R-100 | JKS-100 | JJS-100 | 5014006-100 | KLS-R-100 | A6K-100-R | HST-100 |
| 55 | 125 A | KTS-R-125 | JKS-125 | JJS-125 | 2028220-125 | KLS-150 | A6K-125-R | HST-125 |
| 75 | 150 A | KTS-R-150 | JKS-150 | JJS-150 | 2028220-150 | KLS-175 | A6K-150-R | HST-150 |

* UL compliance only 525-600V

Table 3.39 525-690 V*, Frame Sizes B and C

Supplementary fuses

| Frame size | Bussmann PN* | Rating |
|------------|--------------|------------|
| D, E and F | KTK-4 | 4 A, 600 V |

Table 3.40 SMPS Fuse

| Size/Type | Bussmann PN* | Littelfuse | Rating |
|----------------------|--------------|------------|------------|
| P90K-P250, 380-500 V | KTK-4 | | 4 A, 600 V |
| P37K-P400, 525-690 V | KTK-4 | | 4 A, 600 V |
| P315-P800, 380-500 V | | KLK-15 | 15A, 600 V |
| P500-P1M2, 525-690 V | | KLK-15 | 15A, 600 V |

Table 3.41 Fan Fuses

| | Size/Type | Bussmann PN* | Rating | Alternative Fuses |
|-----------------|----------------------------------|------------------|------------|---|
| 2.5-4.0 A Fuse | P450-P800, 380-500 V | LPJ-6 SP or SPI | 6 A, 600V | Any listed Class J Dual Element, Time Delay, 6 A |
| | P630-P1M2, 525-690 V | LPJ-10 SP or SPI | 10 A, 600V | Any listed Class J Dual Element, Time Delay, 10 A |
| 4.0-6.3 A Fuse | P450-P800, 380-500 V | LPJ-10 SP or SPI | 10 A, 600V | Any listed Class J Dual Element, Time Delay, 10 A |
| | P630-P1M2, 525-690 V | LPJ-15 SP or SPI | 15 A, 600V | Any listed Class J Dual Element, Time Delay, 15 A |
| 6.3 - 10 A Fuse | P450-P800600HP-1200HP, 380-500 V | LPJ-15 SP or SPI | 15 A, 600V | Any listed Class J Dual Element, Time Delay, 15 A |
| | P630-P1M2, 525-690 V | LPJ-20 SP or SPI | 20 A, 600V | Any listed Class J Dual Element, Time Delay, 20A |
| 10 - 16 A Fuse | P450-P800, 380-500 V | LPJ-25 SP or SPI | 25 A, 600V | Any listed Class J Dual Element, Time Delay, 25 A |
| | P630-P1M2, 525-690 V | LPJ-20 SP or SPI | 20 A, 600V | Any listed Class J Dual Element, Time Delay, 20 A |

Table 3.42 Manual Motor Controller Fuses

| Frame size | Bussmann PN* | Rating | Alternative Fuses |
|------------|------------------|-------------|---|
| F | LPJ-30 SP or SPI | 30 A, 600 V | Any listed Class J Dual Element, Time Delay, 30 A |

Table 3.43 30 A Fuse Protected Terminal Fuse

| Frame size | Bussmann PN* | Rating | Alternative Fuses |
|------------|-----------------|------------|--|
| F | LPJ-6 SP or SPI | 6 A, 600 V | Any listed Class J Dual Element, Time Delay, 6 A |

Table 3.44 Control Transformer Fuse

| Frame size | Bussmann PN* | Rating |
|------------|--------------|---------------|
| F | GMC-800MA | 800 mA, 250 V |

Table 3.45 NAMUR Fuse

| Frame size | Bussmann PN* | Rating | Alternative Fuses |
|------------|--------------|------------|--------------------------|
| F | LP-CC-6 | 6 A, 600 V | Any listed Class CC, 6 A |

Table 3.46 Safety Relay Coil Fuse with PILZ Relay

3.5.14 Mains Disconnectors - Frame Size D, E and F

| Frame size | Power | Type |
|------------|-----------|-------------------------------|
| 380-500 V | | |
| D1/D3 | P90K-P110 | ABB OT200U12-91 |
| D2/D4 | P132-P200 | ABB OT400U12-91 |
| E1/E2 | P250 | ABB OT600U03 |
| E1/E2 | P315-P400 | ABB OT800U03 |
| F3 | P450 | Merlin Gerin NPJF36000S12AAYP |
| F3 | P500-P630 | Merlin Gerin NRKF36000S20AAYP |
| F4 | P710-P800 | Merlin Gerin NRKF36000S20AAYP |
| 525-690 V | | |
| D1/D3 | P90K-P132 | ABB OT200U12-91 |
| D2/D4 | P160-P315 | ABB OT400U12-91 |
| E1/E2 | P355-P560 | ABB OETL-NF600A |
| F3 | P630-P710 | Merlin Gerin NPJF36000S12AAYP |
| F3 | P800 | Merlin Gerin NRKF36000S20AAYP |
| F4 | P900-P1M2 | Merlin Gerin NRKF36000S20AAYP |

Table 3.47 Mains Disconnector Types

3.5.15 F-Frame Circuit Breakers

| Frame size | Power & voltage | Type | Default breaker settings | |
|------------|---|-------------------------------------|--------------------------|----------|
| | | | Trip level [A] | Time [s] |
| F3 | P450 380-500 V & P630-P710 525-690 V | Merlin Gerin NPJF36120U31AABSCYP | 1200 | 0.5 |
| F3 | P500-P630 380-500 V & P800 525-690 V | Merlin Gerin NRJF36200U31AABSCYP | 2000 | 0.5 |
| F4 | P710 380-500 V & P900-P1M2 525-690 V | Merlin Gerin NRJF36200U31AABSCYP | 2000 | 0.5 |
| F4 | P800 380-500 V | Merlin Gerin NRJF36250U31AABSCYP | 2500 | 0.5 |

Table 3.48 Circuit Breakers Types

3.5.16 F-Frame Mains Contactors

| Frame size | Power & voltage | Type |
|------------|---|-------------------|
| F3 | P450-P500 380-500 V & P630-P800 525-690 V | Eaton XTCE650N22A |
| F3 | P560 380-500 V | Eaton XTCE820N22A |
| F3 | P630 380-500 V | Eaton XTCEC14P22B |
| F4 | P900 525-690 V | Eaton XTCE820N22A |
| F4 | P710-P800 380-500 V & P1M2 525-690 V | Eaton XTCEC14P22B |

Table 3.49 Mains Contactor Types



Customer supplied 230 V supply required for Mains Contactors.

3.5.17 Motor Insulation

For motor cable lengths \leq the maximum cable length listed in , the recommended motor insulation ratings are in *Table 3.50*. The peak voltage can be up to twice the DC link voltage, 2.8 times the mains voltage, due to transmission line effects in the motor cable. If a motor has a lower insulation rating, use a dU/dt or sine wave filter.

| Nominal Mains Voltage | Motor Insulation |
|--|-------------------------------------|
| $U_N \leq 420\text{ V}$ | Standard $U_{LL} = 1300\text{ V}$ |
| $420\text{ V} < U_N \leq 500\text{ V}$ | Reinforced $U_{LL} = 1600\text{ V}$ |
| $500\text{ V} < U_N \leq 600\text{ V}$ | Reinforced $U_{LL} = 1800\text{ V}$ |
| $600\text{ V} < U_N \leq 690\text{ V}$ | Reinforced $U_{LL} = 2000\text{ V}$ |

Table 3.50 Motor Insulation at Various Nominal Mains Voltages

3.5.18 Motor Bearing Currents

All motors installed with FC 302 90 kW or higher power drives should have NDE (Non-Drive End) insulated bearings installed to eliminate circulating bearing currents. To minimize DE (Drive End) bearing and shaft currents proper grounding of the drive, motor, driven machine, and motor to the driven machine is required.

Standard Mitigation Strategies:

1. Use an insulated bearing
2. Apply rigorous installation procedures
 - 2a Ensure the motor and load motor are aligned
 - 2b Strictly follow the EMC Installation guideline
 - 2c Reinforce the PE so the high frequency impedance is lower in the PE than the input power leads
 - 2d Provide a good high frequency connection between the motor and the frequency converter for instance by screened cable which has a 360° connection in the motor and the frequency converter
 - 2e Make sure that the impedance from frequency converter to building ground is lower than the grounding impedance of the machine. This can be difficult for pumps
 - 2f Make a direct earth connection between the motor and load motor
3. Lower the IGBT switching frequency
4. Modify the inverter waveform, 60° AVM vs. SFAVM

5. Install a shaft grounding system or use an isolating coupling
6. Apply conductive lubrication
7. Use minimum speed settings if possible
8. Try to ensure the line voltage is balanced to ground. This can be difficult for IT, TT, TN-CS or Grounded leg systems
9. Use a dU/dt or sinus filter

3.5.19 Brake Resistor Temperature Switch

Torque: 0.5-0.6 Nm (5 in-lbs)

Screw size: M3

This input can be used to monitor the temperature of an externally connected brake resistor. If the input between 104 and 106 is established, the frequency converter trips on warning/alarm 27, *Brake IGBT*. If the connection is closed between 104 and 105, the frequency converter trips on warning/alarm 27, *Brake IGBT*.

Install a KLIXON switch that is normally closed. If this function is not used, short circuit 106 and 104 together. Normally closed: 104-106 (factory installed jumper) Normally open: 104-105

| Terminal No. | Function |
|---------------|------------------------------------|
| 106, 104, 105 | Brake resistor temperature switch. |

Table 3.51 Terminals for Brake Resistor Temperature Switch

NOTICE

If the temperature of the brake resistor gets too high and the thermal switch drops out, the frequency converter stops braking. The motor starts coasting.

3.5.20 Control Cable Routing

Tie down all control wires to the designated control cable routing as shown in the picture. Remember to connect the shields in a proper way to ensure optimum electrical immunity.

Fieldbus connection

Connections are made to the relevant options on the control card. For details, see the relevant fieldbus instruction. The cable must be placed in the provided path inside the frequency converter and tied down with other control wires (see illustrations).




Illustration 3.65 Control Card Wiring Path for the D3. Control Card Wiring for the D1, D2, D4, E1 and E2 use the same Path




Illustration 3.67 Top Connection for Fieldbus.




Illustration 3.68




Illustration 3.66 Control Card Wiring Path for the F1/F3. Control Card Wiring for the F2/F4 use the same Path




Illustration 3.69

In the Chassis (IP00) and NEMA 1 units, it is also possible to connect the fieldbus from the top of the unit as shown in the following pictures. On the NEMA 1 unit a cover plate must be removed.

Kit number for fieldbus top connection: 176F1742

3

Installation of 24 V external DC Supply

Torque: 0.5 - 0.6 Nm (5 in-lbs)

Screw size: M3

| No. | Function |
|----------------|-------------------------|
| 35 (-), 36 (+) | 24 V external DC supply |

Table 3.52 Terminals for 24 V External DC Supply

24 V DC external supply can be used as low-voltage supply to the control card and any option cards installed. This enables full operation of the LCP (including parameter setting) without connection to mains. Note that a warning of low voltage is given when 24 V DC has been connected; however, there is no tripping.

⚠ WARNING

Use 24 V DC supply of type PELV to ensure correct galvanic isolation (type PELV) on the control terminals of the frequency converter.

3.5.21 Access to Control Terminals

All terminals to the control cables are located beneath the LCP. They are accessed by opening the door of the IP21/IP54 version or removing the covers of the IP00 version.

3.5.22 Electrical Installation, Control Terminals

To connect the cable to the terminal

1. Strip insulation by about 9-10 mm




Illustration 3.70 Stripping of Insulation

2. Insert a screwdriver¹⁾ in the square hole.
3. Insert the cable in the adjacent circular hole.




Illustration 3.71

4. Remove the screwdriver. The cable is now mounted in the terminal.

To remove the cable from the terminal

1. Insert a screw driver¹⁾ in the square hole.
2. Pull out the cable.




Illustration 3.72

¹⁾ Max. 0.4 x 2.5 mm




Illustration 3.73

3.5.23 Electrical Installation, Control Cables




Illustration 3.74

A=Analog, D=Digital

*Terminal 37 (optional) is used for Safe Torque Off. For Safe Torque Off installation instructions, refer to the *Safe Torque Off Operating Instructions for Danfoss VLT® Frequency Converters*. Terminal 37 is not included in FC 301 (except enclosure type A1). Relay 2 and terminal 29 have no function in FC 301.

**Do not connect cable screen.

3




Illustration 3.75 Diagram Showing all Electrical Terminals with NAMUR Option shown in Dotted Line Box

Very long control cables and analog signals may in rare cases and depending on installation result in 50/60 Hz ground loops due to noise from mains supply cables.

If this occurs, it may be necessary to break the screen or insert a 100 nF capacitor between screen and chassis.

Connect the digital and analog inputs and outputs separately to the frequency converter common inputs (terminal 20, 55, 39) to avoid ground currents from both groups to affect other groups. For example, switching on the digital input may disturb the analog input signal.

Input polarity of control terminals




Illustration 3.76




Illustration 3.77

NOTICE

Control cables must be screened/armoured.




Illustration 3.78

Connect the wires as described in the product related *Operating Instructions*. Remember to connect the shields in a proper way to ensure optimum electrical immunity.

3.5.24 Switches S201, S202, and S801

Switches S201 (A53) and S202 (A54) are used to select a current (0-20 mA) or a voltage (-10 to +10 V) configuration of the analog input terminals 53 and 54.

Switch S801 (BUS TER.) can be used to enable termination on the RS-485 port (terminals 68 and 69).

See *Illustration 3.74*.

Default setting:

- S201 (A53) = OFF (voltage input)
- S202 (A54) = OFF (voltage input)
- S801 (Bus termination) = OFF

NOTICE

When changing the function of S201, S202 or S801 be careful not to use force for the switch over. It is recommended to remove the LCP fixture (cradle) when operating the switches. The switches must not be operated with power on the frequency converter.

3





Illustration 3.79



130BA156.12





Illustration 3.81

3.6 Connection Examples

3.6.1 Start/Stop

Terminal 18 = 5-10 Terminal 18 Digital Input [8] Start
 Terminal 27 = 5-12 Terminal 27 Digital Input [0] No operation (Default coast inverse)
 Terminal 37 = Safe Torque Off



130BA155.12




Illustration 3.80

3.6.2 Pulse Start/Stop

Terminal 18 = 5-10 Terminal 18 Digital Input [9] Latched start
 Terminal 27 = 5-12 Terminal 27 Digital Input [6] Stop inverse
 Terminal 37 = Safe Torque Off

3.6.3 Speed Up/Down

Terminals 29/32 = Speed up/down

Terminal 18 = 5-10 Terminal 18 Digital Input [9] Start (default)


Terminal 27 = 5-12 Terminal 27 Digital Input [19] Freeze reference

Terminal 29 = 5-13 Terminal 29 Digital Input [21] Speed up

Terminal 32 = 5-14 Terminal 32 Digital Input [22] Speed down

NOTICE

Terminal 29 only in FC x02 (x=series type).



130BA021.12

Illustration 3.82 Speed Up/Down

3.6.4 Potentiometer Reference

Voltage reference via a potentiometer

Reference Source 1 = [1] Analog input 53 (default)

Terminal 53, Low Voltage = 0 V

Terminal 53, High Voltage = 10 V

Terminal 53, Low Ref./Feedback = 0 RPM

Terminal 53, High Ref./Feedback = 1500 RPM

Switch S201 = OFF (U)




Illustration 3.83 Potentiometer Reference


3.7 Final Set-Up and Test

To test the set-up and ensure that the frequency converter is running, follow these steps.

Step 1. Locate the motor name plate

NOTICE

The motor is either star- (Y) or delta- connected (Δ). This information is located on the motor name plate data.



130BA767.10

3

| THREE PHASE INDUCTION MOTOR | | | | |
|-----------------------------|--------------|--------------|-----------|-----------------|
| MOD MCV 315E | Nr. | 135189 12 04 | IL/IN 6.5 | |
| kW 400 | PRIMARY | | | SF 1.15 |
| HP 536 | V 690 | A 410.6 | CONN Y | COS φ 0.85 40 |
| mm 1481 | V | A | CONN | AMB 40 °C |
| Hz 50 | V | A | CONN | ALT 1000 m |
| DESIGNN | SECONDARY | | | RISE 80 °C |
| DUTY S1 | V | A | CONN | ENCLOSURE IP23 |
| INSUL I | EFFICIENCY % | 95.8% | 100% | 95.8% |
| | | | 75% | WEIGHT 1.83 ton |

CAUTION

Illustration 3.84

Step 2. Enter the motor name plate data in this parameter list.

To access this list first press [Quick Menu] then select "Q2 Quick Setup".

| | |
|----|--|
| 1. | Parameter 1-20 Motor Power [kW] 1-21 Motor Power [HP] |
| 2. | 1-22 Motor Voltage |
| 3. | Parameter 1-23 Motor Frequency |
| 4. | 1-24 Motor Current |
| 5. | 1-25 Motor Nominal Speed |

Table 3.53

Step 3. Activate the Automatic Motor Adaptation (AMA)

Performing an AMA ensures optimum performance. The AMA measures the values from the motor model equivalent diagram.

1. Connect terminal 37 to terminal 12 (if terminal 37 is available).
2. Connect terminal 27 to terminal 12 or set 5-12 Terminal 27 Digital Input to [0] No function.
3. Activate the AMA 1-29 Automatic Motor Adaptation (AMA).
4. Select between complete or reduced AMA. If a Sine-wave filter is mounted, run only the reduced AMA, or remove the Sine-wave filter during the AMA procedure.

5. Press [OK]. The display shows *Press [Hand On] to start*.
6. Press [Hand On]. A progress bar indicates if the AMA is in progress.

Stop the AMA during operation

1. Press [Off] - the frequency converter enters into alarm mode and the display shows that the AMA was terminated by the user.

Successful AMA

1. The display shows *Press [OK] to finish AMA*.
2. Press [OK] to exit the AMA state.

Unsuccessful AMA

1. The frequency converter enters into alarm mode. A description of the alarm can be found in *chapter 6 Warnings and Alarms*.
2. "Report Value" in the [Alarm Log] shows the last measuring sequence carried out by the AMA, before the frequency converter entered alarm mode. This number along with the description of the alarm assists in troubleshooting. If contacting Danfoss for service, make sure to mention number and alarm description.

NOTICE

Unsuccessful AMA is often caused by incorrectly registered motor name plate data or a too big difference between the motor power size and the frequency converter power size.

Step 4. Set speed limit and ramp time

Parameter 3-02 Minimum Reference

Parameter 3-03 Maximum Reference

Set up the desired limits for speed and ramp time

4-11 Motor Speed Low Limit [RPM] or 4-12 Motor Speed Low Limit [Hz]

4-13 Motor Speed High Limit [RPM] or 4-14 Motor Speed High Limit [Hz]

Parameter 3-41 Ramp 1 Ramp Up Time

Parameter 3-42 Ramp 1 Ramp Down Time

3.8 Additional Connections

3.8.1 Mechanical Brake Control

In hoisting/lowering applications, it is necessary to be able to control an electro-mechanical brake:

- Control the brake using any relay output or digital output (terminal 27 or 29).
- Keep the output closed (voltage-free) as long as the frequency converter is unable to support the motor, for example due to the load being too heavy.

- Select *[32] Mechanical brake control* in parameter group *5-4* Relays* for applications with an electro-mechanical brake.
- The brake is released when the motor current exceeds the preset value in *2-20 Release Brake Current*.
- The brake is engaged when the output frequency is less than the frequency set in *2-21 Activate Brake Speed [RPM]* or *2-22 Activate Brake Speed [Hz]*, and only if the frequency converter carries out a stop command.

If the frequency converter is in alarm mode or in an over-voltage situation, the mechanical brake immediately cuts in.

3.8.2 Parallel Connection of Motors

The frequency converter can control several parallel-connected motors. The total current consumption of the motors must not exceed the rated output current $I_{M,N}$ for the frequency converter.

NOTICE

Installations with cables connected in a common joint as in *Illustration 3.85*, is only recommended for short cable lengths.

NOTICE

When motors are connected in parallel, *1-29 Automatic Motor Adaptation (AMA)* cannot be used.

NOTICE

The electronic thermal relay (ETR) of the frequency converter cannot be used as motor protection for the individual motor in systems with parallel-connected motors. Provide further motor protection by e.g. thermistors in each motor or individual thermal relays (circuit breakers are not suitable as protection).

3.8.3 Motor Thermal Protection

The electronic thermal relay in the frequency converter has received UL-approval for single motor protection, when *1-90 Motor Thermal Protection* is set for *ETR Trip* and *1-24 Motor Current* is set to the rated motor current (see motor name plate).

For thermal motor protection it is also possible to use the MCB 112 PTC Thermistor Card option. This card provides ATEX certificate to protect motors in explosion hazardous areas, Zone 1/21 and Zone 2/22. When *1-90 Motor Thermal Protection* is set to [20] *ATEX ETR* is combined with the use of MCB 112, it is possible to control an Ex-e motor in explosion hazardous areas. Consult the programming guide for details on how to set up the frequency converter for safe operation of Ex-e motors.




Illustration 3.85

Problems may arise at start and at low RPM values if motor sizes are widely different because small motors' relatively high ohmic resistance in the stator calls for a higher voltage at start and at low RPM values.

4 How to Programme

4.1 The Graphical and Numerical LCP

The easiest programming of the frequency converter is performed by the graphical LCP (LCP 102). Consult the frequency converter *Design Guide*, when using the Numeric Local Control Panel (LCP 101).

4

The control panel is divided into 4 functional groups:

1. Graphical display with Status lines.
2. Menu keys and indicator lights - changing parameters and switching between display functions.
3. Navigation keys and indicator lights (LEDs).
4. Operation keys and indicator lights (LEDs).

All data is displayed in a graphical LCP display, which can show up to 5 items of operating data while displaying [Status].

Display lines:

- a. **Status line:** Status messages displaying icons and graphic.
- b. **Line 1-2:** Operator data lines displaying data defined or selected by the user. By pressing [Status], up to one extra line can be added.
- c. **Status line:** Status messages displaying text.

NOTICE

If some operation is delaying the start-up, the LCP displays the INITIALISING message until it is ready. Adding or removing options may delay the start-up.




Illustration 4.1 Control Panel (LCP)

4.1.1 How to Programme on the Numerical Local Control Panel

The following instructions are valid for the numerical LCP (LCP 101):

The control panel is divided into 4 functional groups:

1. Numerical display.
2. Menu keys and indicator lights - changing parameters and switching between display functions.
3. Navigation keys and indicator lights (LEDs).
4. Operation keys and indicator lights (LEDs).




Illustration 4.2

4.1.2 Initial Commissioning

The easiest way of carrying out the initial commissioning is by pressing [Quick Menu] and following the quick set-up procedure using LCP 102 (read *Table 4.1* from left to right). The example applies to open loop applications.

| Press | | | | |
|---------------------------------------|--|---|--|--|
| | | Q2 Quick Menu | | |
| Parameter 0-01 Language | | Set language | | |
| Parameter 1-20 Motor Power [kW] | | Set Motor nameplate power | | |
| 1-22 Motor Voltage | | Set Nameplate voltage | | |
| Parameter 1-23 Motor Frequency | | Set Nameplate frequency | | |
| 1-24 Motor Current | | Set Nameplate current | | |
| 1-25 Motor Nominal Speed | | Set Nameplate speed in RPM | | |
| 5-12 Terminal 27 Digital Input | | If terminal default is <i>Coast inverse</i> it is possible to change this setting to <i>No function</i> . No connection to terminal 27 is then needed for running AMA | | |
| 1-29 Automatic Motor Adaptation (AMA) | | Set desired AMA function. Enable complete AMA is recommended | | |
| Parameter 3-02 Minimum Reference | | Set the minimum speed of the motor shaft | | |
| Parameter 3-03 Maximum Reference | | Set the maximum speed of the motor shaft | | |
| Parameter 3-41 Ramp 1 Ramp Up Time | | Set the ramping up time with reference to synchronous motor speed, n_s | | |
| Parameter 3-42 Ramp 1 Ramp Down Time | | Set the ramping down time with reference to synchronous motor speed, n_s | | |
| 3-13 Reference Site | | Set the site from where the reference must work | | |

Table 4.1 Quick Set-up Procedure

Another easy way of commissioning the frequency converter is by using the Smart Application Setup (SAS), which can also be found under the Quick Menu. Follow the indications on the successive screens for setting up the applications listed.

[Info] can be used throughout the SAS to see help information for various selections, settings, and messages. The following 3 applications are included:

- Mechanical Brake
- Conveyor
- Pump/Fan

The following 4 field-busses can be selected:

- Profibus
- Profinet
- DeviceNet
- EthernetIP

NOTICE

The start conditions are ignored while in the wizard.

NOTICE

The Smart Set-up runs automatically on the first power-up of the frequency converter or after a reset to factory settings. If no action is taken, the SAS screen automatically disappears after 10 min.

4.2 Quick Setup

| 0-01 Language | | |
|---------------|------------|---|
| Option: | Function: | |
| | | Defines the language to be used in the display. The frequency converter is delivered with 4 different language packages English and German are included in all packages. English cannot be erased or manipulated. |
| [0] * | English | Part of Language packages 1 - 4 |
| [1] | Deutsch | Part of Language packages 1 - 4 |
| [2] | Francais | Part of Language package 1 |
| [3] | Dansk | Part of Language package 1 |
| [4] | Spanish | Part of Language package 1 |
| [5] | Italiano | Part of Language package 1 |
| [6] | Svenska | Part of Language package 1 |
| [7] | Nederlands | Part of Language package 1 |
| [10] | Chinese | Part of Language package 2 |
| [20] | Suomi | Part of Language package 1 |

| 0-01 Language | | |
|---------------|------------------|----------------------------|
| Option: | Function: | |
| [22] | English US | Part of Language package 4 |
| [27] | Greek | Part of Language package 4 |
| [28] | Bras.port | Part of Language package 4 |
| [36] | Slovenian | Part of Language package 3 |
| [39] | Korean | Part of Language package 2 |
| [40] | Japanese | Part of Language package 2 |
| [41] | Turkish | Part of Language package 4 |
| [42] | Trad.Chinese | Part of Language package 2 |
| [43] | Bulgarian | Part of Language package 3 |
| [44] | Srpski | Part of Language package 3 |
| [45] | Romanian | Part of Language package 3 |
| [46] | Magyar | Part of Language package 3 |
| [47] | Czech | Part of Language package 3 |
| [48] | Polski | Part of Language package 4 |
| [49] | Russian | Part of Language package 3 |
| [50] | Thai | Part of Language package 2 |
| [51] | Bahasa Indonesia | Part of Language package 2 |
| [52] | Hrvatski | Part of Language package 3 |

| 1-20 Motor Power [kW] | | |
|------------------------------------|---|--|
| Range: | Function: | |
| Size related* [0.09 - 3000.00 kW] | <p>NOTICE</p> <p>This parameter cannot be adjusted while the motor is running.</p> <p>Enter the nominal motor power in kW according to the motor nameplate data. The default value corresponds to the nominal rated output of the unit. This parameter is visible in LCP if 0-03 Regional Settings is [0] International.</p> <p>NOTICE</p> <p>4 sizes down, 1 size up from nominal unit rating.</p> | |

| 1-22 Motor Voltage | | |
|------------------------------|---|--|
| Range: | Function: | |
| Size related* [10 - 1000 V] | Enter the nominal motor voltage according to the motor nameplate data. The default value corresponds to the nominal rated output of the unit. | |

| 1-23 Motor Frequency | | |
|----------------------|----------------|--|
| Range: | | Function: |
| Size related* | [20 - 1000 Hz] | Min - Max motor frequency: 20-1000 Hz. Select the motor frequency value from the motor nameplate data. If a value different from 50 Hz or 60 Hz is selected, adapt the load independent settings in <i>1-50 Motor Magnetisation at Zero Speed to 1-53 Model Shift Frequency</i> . For 87 Hz operation with 230/400 V motors, set the nameplate data for 230 V/50 Hz. To run at 87 Hz, adapt <i>4-13 Motor Speed High Limit [RPM]</i> and <i>parameter 3-03 Maximum Reference</i> . |

| 1-24 Motor Current | | |
|--------------------|----------------------|--|
| Range: | | Function: |
| Size related* | [0.10 - 10000.00 A] | Enter the nominal motor current value from the motor nameplate data. This data is used for calculating motor torque, motor thermal protection etc. |

| 1-25 Motor Nominal Speed | | |
|--------------------------|-------------------|---|
| Range: | | Function: |
| Size related* | [100 - 60000 RPM] | Enter the nominal motor speed value from the motor nameplate data. This data is used for calculating automatic motor compensations. |

| 5-12 Terminal 27 Digital Input | | |
|--------------------------------|---------------|--|
| Option: | Function: | |
| [2] * | Coast inverse | Functions are described under parameter group <i>5-1* Digital Inputs</i> |

| 1-29 Automatic Motor Adaptation (AMA) | | |
|---------------------------------------|---------------------|--|
| Option: | Function: | |
| | | The AMA function optimises dynamic motor performance by automatically optimising the advanced motor parameters (<i>1-30 Stator Resistance (Rs)</i> to <i>1-35 Main Reactance (Xh)</i>) at motor standstill. Activate the AMA function by pressing [Hand on] after selecting [1] <i>Enable complete AMA</i> or [2] <i>Enable reduced AMA</i> . See also <i>chapter 3.7.1 Final Set-Up and Test</i> . After a normal sequence, the display reads: "Press [OK] to finish AMA". After pressing [OK], the frequency converter is ready for operation. This parameter cannot be adjusted while the motor is running. |
| [0] | OFF | |
| [1] | Enable complete AMA | Performs AMA of the stator resistance R_s , the rotor resistance R_r , the stator leakage reactance |

| 1-29 Automatic Motor Adaptation (AMA) | | |
|---------------------------------------|--------------------|---|
| Option: | Function: | |
| | | X_1 , the rotor leakage reactance X_2 and the main reactance X_h . FC 301: The complete AMA does not include X_h measurement for FC 301. Instead, the X_h value is determined from the motor database. <i>1-35 Main Reactance (Xh)</i> may be adjusted to obtain optimal start performance. |
| [2] | Enable reduced AMA | Performs a reduced AMA of the stator resistance R_s in the system only. Select this option if an LC filter is used between the frequency converter and the motor. |

Note:

- For the best adaptation of the frequency converter, run AMA on a cold motor.
- AMA cannot be performed while the motor is running.
- AMA cannot be performed on permanent magnet motors.

NOTICE

It is important to set motor parameter group 1-2* correctly, since these form part of the AMA algorithm. An AMA must be performed to achieve optimum dynamic motor performance. It may take up to 10 min, depending on the power rating of the motor.

NOTICE

Avoid generating external torque during AMA.

NOTICE

If one of the settings in parameter group 1-2* *Motor Data* is changed, *1-30 Stator Resistance (Rs)* to *1-39 Motor Poles* return to default setting.

| 3-02 Minimum Reference | | |
|------------------------|---|--|
| Range: | | Function: |
| Size related* | [-999999.999 - par. 3-03 ReferenceFeedbackUnit] | Enter the minimum reference. The minimum reference is the lowest value obtainable by summing all references. Minimum reference is active only when <i>3-00 Reference Range</i> is set to [0] <i>Min.- Max</i> . The minimum reference unit matches: <ul style="list-style-type: none"> • The configuration of <i>1-00 Configuration Mode</i>: |

4.3 Parameter Menu Structure

| 3-02 Minimum Reference | | |
|------------------------|--|---|
| Range: | | Function: |
| | | <p>for [1] Speed closed loop, RPM; for [2] Torque, Nm.</p> <ul style="list-style-type: none"> The unit selected in 3-01 Reference/Feedback Unit. |

| 3-03 Maximum Reference | | |
|------------------------|--|--|
| Range: | | Function: |
| Size related* | [par. 3-02 - 999999,999 ReferenceFeed-backUnit] | <p>Enter the Maximum Reference. The Maximum Reference is the highest value obtainable by summing all references.</p> <p>The Maximum Reference unit matches:</p> <ul style="list-style-type: none"> The choice of configuration in 1-00 Configuration Mode: for [1] Speed closed loop, RPM; for [2] Torque, Nm. The unit selected in 3-00 Reference Range. |

| 3-41 Ramp 1 Ramp Up Time | | |
|--------------------------|------------------|---|
| Range: | | Function: |
| Size related* | [0.01 - 3600 s] | <p>Enter the ramp-up time, i.e. the acceleration time from 0 RPM to the synchronous motor speed n_s. Select a ramp-up time such that the output current does not exceed the current limit in 4-18 Current Limit during ramping. The value 0.00 corresponds to 0.01 s in speed mode. See ramp-down time in parameter 3-42 Ramp 1 Ramp Down Time.</p> $Par. 3-41 = \frac{t_{acc} [s] \times n_s [RPM]}{ref [RPM]}$ |

| 3-42 Ramp 1 Ramp Down Time | | |
|----------------------------|------------------|---|
| Range: | | Function: |
| Size related* | [0.01 - 3600 s] | <p>Enter the ramp-down time, that is, the deceleration time from the synchronous motor speed n_s to 0 RPM. Select a ramp-down time such that no overvoltage arises in the inverter due to regenerative operation of the motor, and such that the generated current does not exceed the current limit set in 4-18 Current Limit. The value 0.00 corresponds to 0.01 s in speed mode. See ramp-up time in parameter 3-41 Ramp 1 Ramp Up Time.</p> $Par. 3-42 = \frac{t_{dec} [s] \times n_s [RPM]}{ref [RPM]}$ |

| | | | | | | | | | |
|------|--|------|-------------------------------------|------|--------------------------------------|------|---|------|--------------------------------------|
| 0-0* | Operation / Display | 1-11 | Motor Model | 1-76 | Start Current | 3-03 | Maximum Reference | 4-1* | Motor Limits |
| 0-0* | Basic Settings | 1-14 | Damping Gain | 1-8* | Stop Adjustments | 3-04 | Reference Function | 4-10 | Motor Speed Direction |
| 0-01 | Language | 1-15 | Low Speed Filter Time Const. | 1-80 | Function at Stop | 3-1* | References | 4-11 | Motor Speed Low Limit [RPM] |
| 0-02 | Motor Speed Unit | 1-16 | High Speed Filter Time Const. | 1-81 | Min Speed for Function at Stop [RPM] | 3-10 | Preset Reference | 4-12 | Motor Speed Low Limit [Hz] |
| 0-03 | Regional Settings | 1-17 | Voltage filter time const. | 1-82 | Min Speed for Function at Stop [Hz] | 3-11 | Jog Speed [Hz] | 4-13 | Motor Speed High Limit [RPM] |
| 0-04 | Operating State at Power-up (Hand) | 1-2* | Motor Data | 1-83 | Precise Stop Function | 3-12 | Catch up/slow Down Value | 4-14 | Motor Speed High Limit [Hz] |
| 0-09 | Performance Monitor | 1-20 | Motor Power [kW] | 1-84 | Precise Stop Counter Value | 3-13 | Reference Site | 4-16 | Torque Limit Motor Mode |
| 0-1* | Set-up Operations | 1-21 | Motor Power [HP] | 1-85 | Precise Stop Speed Compensation | 3-14 | Preset Relative Reference | 4-17 | Torque Limit Generator Mode |
| 0-10 | Active Set-up | 1-22 | Motor Voltage | | Delay | 3-15 | Reference Resource 1 | 4-18 | Current Limit |
| 0-11 | Edit Set-up | 1-23 | Motor Frequency | 1-9* | Motor Temperature | 3-16 | Reference Resource 2 | 4-19 | Max Output Frequency |
| 0-12 | This Set-up Linked to | 1-24 | Motor Current | 1-90 | Motor Thermal Protection | 3-17 | Reference Resource 3 | 4-2* | Limit Factors |
| 0-13 | Readout: Linked Set-ups | 1-25 | Motor Nominal Speed | 1-91 | Motor External Fan | 3-18 | Relative Scaling Reference Resource | 4-20 | Torque Limit Factor Source |
| 0-14 | Readout: Edit Set-ups / Channel | 1-26 | Motor Cont. Rated Torque | 1-93 | Thermistor Resource | 3-19 | Jog Speed [RPM] | 4-21 | Speed Limit Factor Source |
| 0-15 | Readout: actual setup | 1-29 | Automatic Motor Adaptation (AMA) | 1-94 | ATEX ETR cur.lim. speed reduction | 3-4* | Ramp 1 | 4-3* | Motor Speed Mon. |
| 0-2* | LCP Display | 1-3* | Adv. Motor Data | 1-95 | KTY Sensor Type | 3-40 | Ramp 1 Type | 4-30 | Motor Feedback Loss Function |
| 0-20 | Display Line 1.1 Small | 1-30 | Stator Resistance (Rs) | 1-96 | KTY Thermistor Resource | 3-41 | Ramp 1 Ramp Up Time | 4-31 | Motor Feedback Speed Error |
| 0-21 | Display Line 1.2 Small | 1-31 | Rotor Resistance (Rr) | 1-97 | KTY Threshold level | 3-42 | Ramp 1 Ramp Down Time | 4-32 | Motor Feedback Loss Timeout |
| 0-22 | Display Line 1.3 Small | 1-33 | Stator Leakage Reactance (X1) | 1-98 | ATEX ETR interpol. points freq. | 3-45 | Ramp 1 S-ramp Ratio at Accel. Start | 4-34 | Tracking Error Function |
| 0-23 | Display Line 2 Large | 1-34 | Rotor Leakage Reactance (X2) | 1-99 | ATEX ETR interpol. points current | 3-46 | Ramp 1 S-ramp Ratio at Decel. Start | 4-35 | Tracking Error |
| 0-24 | Display Line 3 Large | 1-35 | Main Reactance (Xh) | 2-* | Brakes | 3-47 | Ramp 1 S-ramp Ratio at Decel. Start | 4-36 | Tracking Error Timeout |
| 0-25 | My Personal Menu | 1-36 | Iron Loss Resistance (Rfe) | 2-0* | DC-Brake | 3-48 | Ramp 1 S-ramp Ratio at Decel. End | 4-37 | Tracking Error Ramping |
| 0-3* | LCP Custom Readout | 1-37 | d-axis Inductance (Ld) | 2-00 | DC Hold Current | 3-5* | Ramp 2 | 4-38 | Tracking Error Ramping Timeout |
| 0-30 | Unit for User-defined Readout | 1-38 | q-axis Inductance (Lq) | 2-01 | DC Brake Current | 3-50 | Ramp 2 Type | 4-39 | Tracking Error After Ramping Timeout |
| 0-31 | Min Value of User-defined Readout | 1-39 | Motor Poles | 2-02 | DC Braking Time | 3-51 | Ramp 2 Ramp Up Time | 4-5* | Adj. Warnings |
| 0-32 | Max Value of User-defined Readout | 1-40 | Back EMF at 1000 RPM | 2-03 | DC Brake Cut In Speed [Hz] | 3-52 | Ramp 2 Ramp Down Time | 4-50 | Warning Current Low |
| 0-37 | Display Text 1 | 1-41 | Motor Angle Offset | 2-04 | DC Brake Cut In Speed [RPM] | 3-55 | Ramp 2 S-ramp Ratio at Accel. Start | 4-51 | Warning Current High |
| 0-38 | Display Text 2 | 1-44 | d-axis Inductance Sat. (LdSat) | 2-05 | Maximum Reference | 3-56 | Ramp 2 S-ramp Ratio at Accel. End | 4-52 | Warning Speed Low |
| 0-39 | Display Text 3 | 1-45 | q-axis Inductance Sat. (LqSat) | 2-06 | Maximum Reference | 3-57 | Ramp 2 S-ramp Ratio at Decel. Start | 4-53 | Warning Speed High |
| 0-4* | LCP keypad | 1-46 | Position Detection Gain | 2-07 | Parking Time | 3-58 | Ramp 2 S-ramp Ratio at Decel. End | 4-54 | Warning Reference Low |
| 0-40 | [Hand on] key on LCP | 1-47 | Low Speed Torque Calibration | 2-1* | Brake Energy Funct. | 3-6* | Ramp 3 | 4-55 | Warning Reference High |
| 0-41 | [Off] key on LCP | 1-48 | Inductance Sat. Point | 2-10 | Brake Function | 3-60 | Ramp 3 Type | 4-56 | Warning Feedback Low |
| 0-42 | [Auto on] key on LCP | 1-5* | Load Indep. Setting | 2-11 | Brake Resistor (ohm) | 3-61 | Ramp 3 Ramp up Time | 4-57 | Warning Feedback High |
| 0-43 | [Reset] key on LCP | 1-50 | Motor Magnetisation at Zero Speed | 2-12 | Brake Power Limit (kW) | 3-62 | Ramp 3 Ramp down Time | 4-58 | Missing Motor Phase Function |
| 0-44 | [Off/Reset] key on LCP | 1-51 | Min Speed Normal Magnetising [RPM] | 2-13 | Brake Power Monitoring | 3-65 | Ramp 3 S-ramp Ratio at Accel. Start | 4-6* | Speed Bypass |
| 0-45 | [Drive Bypass] key on LCP | 1-52 | Min Speed Normal Magnetising [Hz] | 2-15 | Brake Check | 3-66 | Ramp 3 S-ramp Ratio at Accel. End | 4-60 | Bypass Speed From [RPM] |
| 0-45 | [Copy/Save] key on LCP | 1-53 | Model Shift Frequency | 2-16 | AC brake Max. Current | 3-67 | Ramp 3 S-ramp Ratio at Decel. Start | 4-61 | Bypass Speed To [RPM] |
| 0-50 | LCP Copy | 1-54 | Voltage reduction in fieldweakening | 2-17 | Over-voltage Control | 3-68 | Ramp 3 S-ramp Ratio at Decel. End | 4-62 | Bypass Speed To [Hz] |
| 0-51 | Set-up Copy | 1-55 | U/f Characteristic - U | 2-18 | Brake Check Condition | 3-7* | Ramp 4 | 4-63 | Bypass Speed To [Hz] |
| 0-6* | Password | 1-56 | U/f Characteristic - F | 2-19 | Over-voltage Gain | 3-70 | Ramp 4 Type | 5-* | Digital In/Out |
| 0-60 | Main Menu Password | 1-58 | Flystart Test Pulses Current | 2-2* | Mechanical Brake | 3-71 | Ramp 4 Ramp up Time | 5-0* | Digital I/O mode |
| 0-61 | Access to Main Menu w/o Password | 1-59 | Flystart Test Pulses Frequency | 2-20 | Release Brake Current | 3-72 | Ramp 4 Ramp Down Time | 5-00 | Digital I/O Mode |
| 0-65 | Quick Menu Password | 1-6* | Load Depen. Setting | 2-21 | Activate Brake Speed [RPM] | 3-75 | Ramp 4 S-ramp Ratio at Accel. Start | 5-01 | Terminal 27 Mode |
| 0-66 | Access to Quick Menu w/o Password | 1-60 | Low Speed Load Compensation | 2-22 | Activate Brake Speed [Hz] | 3-76 | Ramp 4 S-ramp Ratio at Accel. End | 5-02 | Terminal 29 Mode |
| 0-67 | Bus Password Access | 1-61 | High Speed Load Compensation | 2-23 | Activate Brake Delay | 3-77 | Ramp 4 S-ramp Ratio at Decel. Start | 5-1* | Digital Inputs |
| 0-68 | Safety Parameters Password | 1-62 | Slip Compensation | 2-24 | Stop Delay | 3-78 | Ramp 4 S-ramp Ratio at Decel. End | 5-10 | Terminal 18 Digital Input |
| 0-69 | Password Protection of Safety Parameters | 1-63 | Slip Compensation Time Constant | 2-25 | Brake Release Time | 3-8* | Other Ramps | 5-11 | Terminal 19 Digital Input |
| 1-* | Load and Motor | 1-64 | Resonance Dampening Time Constant | 2-26 | Torque Ref | 3-80 | Jog Ramp Time | 5-12 | Terminal 27 Digital Input |
| 1-0* | General Settings | 1-65 | Resonance Dampening Time Constant | 2-27 | Torque Ramp Time | 3-81 | Quick Stop Ramp Type | 5-13 | Terminal 29 Digital Input |
| 1-00 | Configuration Mode | 1-66 | Min. Current at Low Speed | 2-28 | Gain Boost Factor | 3-82 | Quick Stop Ramp Type | 5-14 | Terminal 32 Digital Input |
| 1-01 | Motor Control Principle | 1-67 | Load Type | 2-29 | Torque Ramp Down Time | 3-83 | Quick Stop S-ramp Ratio at Decel. Start | 5-15 | Terminal 33 Digital Input |
| 1-02 | Flux Motor Feedback Source | 1-68 | Minimum Inertia | 2-30 | Position P Start Proportional Gain | 3-84 | Quick Stop S-ramp Ratio at Decel. End | 5-16 | Terminal X30/2 Digital Input |
| 1-03 | Torque Characteristics | 1-69 | Maximum Inertia | 2-31 | Speed PID Start Proportional Gain | 3-9* | Digital Pot.Meter | 5-17 | Terminal X30/3 Digital Input |
| 1-04 | Overload Mode | 1-7* | Start Adjustments | 2-32 | Speed PID Start Integral Time | 3-90 | Step Size | 5-18 | Terminal X30/4 Digital Input |
| 1-05 | Local Mode Configuration | 1-70 | PM Start Mode | 2-33 | Speed PID Start Lowpass Filter Time | 3-91 | Ramp Time | 5-19 | Terminal 37 Safe Stop |
| 1-06 | Clockwise Direction | 1-71 | Start Delay | 3-* | Reference / Ramps | 3-92 | Power Restore | 5-20 | Terminal X46/1 Digital Input |
| 1-07 | Motor Angle Offset Adjust | 1-72 | Start Function | 3-0* | Reference Limits | 3-93 | Maximum Limit | 5-21 | Terminal X46/3 Digital Input |
| 1-1* | Special Settings | 1-73 | Flying Start | 3-00 | Reference Range | 3-94 | Minimum Limit | 5-22 | Terminal X46/5 Digital Input |
| 1-10 | Motor Construction | 1-74 | Start Speed [RPM] | 3-01 | Reference/Feedback Unit | 3-95 | Ramp Delay | 5-23 | Terminal X46/7 Digital Input |
| | | 1-75 | Start Speed [Hz] | 3-02 | Minimum Reference | 4-* | Limits / Warnings | 5-24 | Terminal X46/9 Digital Input |

| | | | | | | | | | |
|------|--------------------------------------|------|--------------------------------------|------|---|-------|--------------------------------|-------|---------------------------------|
| 5-25 | Terminal X46/11 Digital Input | 6-24 | Terminal 54 Low Ref./Feedb. Value | 7-31 | Process PID Anti Windup | 8-52 | DC Brake Select | 10-11 | Process Data Config Write |
| 5-26 | Terminal X46/13 Digital Input | 6-25 | Terminal 54 High Ref./Feedb. Value | 7-32 | Process PID Start Speed | 8-53 | Start Select | 10-12 | Process Data Config Read |
| 5-3* | Digital Outputs | 6-26 | Terminal 54 Filter Time Constant | 7-33 | Process PID Proportional Gain | 8-54 | Reversing Select | 10-13 | Warning Parameter |
| 5-30 | Terminal 27 Digital Output | 6-3* | Analog Input 3 | 7-34 | Process PID Integral Time | 8-55 | Set-up Select | 10-14 | Net Reference |
| 5-31 | Terminal 29 Digital Output | 6-30 | Terminal X30/11 Low Voltage | 7-35 | Process PID Differentiation Time | 8-56 | Preset Reference Select | 10-15 | Net Control |
| 5-32 | Term X30/6 Digi Out (MCB 101) | 6-31 | Terminal X30/11 High Voltage | 7-36 | Process PID Diff. Gain Limit | 8-57 | Profidrive OFF2 Select | 10-2* | COS Filters |
| 5-33 | Term X30/7 Digi Out (MCB 101) | 6-34 | Term. X30/11 Low Ref./Feedb. Value | 7-38 | Process PID Feed Forward Factor | 8-58 | Profidrive OFF3 Select | 10-20 | COS Filter 1 |
| 5-4* | Relays | 6-35 | Term. X30/11 High Ref./Feedb. Value | 7-39 | On Reference Bandwidth | 8-8* | FC Port Diagnostics | 10-21 | COS Filter 2 |
| 5-40 | Function Relay | 6-36 | Term. X30/11 Filter Time Constant | 7-4* | Adv. Process PID I | 8-80 | Bus Message Count | 10-22 | COS Filter 3 |
| 5-41 | On Delay, Relay | 6-4* | Analog Input 4 | 7-40 | Process PID I-part Reset | 8-81 | Bus Error Count | 10-23 | COS Filter 4 |
| 5-42 | Off Delay, Relay | 6-40 | Terminal X30/12 Low Voltage | 7-41 | Process PID Output Neg. Clamp | 8-82 | Slave Messages Rcvd | 10-3* | Parameter Access |
| 5-5* | Pulse Input | 6-41 | Terminal X30/12 High Voltage | 7-42 | Process PID Output Pos. Clamp | 8-83 | Slave Error Count | 10-30 | Array Index |
| 5-50 | Term. 29 Low Frequency | 6-44 | Term. X30/12 Low Ref./Feedb. Value | 7-43 | Process PID Gain Scale at Min. Ref. | 8-9* | Bus Jog | 10-31 | Store Data Values |
| 5-51 | Term. 29 High Frequency | 6-45 | Term. X30/12 High Ref./Feedb. Value | 7-44 | Process PID Gain Scale at Max. Ref. | 8-90 | Bus Jog 1 Speed | 10-32 | DeviceNet Revision |
| 5-52 | Term. 29 Low Ref./Feedb. Value | 6-46 | Term. X30/12 Filter Time Constant | 7-45 | Process PID Feed Fwd Resource | 8-91 | Bus Jog 2 Speed | 10-33 | Store Always |
| 5-53 | Term. 29 High Ref./Feedb. Value | 6-5* | Analog Output 1 | 7-46 | Process PID Feed Fwd Normal/ Inv. Ctrl. | 9-0* | PROFIDRIVE | 10-34 | DeviceNet Product Code |
| 5-54 | Pulse Filter Time Constant #29 | 6-50 | Terminal 42 Output | 7-48 | PCD Feed Forward | 9-00 | Setpoint | 10-39 | DeviceNet F Parameters |
| 5-55 | Term. 33 Low Frequency | 6-51 | Terminal 42 Output Min Scale | 7-49 | Process PID Output Normal/ Inv. Ctrl. | 9-07 | Actual Value | 10-5* | CANopen |
| 5-56 | Term. 33 High Frequency | 6-52 | Terminal 42 Output Max Scale | 7-5* | Adv. Process PID II | 9-15 | PCD Write Configuration | 10-50 | Process Data Config Write. |
| 5-57 | Term. 33 Low Ref./Feedb. Value | 6-53 | Term 42 Output Bus Ctrl | 7-50 | Process PID Extended PID | 9-16 | PCD Read Configuration | 10-51 | Process Data Config Read. |
| 5-58 | Term. 33 High Ref./Feedb. Value | 6-54 | Terminal 42 Output Timeout Preset | 7-51 | Process PID Feed Fwd Gain | 9-18 | Node Address | 12-2* | Ethernet |
| 5-59 | Pulse Filter Time Constant #33 | 6-55 | Analog Output Filter | 7-52 | Process PID Feed Fwd Ramp up | 9-22 | Telegram Selection | 12-0* | IP Settings |
| 5-6* | Pulse Output | 6-6* | Analog Output 2 | 7-53 | Process PID Feed Fwd Ramp down | 9-23 | Parameters for Signals | 12-00 | IP Address Assignment |
| 5-60 | Terminal 27 Pulse Output Variable | 6-60 | Terminal X30/8 Output | 7-55 | Process PID Feed Fwd Ramp down | 9-27 | Parameter Edit | 12-01 | IP Address |
| 5-62 | Pulse Output Max Freq #27 | 6-61 | Terminal X30/8 Min. Scale | 7-56 | Process PID Ref. Filter Time | 9-28 | Process Control | 12-02 | Subnet Mask |
| 5-63 | Terminal 29 Pulse Output Variable | 6-62 | Terminal X30/8 Max. Scale | 7-57 | Process PID Fb. Filter Time | 9-44 | Fault Message Counter | 12-03 | Default Gateway |
| 5-65 | Pulse Output Max Freq #29 | 6-63 | Terminal X30/8 Bus Control | 8-3* | Comm. and Options | 9-45 | Fault Code | 12-04 | DHCP Server |
| 5-66 | Terminal X30/6 Pulse Output Variable | 6-64 | Terminal X30/8 Output Timeout Preset | 8-0* | General Settings | 9-47 | Fault Number | 12-05 | Lease Expires |
| 5-68 | Pulse Output Max Freq #X30/6 | 6-7* | Analog Output 3 | 8-01 | Control Site | 9-52 | Fault Situation Counter | 12-06 | Name Servers |
| 5-7* | 24V Encoder Input | 6-70 | Terminal X45/1 Output | 8-02 | Control Word Source | 9-53 | Profibus Warning Word | 12-07 | Domain Name |
| 5-70 | Term 32/33 Pulses Per Revolution | 6-71 | Terminal X45/1 Min. Scale | 8-03 | Control Word Timeout Time | 9-63 | Actual Baud Rate | 12-08 | Host Name |
| 5-71 | Term 32/33 Encoder Direction | 6-72 | Terminal X45/1 Max. Scale | 8-04 | Control Word Timeout Function | 9-64 | Device Identification | 12-09 | Physical Address |
| 5-8* | I/O Options | 6-73 | Terminal X45/1 Bus Control | 8-05 | End-of-timeout Function | 9-65 | Profile Number | 12-1* | Ethernet Link Parameters |
| 5-80 | AHF Cap Reconnect Delay | 6-74 | Terminal X45/1 Output Timeout Preset | 8-06 | Reset Control Word Timeout | 9-67 | Control Word 1 | 12-10 | Link Status |
| 5-9* | Bus Controlled | 6-7* | Analog Output 4 | 8-07 | Diagnosis Trigger | 9-68 | Status Word 1 | 12-11 | Link Duration |
| 5-90 | Digital & Relay Bus Control | 6-80 | Terminal X45/3 Output | 8-08 | Readout Filtering | 9-71 | Profibus Save Data Values | 12-12 | Auto Negotiation |
| 5-93 | Pulse Out #27 Bus Control | 6-81 | Terminal X45/3 Min. Scale | 8-1* | Ctrl. Word Settings | 9-72 | ProfibusDriveReset | 12-13 | Link Speed |
| 5-94 | Pulse Out #27 Timeout Preset | 6-82 | Terminal X45/3 Max. Scale | 8-10 | Control Word Profile | 9-75 | DO Identification | 12-14 | Link Duplex |
| 5-95 | Pulse Out #29 Bus Control | 6-83 | Terminal X45/3 Bus Control | 8-13 | Configurable Status Word STW | 9-80 | Defined Parameters (1) | 12-2* | Process Data |
| 5-96 | Pulse Out #29 Timeout Preset | 6-84 | Terminal X45/3 Output Timeout Preset | 8-14 | Configurable Control Word CTW | 9-81 | Defined Parameters (2) | 12-20 | Control Instance |
| 5-97 | Pulse Out #X30/6 Bus Control | 7-7* | Controllers | 8-17 | Configurable Alarm and Warning Word | 9-82 | Defined Parameters (3) | 12-21 | Process Data Config Write |
| 5-98 | Pulse Out #X30/6 Timeout Preset | 7-0* | Speed PID Ctrl. | 8-19 | Product Code | 9-83 | Defined Parameters (4) | 12-22 | Process Data Config Read |
| 6-0* | Analog I/O Mode | 7-00 | Speed PID Feedback Source | 8-3* | FC Port Settings | 9-84 | Defined Parameters (5) | 12-23 | Process Data Config Write Size |
| 6-00 | Live Zero Timeout Time | 7-02 | Speed PID Proportional Gain | 8-30 | Protocol | 9-90 | Changed Parameters (1) | 12-24 | Process Data Config Read Size |
| 6-01 | Live Zero Timeout Function | 7-03 | Speed PID Integral Time | 8-31 | Address | 9-91 | Changed Parameters (2) | 12-27 | Master Address |
| 6-1* | Analog Input 1 | 7-04 | Speed PID Differentiation Time | 8-32 | FC Port Baud Rate | 9-92 | Changed Parameters (3) | 12-28 | Store Data Values |
| 6-10 | Terminal 53 Low Voltage | 7-05 | Speed PID Diff. Gain Limit | 8-33 | Parity / Stop Bits | 9-93 | Changed Parameters (4) | 12-29 | Store Always |
| 6-11 | Terminal 53 High Voltage | 7-06 | Speed PID Lowpass Filter Time | 8-34 | Estimated cycle time | 9-94 | Changed Parameters (5) | 12-3* | EtherNet/IP |
| 6-12 | Terminal 53 Low Current | 7-07 | Speed PID Feedback Gear Ratio | 8-35 | Minimum Response Delay | 9-99 | Profibus Revision Counter | 12-30 | Warning Parameter |
| 6-13 | Terminal 53 High Current | 7-08 | Speed PID Feed Forward Factor | 8-36 | Max Response Delay | 10-0* | CAN Fields | 12-31 | Net Reference |
| 6-14 | Terminal 53 Low Ref./Feedb. Value | 7-1* | Torque PI Ctrl. | 8-37 | Max Inter-Char Delay | 10-00 | Common Settings | 12-32 | Net Control |
| 6-15 | Terminal 53 High Ref./Feedb. Value | 7-12 | Torque PI Proportional Gain | 8-40 | Telegram Selection | 10-01 | CAN Protocol | 12-33 | CIP Revision |
| 6-16 | Terminal 53 Filter Time Constant | 7-13 | Torque PI Integration Time | 8-41 | Parameters for Signals | 10-02 | MAC ID | 12-34 | CIP Product Code |
| 6-2* | Analog Input 2 | 7-2* | Process Ctrl. Feedb | 8-42 | PCD Write Configuration | 10-05 | Readout Transmit Error Counter | 12-35 | EDS Parameter |
| 6-20 | Terminal 54 Low Voltage | 7-20 | Process CL Feedback 1 Resource | 8-43 | PCD Read Configuration | 10-06 | Readout Receive Error Counter | 12-37 | COS Inhibit Timer |
| 6-21 | Terminal 54 High Voltage | 7-22 | Process CL Feedback 2 Resource | 8-5* | Digital/Bus | 10-07 | Readout Bus Off Counter | 12-38 | COS Filter |
| 6-22 | Terminal 54 Low Current | 7-3* | Process PID Ctrl. | 8-50 | Coasting Select | 10-1* | DeviceNet | 12-40 | Status Parameter |
| 6-23 | Terminal 54 High Current | 7-30 | Process PID Normal/ Inverse Control | 8-51 | Quick Stop Select | 10-10 | Process Data Type Selection | 12-41 | Slave Message Count |

| | | | | | | | |
|-------|-----------------------------------|-------|-----------------------------------|-------|-------------------------------|-------|-------------------------------------|
| 12-42 | Slave Exception Message Count | 15-14 | Samples Before Trigger | 16-13 | Frequency | 16-82 | Fieldbus REF 1 |
| 12-5* | EtherCAT | 15-2* | Historic Log | 16-14 | Motor current | 16-84 | Comm. Option STW |
| 12-50 | Configured Station Alias | 15-20 | Historic Log: Event | 16-15 | Frequency [%] | 16-85 | FC Port CTW 1 |
| 12-51 | Configured Station Address | 15-21 | Historic Log: Value | 16-16 | Torque [Nm] | 16-86 | FC Port REF 1 |
| 12-59 | EtherCAT Status | 15-22 | Historic Log: Time | 16-17 | Speed [RPM] | 16-87 | Bus Readout Alarm/Warning |
| 12-6* | Ethernet PowerLink | 15-3* | Fault Log | 16-18 | Motor Thermal | 16-89 | Configurable Alarm/Warning Word |
| 12-60 | Node ID | 15-30 | Fault Log: Error Code | 16-19 | KTY sensor temperature | 16-9* | Diagnosis Readouts |
| 12-62 | SDO Timeout | 15-31 | Fault Log: Value | 16-20 | Motor Alarm Word | 16-90 | Alarm Word 2 |
| 12-63 | Basic Ethernet Timeout | 15-32 | Fault Log: Time | 16-21 | Torque [%] High Res. | 16-91 | Warning Word 2 |
| 12-66 | Threshold | 15-4* | Drive Identification | 16-22 | Torque [%] | 16-92 | Warning Word 2 |
| 12-67 | Threshold Counters | 15-40 | FC Type | 16-23 | Motor Shaft Power [kW] | 16-93 | Warning Word 2 |
| 12-68 | Cumulative Counters | 15-41 | Power Section | 16-24 | Calibrated Stator Resistance | 16-94 | Ext. Status Word |
| 12-69 | Ethernet PowerLink Status | 15-42 | Voltage | 16-25 | Torque [Nm] High | 17-1* | Feedback Option |
| 12-8* | Other Ethernet Services | 15-43 | Software Version | 16-3* | Drive Status | 17-1* | Inc. Enc. Interface |
| 12-80 | FTP Server | 15-44 | Ordered Typecode String | 16-30 | DC Link Voltage | 17-10 | Signal Type |
| 12-81 | HTTP Server | 15-45 | Actual Typecode String | 16-32 | Brake Energy /s | 17-11 | Resolution (PPR) |
| 12-82 | SMTP Service | 15-46 | Frequency Converter Ordering No | 16-33 | Brake Energy /2 min | 17-2* | Abs. Enc. Interface |
| 12-89 | Transparent Socket Channel Port | 15-47 | Power Card Ordering No | 16-34 | Heatsink Temp. | 17-20 | Protocol Selection |
| 12-9* | Advanced Ethernet Services | 15-48 | LCP Id No | 16-35 | Inverter Thermal | 17-21 | Resolution (Positions/Rev) |
| 12-90 | Cable Diagnostic | 15-49 | SW ID Control Card | 16-36 | Inv. Nom. Current | 17-24 | SSI Data Length |
| 12-91 | Auto Cross Over | 15-50 | SW ID Power Card | 16-37 | Inv. Max. Current | 17-25 | Clock Rate |
| 12-92 | IGMP Snooping | 15-51 | Frequency Converter Serial Number | 16-38 | SL Controller State | 17-26 | SSI Data Format |
| 12-93 | Cable Error Length | 15-53 | Power Card Serial Number | 16-39 | Control Card Temp. | 17-34 | HIPERFACE Baudrate |
| 12-94 | Broadcast Storm Protection | 15-58 | Smart Setup Filename | 16-40 | Logging Buffer Full | 17-5* | Resolver Interface |
| 12-95 | Broadcast Storm Filter | 15-59 | CSIV Filename | 16-41 | LCP Bottom Statusline | 17-50 | Poles |
| 12-96 | Port Config | 15-6* | Option Ident | 16-45 | Motor Phase U Current | 17-51 | Input Voltage |
| 12-98 | Interface Counters | 15-60 | Option Mounted | 16-46 | Motor Phase V Current | 17-52 | Input Frequency |
| 12-99 | Media Counters | 15-61 | Option SW Version | 16-47 | Motor Phase W Current | 17-53 | Transformation Ratio |
| 13-0* | Smart Logic | 15-62 | Option Ordering No | 16-48 | Speed Ref. After Ramp [RPM] | 17-56 | Encoder Sim. Resolution |
| 13-0* | SLC Settings | 15-63 | Option Serial No | 16-49 | Current Fault Source | 17-59 | Resolver Interface |
| 13-00 | SL Controller Mode | 15-70 | Option in Slot A | 16-5* | Ref. & Feedb. | 17-6* | Monitoring and App. |
| 13-01 | Start Event | 15-71 | Slot A Option SW Version | 16-50 | External Reference | 17-60 | Feedback Direction |
| 13-02 | Stop Event | 15-72 | Option in Slot B | 16-51 | Pulse Reference | 17-61 | Feedback Signal Monitoring |
| 13-03 | Reset SLC | 15-73 | Slot B Option SW Version | 16-52 | Feedback[Unit] | 18-* | Data Readouts 2 |
| 13-1* | Comparators | 15-74 | Option in Slot C0/E0 | 16-53 | Digi Pot Reference | 18-3* | Analog Readouts |
| 13-10 | Comparator Operand | 15-75 | Slot C0/E0 Option SW Version | 16-57 | Feedback [RPM] | 18-36 | Analog Input X48/2 [mA] |
| 13-11 | Comparator Operator | 15-76 | Option in Slot C1/E1 | 16-6* | Inputs & Outputs | 18-37 | Temp. Input X48/4 |
| 13-12 | Comparator Value | 15-77 | Slot C1/E1 Option SW Version | 16-60 | Digital Input | 18-38 | Temp. Input X48/7 |
| 13-1* | RS Flip Flops | 15-8* | Operating Data II | 16-61 | Terminal 53 Switch Setting | 18-39 | Temp. Input X48/10 |
| 13-15 | RS-FF Operand S | 15-80 | Fan Running Hours | 16-62 | Analog Input 53 | 18-6* | Inputs & Outputs 2 |
| 13-16 | RS-FF Operand R | 15-81 | Preset Fan Running Hours | 16-63 | Terminal 54 Switch Setting | 18-60 | Digital Input 2 |
| 13-2* | Timers | 15-89 | Configuration Change Counter | 16-64 | Analog Input 54 | 18-9* | PID Readouts |
| 13-20 | SL Controller Timer | 15-92 | Defined Parameters | 16-65 | Analog Output 42 [mA] | 18-90 | Process PID Error |
| 13-4* | Logic Rules | 15-93 | Modified Parameters | 16-66 | Digital Output [bin] | 18-91 | Process PID Output |
| 13-40 | Logic Rule Boolean 1 | 15-98 | Drive Identification | 16-67 | Freq. Input #29 [Hz] | 18-92 | Process PID Clamped Output |
| 13-41 | Logic Rule Operator 1 | 15-99 | Parameter Metadata | 16-68 | Freq. Input #33 [Hz] | 18-93 | Process PID Gain Scaled Output |
| 13-42 | Logic Rule Boolean 2 | 16-* | Data Readouts | 16-69 | Pulse Output #27 [Hz] | 30-* | Special Features |
| 13-43 | Logic Rule Operator 2 | 16-0* | General Status | 16-70 | Pulse Output #29 [Hz] | 30-0* | Wobbler |
| 13-44 | Logic Rule Boolean 3 | 16-00 | Control Word | 16-71 | Relay Output [bin] | 30-00 | Wobble Mode |
| 13-5* | States | 16-01 | Reference [Unit] | 16-72 | Counter A | 30-01 | Wobble Delta Frequency [Hz] |
| 13-51 | SL Controller Event | 16-02 | Reference % | 16-73 | Counter B | 30-02 | Wobble Delta Frequency [%] |
| 13-52 | SL Controller Action | 16-03 | Status Word | 16-74 | Prec. Stop Counter | 30-03 | Wobble Delta Freq. Scaling Resource |
| 14-0* | Special Functions | 16-05 | Main Actual Value [%] | 16-75 | Analog in X30/11 | 30-04 | Wobble Jump Frequency [Hz] |
| 14-0* | Inverter Switching | 16-09 | Custom Readout | 16-76 | Analog in X30/12 | 30-05 | Wobble Jump Frequency [%] |
| 14-00 | Switching Pattern | 16-1* | Motor Status | 16-77 | Analog Out X30/8 [mA] | 30-06 | Wobble Jump Time |
| 14-01 | Switching Frequency | 16-10 | Logging Source | 16-78 | Analog Out X45/1 [mA] | 30-07 | Wobble Sequence Time |
| 14-03 | Overmodulation | 16-11 | Power [kW] | 16-79 | Analog Out X45/3 [mA] | 30-08 | Wobble Up/ Down Time |
| 14-04 | PWM Random | 16-12 | Motor Voltage | 16-8* | Fieldbus & FC Port | 30-09 | Wobble Random Function |
| 14-06 | Dead Time Compensation | | | 16-80 | Fieldbus CTW 1 | 30-10 | Wobble Ratio |

| | | | | | | | |
|-------|--|-------|------------------------------------|-------|-----------------------------------|-------|------------------------------------|
| 30-11 | Wobble Random Ratio Max. | 33-31 | Synchronisation Type | 34-08 | PCD 8 Write to MCO | 35-37 | Term. X48/10 High Temp. Limit |
| 30-12 | Wobble Random Ratio Min. | 33-32 | Feed Forward Velocity Adaptation | 34-09 | PCD 9 Write to MCO | 35-44 | 35-4* Analog Input X48/2 |
| 30-19 | Wobble Delta Freq. Scaled | 33-33 | Velocity Filter Window | 34-10 | PCD 10 Write to MCO | 35-42 | Term. X48/2 Low Current |
| 30-2* | Adv. Start Adjust | 33-34 | Slave Marker filter time | 34-2* | PCD Read Par. | 35-43 | Term. X48/2 High Current |
| 30-20 | High Starting Torque Time [s] | 33-4* | Limit Handling | 34-21 | PCD 1 Read from MCO | 35-44 | Term. X48/2 Low Ref./Feedb. Value |
| 30-21 | High Starting Torque Current [%] | 33-40 | Behaviour at End Limit Switch | 34-22 | PCD 2 Read from MCO | 35-45 | Term. X48/2 High Ref./Feedb. Value |
| 30-22 | Locked Rotor Protection | 33-41 | Negative Software End Limit | 34-23 | PCD 3 Read from MCO | 35-46 | Term. X48/2 Filter Time Constant |
| 30-23 | Locked Rotor Detection Time [s] | 33-42 | Positive Software End Limit | 34-24 | PCD 4 Read from MCO | 42-1* | 42-1* Speed Monitoring |
| 30-24 | Locked Rotor Detection Speed Error [%] | 33-43 | Negative Software End Limit Active | 34-25 | PCD 5 Read from MCO | 42-10 | Measured Speed Source |
| 30-8* | Compatibility (I) | 33-44 | Reverse Software End Limit Active | 34-26 | PCD 6 Read from MCO | 42-11 | Encoder Resolution |
| 30-80 | d-axis Inductance (Ld) | 33-45 | Time in Target Window | 34-27 | PCD 7 Read from MCO | 42-12 | Encoder Direction |
| 30-81 | Brake Resistor (ohm) | 33-46 | Target Window Limit/Value | 34-28 | PCD 8 Read from MCO | 42-13 | Gear Ratio |
| 30-83 | Speed PID Proportional Gain | 33-5* | I/O Configuration | 34-29 | PCD 9 Read from MCO | 42-14 | Feedback Type |
| 30-84 | Process PID Proportional Gain | 33-50 | Terminal X57/1 Digital Input | 34-30 | PCD 10 Read from MCO | 42-15 | Feedback Filter |
| 31-00 | Bypass Option | 33-51 | Terminal X57/2 Digital Input | 34-4* | Inputs & Outputs | 42-17 | Tolerance Error |
| 31-01 | Bypass Start Time Delay | 33-52 | Terminal X57/3 Digital Input | 34-41 | Digital Inputs | 42-18 | Zero Speed Timer |
| 31-02 | Bypass Trip Time Delay | 33-53 | Terminal X57/4 Digital Input | 34-5* | Process Data | 42-19 | Zero Speed Limit |
| 31-03 | Test Mode Activation | 33-54 | Terminal X57/5 Digital Input | 34-50 | Actual Position | 42-20 | Safe Input |
| 31-10 | Bypass Status Word | 33-55 | Terminal X57/6 Digital Input | 34-51 | Commanded Position | 42-21 | Type |
| 31-11 | Bypass Running Hours | 33-56 | Terminal X57/7 Digital Input | 34-52 | Actual Master Position | 42-22 | Discrepancy Time |
| 31-19 | Remote Bypass Activation | 33-57 | Terminal X57/8 Digital Input | 34-53 | Slave Index Position | 42-23 | Stable Signal Time |
| 32-2* | MCO Basic Settings | 33-58 | Terminal X57/9 Digital Input | 34-54 | Master Index Position | 42-24 | Restart Behaviour |
| 32-0* | Encoder 2 | 33-59 | Terminal X57/10 Digital Input | 34-55 | Curve Position | 42-3* | General |
| 32-00 | Incremental Signal Type | 33-60 | Terminal X59/1 and X59/2 Mode | 34-56 | Track Error | 42-30 | External Failure Reaction |
| 32-01 | Incremental Resolution | 33-61 | Terminal X59/1 Digital Input | 34-57 | Synchronizing Error | 42-31 | Reset Source |
| 32-02 | Absolute Protocol | 33-62 | Terminal X59/2 Digital Input | 34-58 | Actual Velocity | 42-33 | Parameter Set Name |
| 32-03 | Absolute Resolution | 33-63 | Terminal X59/1 Digital Output | 34-59 | Actual Master Velocity | 42-35 | S-CRC Value |
| 32-04 | Absolute Encoder Baudrate X55 | 33-64 | Terminal X59/2 Digital Output | 34-60 | Synchronizing Status | 42-36 | Level 1 Password |
| 32-05 | Absolute Encoder Data Length | 33-65 | Terminal X59/3 Digital Output | 34-61 | Axis Status | 42-4* | SS1 |
| 32-06 | Absolute Encoder Clock Frequency | 33-66 | Terminal X59/4 Digital Output | 34-62 | Program Status | 42-40 | Type |
| 32-07 | Absolute Encoder Clock Generation | 33-67 | Terminal X59/5 Digital Output | 34-64 | MCO 302 Status | 42-41 | Ramp Profile |
| 32-08 | Absolute Encoder Cable Length | 33-68 | Terminal X59/6 Digital Output | 34-65 | MCO 302 Control | 42-42 | Delay Time |
| 32-09 | Encoder Monitoring | 33-69 | Terminal X59/7 Digital Output | 34-7* | Diagnosis readouts | 42-43 | Delta T |
| 32-10 | Rotational Direction | 33-70 | Terminal X59/8 Digital Output | 34-70 | MCO Alarm Word 1 | 42-44 | Deceleration Rate |
| 32-11 | User Unit Denominator | 33-8* | Global Parameters | 34-71 | MCO Alarm Word 2 | 42-45 | Delta V |
| 32-12 | User Unit Numerator | 33-80 | Activated Program Number | 35-0* | Sensor Input Option | 42-46 | Zero Speed |
| 32-13 | Enc.2 Control | 33-81 | Power-up State | 35-00 | Temp. Input Mode | 42-47 | Ramp Time |
| 32-14 | Enc.2 node ID | 33-82 | Drive Status Monitoring | 35-01 | Term. X48/4 Temperature Unit | 42-48 | S-ramp Ratio at Decel. Start |
| 32-15 | Enc.2 CAN guard | 33-83 | Behaviour afterError | 35-02 | Term. X48/7 Temperature Unit | 42-49 | S-ramp Ratio at Decel. End |
| 32-3* | Encoder 1 | 33-84 | Behaviour afterEsc. | 35-03 | Term. X48/7 Input Type | 42-5* | SLS |
| 32-30 | Incremental Signal Type | 33-85 | MCO Supplied by External 24VDC | 35-04 | Term. X48/10 Temperature Unit | 42-50 | Cut Off Speed |
| 32-31 | Incremental Resolution | 33-86 | Terminal state at alarm | 35-05 | Term. X48/10 Input Type | 42-51 | Speed Limit |
| 32-32 | Absolute Protocol | 33-87 | Terminal state at alarm | 35-06 | Temperature Sensor Alarm Function | 42-52 | Fail Safe Reaction |
| 32-33 | Absolute Resolution | 33-9* | MCO Port Settings | 35-1* | Temp. Input X48/4 | 42-53 | Start Ramp |
| 32-35 | Absolute Encoder Data Length | 33-90 | X62 MCO CAN node ID | 35-14 | Term. X48/4 Filter Time Constant | 42-54 | Ramp Down Time |
| 32-36 | Absolute Encoder Clock Frequency | 33-91 | X62 MCO CAN baud rate | 35-15 | Term. X48/4 Temp. Monitor | 42-8* | Status |
| 32-37 | Absolute Encoder Clock Generation | 33-94 | X60 MCO RS485 serial termination | 35-16 | Term. X48/4 Low Temp. Limit | 42-80 | Safe Option Status |
| 32-38 | Absolute Encoder Cable Length | 33-95 | X60 MCO RS485 serial baud rate | 35-17 | Term. X48/4 High Temp. Limit | 42-81 | Safe Option Status 2 |
| 32-39 | Encoder Monitoring | 34-2* | MCO Data Readouts | 35-2* | Temp. Input X48/7 | 42-85 | Active Safe Func. |
| 32-40 | Encoder Termination | 34-0* | PCD Write Par. | 35-24 | Term. X48/7 Filter Time Constant | 42-86 | Safe Option Info |
| 32-43 | Enc.1 Control | 34-01 | PCD 1 Write to MCO | 35-25 | Term. X48/7 Temp. Monitor | 42-89 | Customization File Version |
| 32-44 | Enc.1 node ID | 34-02 | PCD 2 Write to MCO | 35-26 | Term. X48/7 Low Temp. Limit | 42-9* | Special |
| 32-45 | Enc.1 CAN guard | 34-03 | PCD 3 Write to MCO | 35-27 | Term. X48/7 High Temp. Limit | 42-90 | Restart Safe Option |
| 32-5* | Feedback Source | 34-04 | PCD 4 Write to MCO | 35-3* | Temp. Input X48/10 | | |
| 32-50 | Source Slave | 34-05 | PCD 5 Write to MCO | 35-34 | Term. X48/10 Filter Time Constant | | |
| 32-51 | MCO 302 Last Will | 34-06 | PCD 6 Write to MCO | 35-35 | Term. X48/10 Temp. Monitor | | |
| 32-52 | Source Master | 34-07 | PCD 7 Write to MCO | 35-36 | Term. X48/10 Low Temp. Limit | | |

5 General Specifications

Mains supply (L1, L2, L3):

| | |
|----------------|----------------|
| Supply voltage | 380-500 V ±10% |
| Supply voltage | 525-690 V ±10% |

Mains voltage low/mains drop-out:

During low mains voltage or a mains drop-out, the frequency converters continues until the intermediate circuit voltage drops below the minimum stop level, which corresponds typically to 15% below the drive's lowest rated supply voltage. Power-up and full torque cannot be expected at mains voltage lower than 10% below the frequency converter's lowest rated supply voltage.

| | |
|--|--|
| Supply frequency | 50/60 Hz ±5% |
| Max. imbalance temporary between mains phases | 3.0 % of rated supply voltage |
| True Power Factor (λ) | ≥ 0.9 nominal at rated load |
| Displacement Power Factor (cos ϕ) near unity | (> 0.98) |
| Switching on input supply L1, L2, L3 (power-ups) | maximum 1 time/2 min. |
| Environment according to EN60664-1 | over-voltage category III/pollution degree 2 |

The unit is suitable for use on a circuit capable of delivering not more than 100.000 RMS symmetrical Amperes, 500/600/690 V maximum.

Motor output (U, V, W)

| | |
|---------------------|----------------------------|
| Output voltage | 0 - 100% of supply voltage |
| Output frequency | 0 - 800* Hz |
| Switching on output | Unlimited |
| Ramp times | 0.01 - 3600 s |

* Voltage and power dependent

Torque characteristics

| | |
|--|--|
| Starting torque (constant torque) | maximum 160% for 60 s ¹⁾ once in 10 min. |
| Starting/overload torque (variable torque) | maximum 110% up to 0.5 s ¹⁾ once in 10 min. |
| Torque rise time in FLUX (for 5 kHz fsw) | 1 ms |
| Torque rise time in VVC ^{plus} (independent of fsw) | 10 ms |

¹⁾ Percentage relates to the nominal torque.

²⁾ The torque response time depends on application and load but as a general rule, the torque step from 0 to reference is 4-5 x torque rise time.

Digital inputs

| | |
|--|--|
| Programmable digital inputs | 4 (6) |
| Terminal number | 18, 19, 27 ¹⁾ , 29, 32, 33, |
| Logic | PNP or NPN |
| Voltage level | 0 - 24 V DC |
| Voltage level, logic '0' PNP | < 5 V DC |
| Voltage level, logic '1' PNP | > 10 V DC |
| Voltage level, logic '0' NPN ²⁾ | > 19 V DC |
| Voltage level, logic '1' NPN ²⁾ | < 14 V DC |
| Maximum voltage on input | 28 V DC |
| Pulse frequency range | 0 - 110 kHz |
| (Duty cycle) Min. pulse width | 4.5 ms |
| Input resistance, R _i | approx.4 kΩ |

Safe stop Terminal 37³⁾ (Terminal 37 is fixed PNP logic)

| | |
|-------------------------------|-------------|
| Voltage level | 0 - 24 V DC |
| Voltage level, logic'0' PNP | < 4 V DC |
| Voltage level, logic'1' PNP | >20 V DC |
| Nominal input current at 24 V | 50 mA rms |
| Nominal input current at 20 V | 60 mA rms |
| Input capacitance | 400 nF |

All digital inputs are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

¹⁾ Terminals 27 and 29 can also be programmed as output.

²⁾ Except safe stop input Terminal 37.

³⁾ See chapter 2.1.9 Safe Torque Off (STO) for further information about terminal 37 and Safe Stop..

Analog inputs

| | |
|----------------------------------|-----------------------------------|
| Number of analog inputs | 2 |
| Terminal number | 53, 54 |
| Modes | Voltage or current |
| Mode select | Switch S201 and switch S202 |
| Voltage mode | Switch S201/switch S202 = OFF (U) |
| Voltage level | -10 to +10 V (scaleable) |
| Input resistance, R _i | approx. 10 kΩ |
| Max. voltage | ± 20 V |
| Current mode | Switch S201/switch S202 = ON (I) |
| Current level | 0/4 to 20 mA (scaleable) |
| Input resistance, R _i | approx. 200 Ω |
| Max. current | 30 mA |
| Resolution for analog inputs | 10 bit (+ sign) |
| Accuracy of analog inputs | Max. error 0.5% of full scale |
| Bandwidth | 100 Hz |

The analog inputs are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.




Illustration 5.1

Pulse/encoder inputs

| | |
|---------------------------------------|---|
| Programmable pulse/encoder inputs | 2/1 |
| Terminal number pulse/encoder | 29 ¹⁾ , 33 ²⁾ / 32 ³⁾ , 33 ³⁾ |
| Max. frequency at terminal 29, 32, 33 | 110 kHz (Push-pull driven) |
| Max. frequency at terminal 29, 32, 33 | 5 kHz (open collector) |
| Min. frequency at terminal 29, 32, 33 | 4 Hz |
| Voltage level | see section on Digital input |
| Maximum voltage on input | 28 V DC |
| Input resistance, R _i | approx. 4 kΩ |
| Pulse input accuracy (0.1-1 kHz) | Max. error: 0.1% of full scale |
| Encoder input accuracy (1-11 kHz) | Max. error: 0.05 % of full scale |

The pulse and encoder inputs (terminals 29, 32, 33) are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

¹⁾ FC 302 only

²⁾ Pulse inputs are 29 and 33

³⁾ Encoder inputs: 32 = A, and 33 = B

Digital output

| | |
|--|---------------------------------|
| Programmable digital/pulse outputs | 2 |
| Terminal number | 27, 29 ¹⁾ |
| Voltage level at digital/frequency output | 0-24 V |
| Max. output current (sink or source) | 40 mA |
| Max. load at frequency output | 1 kΩ |
| Max. capacitive load at frequency output | 10 nF |
| Minimum output frequency at frequency output | 0 Hz |
| Maximum output frequency at frequency output | 32 kHz |
| Accuracy of frequency output | Max. error: 0.1 % of full scale |
| Resolution of frequency outputs | 12 bit |

¹⁾ Terminal 27 and 29 can also be programmed as input.

The digital output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Analog output

| | |
|---|--------------------------------|
| Number of programmable analog outputs | 1 |
| Terminal number | 42 |
| Current range at analog output | 0/4 to 20 mA |
| Max. load GND - analog output less than | 500 Ω |
| Accuracy on analog output | Max. error: 0.5% of full scale |
| Resolution on analog output | 12 bit |

The analog output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control card, 24 V DC output

| | |
|-----------------|--------------|
| Terminal number | 12, 13 |
| Output voltage | 24 V +1, -3V |
| Max. load | 200 mA |

The 24 V DC supply is galvanically isolated from the supply voltage (PELV), but has the same potential as the analog and digital inputs and outputs.

Control card, 10 V DC output

| | |
|-----------------|---------------|
| Terminal number | ±50 |
| Output voltage | 10.5 V ±0.5 V |
| Max. load | 15 mA |

The 10 V DC supply is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control card, RS-485 serial communication

| | |
|--------------------|----------------------------------|
| Terminal number | 68 (P,TX+, RX+), 69 (N,TX-, RX-) |
| Terminal number 61 | Common for terminals 68 and 69 |

The RS-485 serial communication circuit is functionally separated from other central circuits and galvanically isolated from the supply voltage (PELV).

Control card, USB serial communication:

| | |
|--------------|------------------|
| USB standard | 1.1 (Full speed) |
| USB plug | USB type B plug |

Connection to PC is carried out via a standard host/device USB cable.

The USB connection is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

The USB ground connection is not galvanically isolated from protection earth. Use only an isolated laptop as PC connection to the USB connector on the frequency converter.

Relay outputs

| | |
|--|---|
| Programmable relay outputs | 2 |
| Relay 01 Terminal number | 1-3 (break), 1-2 (make) |
| Max. terminal load (AC-1) ¹⁾ on 1-3 (NC), 1-2 (NO) (Resistive load) | 240 V AC, 2 A |
| Max. terminal load (AC-15) ¹⁾ (Inductive load @ cosφ 0.4) | 240 V AC, 0.2 A |
| Max. terminal load (DC-1) ¹⁾ on 1-2 (NO), 1-3 (NC) (Resistive load) | 60 V DC, 1 A |
| Max. terminal load (DC-13) ¹⁾ (Inductive load) | 24 V DC, 0.1 A |
| Relay 02 (FC 302 only) Terminal number | 4-6 (break), 4-5 (make) |
| Max. terminal load (AC-1) ¹⁾ on 4-5 (NO) (Resistive load) | 400 V AC, 2 A |
| Max. terminal load (AC-15) ¹⁾ on 4-5 (NO) (Inductive load @ cosφ 0.4) | 240 V AC, 0.2 A |
| Max. terminal load (DC-1) ¹⁾ on 4-5 (NO) (Resistive load) | 80 V DC, 2 A |
| Max. terminal load (DC-13) ¹⁾ on 4-5 (NO) (Inductive load) | 24 V DC, 0.1 A |
| Max. terminal load (AC-1) ¹⁾ on 4-6 (NC) (Resistive load) | 240 V AC, 2 A |
| Max. terminal load (AC-15) ¹⁾ on 4-6 (NC) (Inductive load @ cosφ 0.4) | 240 V AC, 0.2 A |
| Max. terminal load (DC-1) ¹⁾ on 4-6 (NC) (Resistive load) | 50 V DC, 2 A |
| Max. terminal load (DC-13) ¹⁾ on 4-6 (NC) (Inductive load) | 24 V DC, 0.1 A |
| Min. terminal load on 1-3 (NC), 1-2 (NO), 4-6 (NC), 4-5 (NO) | 24 V DC 10 mA, 24 V AC 20 mA |
| Environment according to EN 60664-1 | overvoltage category III/pollution degree 2 |

1) IEC 60947 part 4 and 5

The relay contacts are galvanically isolated from the rest of the circuit by reinforced isolation (PELV).

Cable lengths and cross sections

| | |
|--|------------------------------|
| Max. motor cable length, screened/armoured | 150 m |
| Max. motor cable length, unscreened/unarmoured | 300 m |
| Maximum cross section to control terminals, flexible/ rigid wire without cable end sleeves | 1.5 mm ² /16 AWG |
| Maximum cross section to control terminals, flexible wire with cable end sleeves | 1 mm ² /18 AWG |
| Maximum cross section to control terminals, flexible wire with cable end sleeves with collar | 0.5 mm ² /20 AWG |
| Minimum cross section to control terminals | 0.25 mm ² /24 AWG |

Control card performance

| | |
|---------------|------|
| Scan interval | 1 ms |
|---------------|------|

Control characteristics

| | |
|--|-------------------------------|
| Resolution of output frequency at 0-590 Hz | ±0.003 Hz |
| Repeat accuracy of Precise start/stop (terminals 18, 19) | ≤±0.1 ms |
| System response time (terminals 18, 19, 27, 29, 32, 33) | ≤ 2 ms |
| Speed control range (open loop) | 1:100 of synchronous speed |
| Speed control range (closed loop) | 1:1000 of synchronous speed |
| Speed accuracy (open loop) | 30-4000 RPM: error ±8 RPM |
| Speed accuracy (closed loop), depending on resolution of feedback device | 0-6000 RPM: error ±0.15 RPM |
| Torque control accuracy (speed feedback) | max error ±5% of rated torque |

All control characteristics are based on a 4-pole asynchronous motor

Surroundings

| | |
|---|---|
| Enclosure, frame size D and E | IP 00/ Chassis, IP 21/ Type 1, IP 54/ Type 12 |
| Enclosure, frame size F | IP 21/ Type 1, IP 54/ Type 12 |
| Vibration test | 0.7 g |
| Max. relative humidity | 5% - 95%(IEC 721-3-3; Class 3K3 (non-condensing) during operation |
| Aggressive environment (IEC 60068-2-43) | class H25 |
| Ambient temperature (with SFAVM switching mode) | |
| - with derating | Max. 55 °C ¹⁾ |
| - at full continuous drive output current | Max. 45 °C ¹⁾ |

1) For more information on derating, see special conditions in the Design Guide

| | |
|---|-----------------|
| Minimum ambient temperature during full-scale operation | 0 °C |
| Minimum ambient temperature at reduced performance | - 10 °C |
| Temperature during storage/transport | -25 - +65/70 °C |
| Maximum altitude above sea level without derating | 1000 m |

Derating for high altitude, see special conditions in the Design Guide

| | |
|-------------------------|--|
| EMC standards, Emission | EN 61800-3, EN 61000-6-3/4, EN 55011 |
| EMC standards, Immunity | EN 61800-3, EN 61000-6-1/2, EN 61000-4-2, EN 61000-4-3, EN 61000-4-4, EN 61000-4-5, EN 61000-4-6 |

See section on special conditions in the Design Guide.

Protection and Features

- Electronic thermal motor protection against overload.
- Temperature monitoring of the heatsink ensures that the frequency converter trips if the temperature reaches a predefined level. An overload temperature cannot be reset until the temperature of the heatsink is below the values stated in the tables on the following pages (Guideline - these temperatures may vary for different power sizes, frame sizes, enclosure ratings etc.).
- The frequency converter is protected against short-circuits on motor terminals U, V, W.
- If a mains phase is missing, the frequency converter trips or issues a warning (depending on the load).
- Monitoring of the intermediate circuit voltage ensures that the frequency converter trips if the intermediate circuit voltage is too low or too high.
- The frequency converter constantly checks for critical levels of internal temperature, load current, high voltage on the intermediate circuit and low motor speeds. As a response to a critical level, the frequency converter can adjust the switching frequency and/ or change the switching pattern to ensure the performance of the frequency converter.

| Mains Supply 3 x 380 - 500 V AC | | | | | | | | | | |
|--|------------------|------|------------------|------|-----------------------|------|-----------------------|------|-----------------------|------|
| FC 302 | P90K | | P110 | | P132 | | P160 | | P200 | |
| High/ Normal Load* | HO | NO | HO | NO | HO | NO | HO | NO | HO | NO |
| Typical Shaft output at 400 V [kW] | 90 | 110 | 110 | 132 | 132 | 160 | 160 | 200 | 200 | 250 |
| Typical Shaft output at 460 V [hp] | 125 | 150 | 150 | 200 | 200 | 250 | 250 | 300 | 300 | 350 |
| Typical Shaft output at 500 V [kW] | 110 | 132 | 132 | 160 | 160 | 200 | 200 | 250 | 250 | 315 |
| Enclosure IP21 | D1 | | D1 | | D2 | | D2 | | D2 | |
| Enclosure IP54 | D1 | | D1 | | D2 | | D2 | | D2 | |
| Enclosure IP00 | D3 | | D3 | | D4 | | D4 | | D4 | |
| Output current | | | | | | | | | | |
| Continuous (at 400 V) [A] | 177 | 212 | 212 | 260 | 260 | 315 | 315 | 395 | 395 | 480 |
| Intermittent (60 s overload) (at 400 V) [A] | 266 | 233 | 318 | 286 | 390 | 347 | 473 | 435 | 593 | 528 |
| Continuous (at 460/500 V) [A] | 160 | 190 | 190 | 240 | 240 | 302 | 302 | 361 | 361 | 443 |
| Intermittent (60 s overload) (at 460/500 V) [A] | 240 | 209 | 285 | 264 | 360 | 332 | 453 | 397 | 542 | 487 |
| Continuous kVA (at 400 V) [kVA] | 123 | 147 | 147 | 180 | 180 | 218 | 218 | 274 | 274 | 333 |
| Continuous kVA (at 460 V) [kVA] | 127 | 151 | 151 | 191 | 191 | 241 | 241 | 288 | 288 | 353 |
| Continuous kVA (at 500 V) [kVA] | 139 | 165 | 165 | 208 | 208 | 262 | 262 | 313 | 313 | 384 |
| Max. input current | | | | | | | | | | |
| Continuous (at 400 V) [A] | 171 | 204 | 204 | 251 | 251 | 304 | 304 | 381 | 381 | 463 |
| Continuous (at 460/500 V) [A] | 154 | 183 | 183 | 231 | 231 | 291 | 291 | 348 | 348 | 427 |
| Max. cable size, mains motor, brake and load share [mm ² (AWG ²)] | 2 x 70 (2 x 2/0) | | 2 x 70 (2 x 2/0) | | 2 x 150 (2 x 300 mcm) | | 2 x 150 (2 x 300 mcm) | | 2 x 150 (2 x 300 mcm) | |
| Max. external mains fuses [A] ¹ | 300 | | 350 | | 400 | | 500 | | 630 | |
| Estimated power loss at 400 V [W] ⁴⁾ | 2369 | 2907 | 2634 | 3357 | 3117 | 3914 | 3640 | 4812 | 4288 | 5517 |
| Estimated power loss at 460 V [W] | 2162 | 2599 | 2350 | 3078 | 2886 | 3781 | 3629 | 4535 | 3624 | 5025 |
| Weight, enclosure IP21, IP54 [kg] | 96 | | 104 | | 125 | | 136 | | 151 | |
| Weight, enclosure IP00 [kg] | 82 | | 91 | | 112 | | 123 | | 138 | |
| Efficiency ⁴⁾ | 0.98 | | | | | | | | | |
| Output frequency | 0 - 800 Hz | | | | | | | | | |
| Heatsink overtemp. trip | 90 °C | | 110 °C | | 110 °C | | 110 °C | | 110 °C | |
| Power card ambient trip | 75 °C | | | | | | | | | |

* High overload = 160% torque during 60 s, Normal overload = 110% torque during 60 s

Table 5.1

| Mains Supply 3 x 380 - 500 V AC | | | | | | | | |
|--|--------------------------|------|--------------------------|------|--------------------------|------|--------------------------|------|
| FC 302 | P250 | | P315 | | P355 | | P400 | |
| High/ Normal Load* | HO | NO | HO | NO | HO | NO | HO | NO |
| Typical Shaft output at 400 V [kW] | 250 | 315 | 315 | 355 | 355 | 400 | 400 | 450 |
| Typical Shaft output at 460 V [hp] | 350 | 450 | 450 | 500 | 500 | 600 | 550 | 600 |
| Typical Shaft output at 500 V [kW] | 315 | 355 | 355 | 400 | 400 | 500 | 500 | 530 |
| Enclosure IP21 | E1 | | E1 | | E1 | | E1 | |
| Enclosure IP54 | E1 | | E1 | | E1 | | E1 | |
| Enclosure IP00 | E2 | | E2 | | E2 | | E2 | |
| Output current | | | | | | | | |
| Continuous (at 400 V) [A] | 480 | 600 | 600 | 658 | 658 | 745 | 695 | 800 |
| Intermittent (60 sec overload) (at 400 V) [A] | 720 | 660 | 900 | 724 | 987 | 820 | 1043 | 880 |
| Continuous (at 460/500 V) [A] | 443 | 540 | 540 | 590 | 590 | 678 | 678 | 730 |
| Intermittent (60 s overload) (at 460/500 V) [A] | 665 | 594 | 810 | 649 | 885 | 746 | 1017 | 803 |
| Continuous kVA (at 400 V) [kVA] | 333 | 416 | 416 | 456 | 456 | 516 | 482 | 554 |
| Continuous kVA (at 460 V) [kVA] | 353 | 430 | 430 | 470 | 470 | 540 | 540 | 582 |
| Continuous kVA (at 500 V) [kVA] | 384 | 468 | 468 | 511 | 511 | 587 | 587 | 632 |
| Max. input current | | | | | | | | |
| Continuous (at 400 V) [A] | 472 | 590 | 590 | 647 | 647 | 733 | 684 | 787 |
| Continuous (at 460/500 V) [A] | 436 | 531 | 531 | 580 | 580 | 667 | 667 | 718 |
| Max. cable size, mains, motor and load share [mm ² (AWG ²)] | 4x240 (4x500 mcm) | | 4x240 (4x500 mcm) | | 4x240 (4x500 mcm) | | 4x240 (4x500 mcm) | |
| Max. cable size, brake [mm ² (AWG ²)] | 2 x 185 (2 x 350 mcm) | | 2 x 185 (2 x 350 mcm) | | 2 x 185 (2 x 350 mcm) | | 2 x 185 (2 x 350 mcm) | |
| Max. external mains fuses [A] ¹ | 700 | | 900 | | 900 | | 900 | |
| Estimated power loss at 400 V [W] ⁴⁾ | 5059 | 6705 | 6794 | 7532 | 7498 | 8677 | 7976 | 9473 |
| Estimated power loss at 460 V [W] | 4822 | 6082 | 6345 | 6953 | 6944 | 8089 | 8085 | 7814 |
| Weight, enclosure IP21, IP54 [kg] | 263 | | 270 | | 272 | | 313 | |
| Weight, enclosure IP00 [kg] | 221 | | 234 | | 236 | | 277 | |
| Efficiency ⁴⁾ | 0.98 | | | | | | | |
| Output frequency | 0 - 600 Hz | | | | | | | |
| Heatsink overtemp. trip | 110 °C | | | | | | | |
| Power card ambient trip | 75 °C | | | | | | | |

* High overload = 160% torque during 60 s, Normal overload = 110% torque during 60 s

Table 5.2

| Mains Supply 3 x 380 - 500 V AC | | | | | | | | | | | | |
|--|----------------------|-------|-----------|-------|-----------|-------|------------------------|-------|-----------|-------|-----------|-------|
| FC 302 | P450 | | P500 | | P560 | | P630 | | P710 | | P800 | |
| High/ Normal Load* | HO | NO | HO | NO | HO | NO | HO | NO | HO | NO | HO | NO |
| Typical Shaft output at 400 V [kW] | 450 | 500 | 500 | 560 | 560 | 630 | 630 | 710 | 710 | 800 | 800 | 1000 |
| Typical Shaft output at 460 V [hp] | 600 | 650 | 650 | 750 | 750 | 900 | 900 | 1000 | 1000 | 1200 | 1200 | 1350 |
| Typical Shaft output at 500 V [kW] | 530 | 560 | 560 | 630 | 630 | 710 | 710 | 800 | 800 | 1000 | 1000 | 1100 |
| Enclosure IP21, IP54 without/with options cabinet | F1/ F3 | | F1/ F3 | | F1/ F3 | | F1/ F3 | | F2/ F4 | | F2/ F4 | |
| Output current | | | | | | | | | | | | |
| Continuous (at 400 V) [A] | 800 | 880 | 880 | 990 | 990 | 1120 | 1120 | 1260 | 1260 | 1460 | 1460 | 1720 |
| Intermittent (60 s overload) (at 400 V) [A] | 1200 | 968 | 1320 | 1089 | 1485 | 1232 | 1680 | 1386 | 1890 | 1606 | 2190 | 1892 |
| Continuous (at 460/500 V) [A] | 730 | 780 | 780 | 890 | 890 | 1050 | 1050 | 1160 | 1160 | 1380 | 1380 | 1530 |
| Intermittent (60 s overload) (at 460/500 V) [A] | 1095 | 858 | 1170 | 979 | 1335 | 1155 | 1575 | 1276 | 1740 | 1518 | 2070 | 1683 |
| Continuous kVA (at 400 V) [kVA] | 554 | 610 | 610 | 686 | 686 | 776 | 776 | 873 | 873 | 1012 | 1012 | 1192 |
| Continuous kVA (at 460 V) [kVA] | 582 | 621 | 621 | 709 | 709 | 837 | 837 | 924 | 924 | 1100 | 1100 | 1219 |
| Continuous kVA (at 500 V) [kVA] | 632 | 675 | 675 | 771 | 771 | 909 | 909 | 1005 | 1005 | 1195 | 1195 | 1325 |
| Max. input current | | | | | | | | | | | | |
| Continuous (at 400 V) [A] | 779 | 857 | 857 | 964 | 964 | 1090 | 1090 | 1227 | 1227 | 1422 | 1422 | 1675 |
| Continuous (at 460/ 500 V) [A] | 711 | 759 | 759 | 867 | 867 | 1022 | 1022 | 1129 | 1129 | 1344 | 1344 | 1490 |
| Max. cable size,motor [mm ² (AWG ²)] | 8x150 (8x300 mcm) | | | | | | 12x150 (12x300 mcm) | | | | | |
| Max. cable size,mains F1/F2 [mm ² (AWG ²)] | 8x240 (8x500 mcm) | | | | | | | | | | | |
| Max. cable size,mains F3/F4 [mm ² (AWG ²)] | 8x456 (8x900 mcm) | | | | | | | | | | | |
| Max. cable size, loadsharing [mm ² (AWG ²)] | 4x120 (4x250 mcm) | | | | | | | | | | | |
| Max. cable size, brake [mm ² (AWG ²)] | 4x185 (4x350 mcm) | | | | | | 6x185 (6x350 mcm) | | | | | |
| Max. external mains fuses [A] ¹ | 1600 | | | | 2000 | | | | 2500 | | | |
| Estimated power loss, 400 V [W] ⁴⁾ | 9031 | 10162 | 10146 | 11822 | 10649 | 12512 | 12490 | 14674 | 14244 | 17293 | 15466 | 19278 |
| Estimated power loss, 460 V [W] | 8212 | 8876 | 8860 | 10424 | 9414 | 11595 | 11581 | 13213 | 13005 | 16229 | 14556 | 16624 |
| F3/F4 max. added losses A1 RFI, CB or Disconnect, & contactor F3/F4 | 893 | 963 | 951 | 1054 | 978 | 1093 | 1092 | 1230 | 2067 | 2280 | 2236 | 2541 |
| Max. panel options losses | 400 | | | | | | | | | | | |
| Weight,enclosure IP21/IP54 [kg] | 1004/1299 | | 1004/1299 | | 1004/1299 | | 1004/1299 | | 1246/1541 | | 1246 1541 | |
| Weight Rectifier Module [kg] | 102 | | 102 | | 102 | | 102 | | 136 | | 136 | |
| Weight Inverter Module [kg] | 102 | | 102 | | 102 | | 136 | | 102 | | 102 | |
| Efficiency ⁴⁾ | 0.98 | | | | | | | | | | | |
| Output frequency | 0-600 Hz | | | | | | | | | | | |
| Heatsink overtemp. trip | 95 °C | | | | | | | | | | | |
| Power card ambient trip | 75 °C | | | | | | | | | | | |
| * High overload = 160% torque during 60 s, Normal overload = 110% torque during 60 s | | | | | | | | | | | | |

Table 5.3

5

| Mains Supply 525-690 V AC | | | | | | | | | | |
|---|--------------|------|------|------|------|------|------|------|------|------|
| FC 302 | P37K | | P45K | | P55K | | P75K | | P90K | |
| High/ Normal Load* | HO | NO | HO | NO | HO | NO | HO | NO | HO | NO |
| Typical Shaft output at 550 V [kW] | 30 | 37 | 37 | 45 | 45 | 55 | 55 | 75 | 75 | 90 |
| Typical Shaft output at 575 V [hp] | 40 | 50 | 50 | 60 | 60 | 75 | 75 | 100 | 100 | 125 |
| Typical Shaft output at 690 V [kW] | 37 | 45 | 45 | 55 | 55 | 75 | 75 | 90 | 90 | 110 |
| Enclosure IP21 | D1 | | D1 | | D1 | | D1 | | D1 | |
| Enclosure IP54 | D1 | | D1 | | D1 | | D1 | | D1 | |
| Enclosure IP00 | D3 | | D3 | | D3 | | D3 | | D3 | |
| Output current | | | | | | | | | | |
| Continuous (at 550 V) [A] | 48 | 56 | 56 | 76 | 76 | 90 | 90 | 113 | 113 | 137 |
| Intermittent (60 s overload) (at 550 V) [A] | 77 | 62 | 90 | 84 | 122 | 99 | 135 | 124 | 170 | 151 |
| Continuous (at 575/690 V) [A] | 46 | 54 | 54 | 73 | 73 | 86 | 86 | 108 | 108 | 131 |
| Intermittent (60 s overload) (at 575/690 V) [A] | 74 | 59 | 86 | 80 | 117 | 95 | 129 | 119 | 162 | 144 |
| Continuous KVA (at 550 V) [KVA] | 46 | 53 | 53 | 72 | 72 | 86 | 86 | 108 | 108 | 131 |
| Continuous KVA (at 575 V) [KVA] | 46 | 54 | 54 | 73 | 73 | 86 | 86 | 108 | 108 | 130 |
| Continuous KVA (at 690 V) [KVA] | 55 | 65 | 65 | 87 | 87 | 103 | 103 | 129 | 129 | 157 |
| Max. input current | | | | | | | | | | |
| Continuous (at 550 V) [A] | 53 | 60 | 60 | 77 | 77 | 89 | 89 | 110 | 110 | 130 |
| Continuous (at 575 V) [A] | 51 | 58 | 58 | 74 | 74 | 85 | 85 | 106 | 106 | 124 |
| Continuous (at 690 V) [A] | 50 | 58 | 58 | 77 | 77 | 87 | 87 | 109 | 109 | 128 |
| Max. cable size, mains, motor, load share and brake [mm ² (AWG)] | 2x70 (2x2/0) | | | | | | | | | |
| Max. external mains fuses [A] ¹ | 125 | | 160 | | 200 | | 200 | | 250 | |
| Estimated power loss at 600 V [W] ⁴⁾ | 1299 | 1398 | 1459 | 1645 | 1643 | 1827 | 1350 | 1599 | 1597 | 1891 |
| Estimated power loss at 690 V [W] ⁴⁾ | 1002 | 1071 | 1071 | 1251 | 1251 | 1392 | 1392 | 1648 | 1650 | 1951 |
| Weight, enclosure IP21, IP54 [kg] | 96 | | | | | | | | | |
| Weight, enclosure IP00 [kg] | 82 | | | | | | | | | |
| Efficiency ⁴⁾ | 0.97 | | 0.97 | | 0.98 | | 0.98 | | 0.98 | |
| Output frequency | 0 - 600Hz | | | | | | | | | |
| Heatsink overtemp. trip | 90°C | | | | | | | | | |
| Power card ambient trip | 75°C | | | | | | | | | |

* High overload = 160% torque during 60 s., Normal overload = 110% torque during 60 s.

Table 5.4

| Mains Supply 525-690 V AC | | | | | | | | |
|--|------------------|------|------------------|------|-----------------------|------|-----------------------|------|
| FC 302 | P110 | | P132 | | P160 | | P200 | |
| High/ Normal Load* | HO | NO | HO | NO | HO | NO | HO | NO |
| Typical Shaft output at 550 V [kW] | 90 | 110 | 110 | 132 | 132 | 160 | 160 | 200 |
| Typical Shaft output at 575 V [hp] | 125 | 150 | 150 | 200 | 200 | 250 | 250 | 300 |
| Typical Shaft output at 690 V [kW] | 110 | 132 | 132 | 160 | 160 | 200 | 200 | 250 |
| Enclosure IP21 | D1 | | D1 | | D2 | | D2 | |
| Enclosure IP54 | D1 | | D1 | | D2 | | D2 | |
| Enclosure IP00 | D3 | | D3 | | D4 | | D4 | |
| Output current | | | | | | | | |
| Continuous (at 550 V) [A] | 137 | 162 | 162 | 201 | 201 | 253 | 253 | 303 |
| Intermittent (60 s overload) (at 550 V) [A] | 206 | 178 | 243 | 221 | 302 | 278 | 380 | 333 |
| Continuous (at 575/690 V) [A] | 131 | 155 | 155 | 192 | 192 | 242 | 242 | 290 |
| Intermittent (60 s overload) (at 575/690 V) [A] | 197 | 171 | 233 | 211 | 288 | 266 | 363 | 319 |
| Continuous KVA (at 550 V) [KVA] | 131 | 154 | 154 | 191 | 191 | 241 | 241 | 289 |
| Continuous KVA (at 575 V) [KVA] | 130 | 154 | 154 | 191 | 191 | 241 | 241 | 289 |
| Continuous KVA (at 690 V) [KVA] | 157 | 185 | 185 | 229 | 229 | 289 | 289 | 347 |
| Max. input current | | | | | | | | |
| Continuous (at 550 V) [A] | 130 | 158 | 158 | 198 | 198 | 245 | 245 | 299 |
| Continuous (at 575 V) [A] | 124 | 151 | 151 | 189 | 189 | 234 | 234 | 286 |
| Continuous (at 690 V) [A] | 128 | 155 | 155 | 197 | 197 | 240 | 240 | 296 |
| Max. cable size, mains motor, load share and brake [mm ² (AWG)] | 2 x 70 (2 x 2/0) | | 2 x 70 (2 x 2/0) | | 2 x 150 (2 x 300 mcm) | | 2 x 150 (2 x 300 mcm) | |
| Max. external mains fuses [A] ¹ | 315 | | 350 | | 350 | | 400 | |
| Estimated power loss at 600 V [W] ⁴⁾ | 1890 | 2230 | 2101 | 2617 | 2491 | 3197 | 3063 | 3757 |
| Estimated power loss at 690 V [W] ⁴⁾ | 1953 | 2303 | 2185 | 2707 | 2606 | 3320 | 3192 | 3899 |
| Weight, Enclosure IP21, IP54 [kg] | 96 | | 104 | | 125 | | 136 | |
| Weight, Enclosure IP00 [kg] | 82 | | 91 | | 112 | | 123 | |
| Efficiency ⁴⁾ | 0.98 | | | | | | | |
| Output frequency | 0 - 600 Hz | | | | | | | |
| Heatsink overtemp. trip | 90°C | | 110°C | | 110°C | | 110°C | |
| Power card ambient trip | 75°C | | | | | | | |

* High overload = 160% torque during 60 s., Normal overload = 110% torque during 60 s.

Table 5.5

| Mains Supply 525-690 V AC | | | | | | |
|--|--------------------------|------|--------------------------|------|--------------------------|------|
| FC 302 | P250 | | P315 | | P355 | |
| High/ Normal Load* | HO | NO | HO | NO | HO | NO |
| Typical Shaft output at 550 V [kW] | 200 | 250 | 250 | 315 | 315 | 355 |
| Typical Shaft output at 575 V [hp] | 300 | 350 | 350 | 400 | 400 | 450 |
| Typical Shaft output at 690 V [kW] | 250 | 315 | 315 | 400 | 355 | 450 |
| Enclosure IP21 | D2 | | D2 | | E1 | |
| Enclosure IP54 | D2 | | D2 | | E1 | |
| Enclosure IP00 | D4 | | D4 | | E2 | |
| Output current | | | | | | |
| Continuous (at 550 V) [A] | 303 | 360 | 360 | 418 | 395 | 470 |
| Intermittent (60 sec overload) (at 550 V) [A] | 455 | 396 | 540 | 460 | 593 | 517 |
| Continuous (at 575/690 V) [A] | 290 | 344 | 344 | 400 | 380 | 450 |
| Intermittent (60 s overload) (at 575/ 690 V) [A] | 435 | 378 | 516 | 440 | 570 | 495 |
| Continuous KVA (at 550 V) [KVA] | 289 | 343 | 343 | 398 | 376 | 448 |
| Continuous KVA (at 575 V) [KVA] | 289 | 343 | 343 | 398 | 378 | 448 |
| Continuous KVA (at 690 V) [KVA] | 347 | 411 | 411 | 478 | 454 | 538 |
| Max. input current | | | | | | |
| Continuous (at 550 V) [A] | 299 | 355 | 355 | 408 | 381 | 453 |
| Continuous (at 575 V) [A] | 286 | 339 | 339 | 390 | 366 | 434 |
| Continuous (at 690 V) [A] | 296 | 352 | 352 | 400 | 366 | 434 |
| Max. cable size, mains, motor and load share [mm ² (AWG)] | 2 x 150 (2 x 300 mcm) | | 2 x 150 (2 x 300 mcm) | | 4 x 240 (4 x 500 mcm) | |
| Max. cable size, brake [mm ² (AWG)] | 2 x 150 (2 x 300 mcm) | | 2 x 150 (2 x 300 mcm) | | 2 x 185 (2 x 350 mcm) | |
| Max. external mains fuses [A] ¹ | 500 | | 550 | | 700 | |
| Estimated power loss at 600 V [W] ⁴⁾ | 3552 | 4307 | 3971 | 4756 | 4130 | 4974 |
| Estimated power loss at 690 V [W] ⁴⁾ | 3704 | 4485 | 4103 | 4924 | 4240 | 5128 |
| Weight, enclosure IP21, IP54 [kg] | 151 | | 165 | | 263 | |
| Weight, enclosure IP00 [kg] | 138 | | 151 | | 221 | |
| Efficiency ⁴⁾ | 0.98 | | | | | |
| Output frequency | 0 - 600Hz | | 0 - 500Hz | | 0 - 500Hz | |
| Heatsink overtemp. trip | 110°C | | 110°C | | 110°C | |
| Power card ambient trip | 75°C | | 75°C | | 75°C | |

* High overload = 160% torque during 60 s, Normal overload = 110% torque during 60 s.

Table 5.6

| Mains Supply 525-690 V AC | | | | | | |
|--|-----------------------|------|-----------------------|------|-----------------------|------|
| FC 302 | P400 | | P500 | | P560 | |
| High/ Normal Load* | HO | NO | HO | NO | HO | NO |
| Typical Shaft output at 550 V [kW] | 315 | 400 | 400 | 450 | 450 | 500 |
| Typical Shaft output at 575 V [hp] | 400 | 500 | 500 | 600 | 600 | 650 |
| Typical Shaft output at 690 V [kW] | 400 | 500 | 500 | 560 | 560 | 630 |
| Enclosure IP21 | E1 | | E1 | | E1 | |
| Enclosure IP54 | E1 | | E1 | | E1 | |
| Enclosure IP00 | E2 | | E2 | | E2 | |
| Output current | | | | | | |
| Continuous (at 550 V) [A] | 429 | 523 | 523 | 596 | 596 | 630 |
| Intermittent (60 sec overload) (at 550 V) [A] | 644 | 575 | 785 | 656 | 894 | 693 |
| Continuous (at 575/690 V) [A] | 410 | 500 | 500 | 570 | 570 | 630 |
| Intermittent (60 s overload) (at 575/690 V) [A] | 615 | 550 | 750 | 627 | 855 | 693 |
| Continuous KVA (at 550 V) [KVA] | 409 | 498 | 498 | 568 | 568 | 600 |
| Continuous KVA (at 575 V) [KVA] | 408 | 498 | 498 | 568 | 568 | 627 |
| Continuous KVA (at 690 V) [KVA] | 490 | 598 | 598 | 681 | 681 | 753 |
| Max. input current | | | | | | |
| Continuous (at 550 V) [A] | 413 | 504 | 504 | 574 | 574 | 607 |
| Continuous (at 575 V) [A] | 395 | 482 | 482 | 549 | 549 | 607 |
| Continuous (at 690 V) [A] | 395 | 482 | 482 | 549 | 549 | 607 |
| Max. cable size, mains, motor and load share [mm ² (AWG)] | 4x240 (4x500 mcm) | | 4x240 (4x500 mcm) | | 4x240 (4x500 mcm) | |
| Max. cable size, brake [mm ² (AWG)] | 2 x 185 (2 x 350 mcm) | | 2 x 185 (2 x 350 mcm) | | 2 x 185 (2 x 350 mcm) | |
| Max. external mains fuses [A] ¹ | 700 | | 900 | | 900 | |
| Estimated power loss at 600 V [W] ⁴⁾ | 4478 | 5623 | 6153 | 7018 | 7007 | 7793 |
| Estimated power loss at 690 V [W] ⁴⁾ | 4605 | 5794 | 6328 | 7221 | 7201 | 8017 |
| Weight, enclosure IP21, IP54 [kg] | 263 | | 272 | | 313 | |
| Weight, enclosure IP00 [kg] | 221 | | 236 | | 277 | |
| Efficiency ⁴⁾ | 0.98 | | | | | |
| Output frequency | 0 - 500Hz | | | | | |
| Heatsink overtemp. trip | 110°C | | | | | |
| Power card ambient trip | 75°C | | | | | |

* High overload = 160% torque during 60 s., Normal overload = 110% torque during 60 s.

Table 5.7

5

| Mains Supply 525-690 V AC | | | | | | |
|--|----------------------|------|------------|-------|------------|-------|
| FC 302 | P630 | | P710 | | P800 | |
| High/ Normal Load* | HO | NO | HO | NO | HO | NO |
| Typical Shaft output at 550 V [kW] | 500 | 560 | 560 | 670 | 670 | 750 |
| Typical Shaft output at 575 V [hp] | 650 | 750 | 750 | 950 | 950 | 1050 |
| Typical Shaft output at 690 V [kW] | 630 | 710 | 710 | 800 | 800 | 900 |
| Enclosure IP21, 54 without/ with options cabinet | F1/ F3 | | F1/ F3 | | F1/ F3 | |
| Output current | | | | | | |
| Continuous (at 550 V) [A] | 659 | 763 | 763 | 889 | 889 | 988 |
| Intermittent (60 sec overload) (at 550 V) [A] | 989 | 839 | 1145 | 978 | 1334 | 1087 |
| Continuous (at 575/690 V) [A] | 630 | 730 | 730 | 850 | 850 | 945 |
| Intermittent (60 sec overload) (at 575/690 V) [A] | 945 | 803 | 1095 | 935 | 1275 | 1040 |
| Continuous KVA (at 550 V) [KVA] | 628 | 727 | 727 | 847 | 847 | 941 |
| Continuous KVA (at 575 V) [KVA] | 627 | 727 | 727 | 847 | 847 | 941 |
| Continuous KVA (at 690 V) [KVA] | 753 | 872 | 872 | 1016 | 1016 | 1129 |
| Max. input current | | | | | | |
| Continuous (at 550 V) [A] | 642 | 743 | 743 | 866 | 866 | 962 |
| Continuous (at 575 V) [A] | 613 | 711 | 711 | 828 | 828 | 920 |
| Continuous (at 690 V) [A] | 613 | 711 | 711 | 828 | 828 | 920 |
| Max. cable size, motor [mm ² (AWG ²)] | 8x150 (8x300 mcm) | | | | | |
| Max. cable size, mains F1 [mm ² (AWG ²)] | 8x240 (8x500 mcm) | | | | | |
| Max. cable size, mains F3 [mm ² (AWG ²)] | 8x456 (8x900 mcm) | | | | | |
| Max. cable size, loadsharing [mm ² (AWG ²)] | 4x120 (4x250 mcm) | | | | | |
| Max. cable size, brake [mm ² (AWG ²)] | 4x185 (4x350 mcm) | | | | | |
| Max. external mains fuses [A] ¹ | 1600 | | | | | |
| Estimated power loss, 600 V [W] ⁴⁾ | 7586 | 8933 | 8683 | 10310 | 10298 | 11692 |
| Estimated power loss, 690 V [W] ⁴⁾ | 7826 | 9212 | 8983 | 10659 | 10646 | 12080 |
| F3/F4 Max added losses CB or Disconnect & Contactor | 342 | 427 | 419 | 532 | 519 | 615 |
| Max panel options losses | 400 | | | | | |
| Weight, enclosure IP21, IP54 [kg] | 1004/ 1299 | | 1004/ 1299 | | 1004/ 1299 | |
| Weight, Rectifier Module [kg] | 102 | | 102 | | 102 | |
| Weight, Inverter Module [kg] | 102 | | 102 | | 136 | |
| Efficiency ⁴⁾ | 0.98 | | | | | |
| Output frequency | 0-500 Hz | | | | | |
| Heatsink overtemp. trip | 95 °C | | 105 °C | | 95 °C | |
| Power card ambient trip | 75 °C | | | | | |

* High overload = 160% torque during 60 s., Normal overload = 110% torque during 60 s.

Table 5.8

| Mains Supply 525-690 V AC | | | | | | |
|--|------------------------|-------|------------|-------|-----------|-------|
| FC 302 | P900 | | P1M0 | | P1M2 | |
| High/ Normal Load* | HO | NO | HO | NO | HO | NO |
| Typical Shaft output at 550 V [kW] | 750 | 850 | 850 | 1000 | 1000 | 1100 |
| Typical Shaft output at 575 V [hp] | 1050 | 1150 | 1150 | 1350 | 1350 | 1550 |
| Typical Shaft output at 690 V [kW] | 900 | 1000 | 1000 | 1200 | 1200 | 1400 |
| Enclosure IP21, IP54 without/with options cabinet | F2/ F4 | | F2/ F4 | | F2/ F4 | |
| Output current | | | | | | |
| Continuous (at 550 V) [A] | 988 | 1108 | 1108 | 1317 | 1317 | 1479 |
| Intermittent (60 s overload) (at 550 V) [A] | 1482 | 1219 | 1662 | 1449 | 1976 | 1627 |
| Continuous (at 575/690 V) [A] | 945 | 1060 | 1060 | 1260 | 1260 | 1415 |
| Intermittent (60 s overload) (at 575/690 V) [A] | 1418 | 1166 | 1590 | 1386 | 1890 | 1557 |
| Continuous KVA (at 550 V) [KVA] | 941 | 1056 | 1056 | 1255 | 1255 | 1409 |
| Continuous KVA (at 575 V) [KVA] | 941 | 1056 | 1056 | 1255 | 1255 | 1409 |
| Continuous KVA (at 690 V) [KVA] | 1129 | 1267 | 1267 | 1506 | 1506 | 1691 |
| Max. input current | | | | | | |
| Continuous (at 550 V) [A] | 962 | 1079 | 1079 | 1282 | 1282 | 1440 |
| Continuous (at 575 V) [A] | 920 | 1032 | 1032 | 1227 | 1227 | 1378 |
| Continuous (at 690 V) [A] | 920 | 1032 | 1032 | 1227 | 1227 | 1378 |
| Max. cable size, motor [mm ² (AWG ²)] | 12x150 (12x300 mcm) | | | | | |
| Max. cable size,mains F2 [mm ² (AWG ²)] | 8x240 (8x500 mcm) | | | | | |
| Max. cable size,mains F4 [mm ² (AWG ²)] | 8x456 (8x900 mcm) | | | | | |
| Max. cable size, loadsharing [mm ² (AWG ²)] | 4x120 (4x250 mcm) | | | | | |
| Max. cable size, brake [mm ² (AWG ²)] | 6x185 (6x350 mcm) | | | | | |
| Max. external mains fuses [A] ¹ | 1600 | | 2000 | | 2500 | |
| Estimated power loss, 600V [W] ⁴⁾ | 11329 | 12909 | 12570 | 15358 | 15258 | 17602 |
| Estimated power loss, 690V [W] ⁴⁾ | 11681 | 13305 | 12997 | 15865 | 15763 | 18173 |
| F3/F4 Max added losses CB or Disconnect & Contactor | 556 | 665 | 634 | 863 | 861 | 1044 |
| Max panel options losses | 400 | | | | | |
| Weight, enclosure IP21, IP54 [kg] | 1246/ 1541 | | 1246/ 1541 | | 1280/1575 | |
| Weight, Rectifier Module [kg] | 136 | | 136 | | 136 | |
| Weight, Inverter Module [kg] | 102 | | 102 | | 136 | |
| Efficiency ⁴⁾ | 0.98 | | | | | |
| Output frequency | 0-500Hz | | | | | |
| Heatsink overtemp. trip | 105°C | | 105°C | | 95°C | |
| Power card ambient trip | 75°C | | | | | |
| * High overload = 160% torque during 60 s., Normal overload = 110% torque during 60 s. | | | | | | |

Table 5.9

1) For type of fuse see *chapter 3.5.13 Fuses*.

2) American Wire Gauge.

3) Measured using 5 m screened motor cables at rated load and rated frequency.

4) The typical power loss is at nominal load conditions and expected to be within +/-15% (tolerance relates to variety in voltage and cable conditions).

Values are based on a typical motor efficiency (eff2/eff3 border line). Motors with lower efficiency will also add to the power loss in the frequency converter and opposite.

If the switching frequency is increased compared to the default setting, the power losses may rise significantly.

LCP and typical control card power consumptions are included. Further options and customer load may add up to 30 W to the losses. (Though typical only 4 W extra for a fully loaded control card, or options for slot A or slot B, each).

Although measurements are made with state of the art equipment, some measurement inaccuracy must be allowed for (+/-5%).

6 Warnings and Alarms

6.1 Status Messages

6.1.1 Warnings/Alarm Messages

A warning or an alarm is signalled by the relevant LED on the front of the frequency converter and indicated by a code on the display.

A warning remains active until its cause is no longer present. Under certain circumstances operation of the motor may still be continued. Warning messages may be critical, but are not necessarily so.

An alarm trips the frequency converter. Reset alarms to restart operation once their cause has been rectified.

This may be done in three ways

- By pressing [Reset].
- Via a digital input with the “Reset” function.
- Via serial communication/optional fieldbus.

NOTICE

After a manual reset pressing [Reset], [Auto On] must be pressed to restart the motor.

If an alarm cannot be reset, the reason may be that its cause has not been rectified, or the alarm is trip-locked (see also *Table 6.1*).

Alarms that are trip-locked offer additional protection, meaning that the mains supply must be switched off before the alarm can be reset. After being switched back on, the frequency converter is no longer blocked and may be reset as described above once the cause has been rectified.

Alarms that are not trip-locked can also be reset using the automatic reset function in *14-20 Reset Mode* (Warning: automatic wake-up is possible!)

If a warning and alarm is marked against a code in *Table 6.1*, this means that either a warning occurs before an alarm, or else that it is possible to specify whether it is a warning or an alarm that is to be displayed for a given fault.

This is possible, for instance, in *1-90 Motor Thermal Protection*. After an alarm or trip, the motor carries on coasting, and the alarm and warning flash. Once the problem has been rectified, only the alarm continues flashing until the frequency converter is reset.

NOTICE

No missing motor phase detection (no 30-32) and no stall detection is active when *1-10 Motor Construction* is set to [1] *PM non salient SPM*.

| No. | Description | Warning | Alarm/Trip | Alarm/Trip Lock | Parameter Reference |
|-----|-----------------------------------|---------|------------|-----------------|-----------------------------------|
| 1 | 10 Volts low | X | | | |
| 2 | Live zero error | (X) | (X) | | 6-01 Live Zero Timeout Function |
| 3 | No motor | (X) | | | 1-80 Function at Stop |
| 4 | Mains phase loss | (X) | (X) | (X) | 14-12 Function at Mains Imbalance |
| 5 | DC link voltage high | X | | | |
| 6 | DC link voltage low | X | | | |
| 7 | DC over-voltage | X | X | | |
| 8 | DC under voltage | X | X | | |
| 9 | Inverter overloaded | X | X | | |
| 10 | Motor ETR over temperature | (X) | (X) | | 1-90 Motor Thermal Protection |
| 11 | Motor thermistor over temperature | (X) | (X) | | 1-90 Motor Thermal Protection |
| 12 | Torque limit | X | X | | |
| 13 | Over Current | X | X | X | |

| No. | Description | Warning | Alarm/Trip | Alarm/Trip Lock | Parameter Reference |
|-----|--|---------|------------|-----------------|--|
| 14 | Earth Fault | X | X | X | |
| 15 | Hardware mismatch | | X | X | |
| 16 | Short Circuit | | X | X | |
| 17 | Control word time-out | (X) | (X) | | 8-04 Control Word Timeout Function |
| 18 | Start Failed | | X | | 1-77 Compressor Start Max Speed [RPM] and 1-79 Compressor Start Max Time to Trip |
| 20 | Temp. Input Error | | | | |
| 21 | Param Error | | | | |
| 22 | Hoist Mech. Brake | (X) | (X) | | Parameter group 2-2* |
| 23 | Internal Fans | X | | | |
| 24 | External Fans | X | | | |
| 25 | Brake resistor short-circuited | X | | | |
| 26 | Brake resistor power limit | (X) | (X) | | 2-13 Brake Power Monitoring |
| 27 | Brake chopper short-circuited | X | X | | |
| 28 | Brake check | (X) | (X) | | 2-15 Brake Check |
| 29 | Heatsink temp | X | X | X | |
| 30 | Motor phase U missing | (X) | (X) | (X) | 4-58 Missing Motor Phase Function |
| 31 | Motor phase V missing | (X) | (X) | (X) | 4-58 Missing Motor Phase Function |
| 32 | Motor phase W missing | (X) | (X) | (X) | 4-58 Missing Motor Phase Function |
| 33 | Inrush Fault | | X | X | |
| 34 | Fieldbus communication fault | X | X | | |
| 35 | Option Fault | | | | |
| 36 | Mains failure | X | X | | |
| 37 | Phase imbalance | | X | | |
| 38 | Internal Fault | | X | X | |
| 39 | Heatsink sensor | | X | X | |
| 40 | Overload of Digital Output Terminal 27 | (X) | | | 5-00 Digital I/O Mode, 5-01 Terminal 27 Mode |
| 41 | Overload of Digital Output Terminal 29 | (X) | | | 5-00 Digital I/O Mode, 5-02 Terminal 29 Mode |
| 42 | Ovrlld X30/6-7 | (X) | | | |
| 43 | Ext. Supply (option) | | | | |
| 45 | Earth Fault 2 | X | X | X | |
| 46 | Pwr. card supply | | X | X | |
| 47 | 24 V supply low | X | X | X | |
| 48 | 1.8 V supply low | | X | X | |
| 49 | Speed limit | | X | | 1-86 Trip Speed Low [RPM] |
| 50 | AMA calibration failed | | X | | |
| 51 | AMA check U_{nom} and I_{nom} | | X | | |
| 52 | AMA low I_{nom} | | X | | |
| 53 | AMA motor too big | | X | | |
| 54 | AMA motor too small | | X | | |
| 55 | AMA parameter out of range | | X | | |
| 56 | AMA interrupted by user | | X | | |

| No. | Description | Warning | Alarm/Trip | Alarm/Trip Lock | Parameter Reference |
|-----|------------------------------------|---------|-------------------|-----------------|---------------------------------------|
| 57 | AMA time-out | | X | | |
| 58 | AMA internal fault | X | X | | |
| 59 | Current limit | X | | | |
| 60 | External Interlock | X | X | | |
| 61 | Feedback Error | (X) | (X) | | 4-30 Motor Feedback Loss Function |
| 62 | Output Frequency at Maximum Limit | X | | | |
| 63 | Mechanical Brake Low | | (X) | | 2-20 Release Brake Current |
| 64 | Voltage Limit | X | | | |
| 65 | Control Board Over-temperature | X | X | X | |
| 66 | Heat sink Temperature Low | X | | | |
| 67 | Option Configuration has Changed | | X | | |
| 68 | Safe Stop | (X) | (X) ¹⁾ | | 5-19 Terminal 37 Safe Stop |
| 69 | Pwr. Card Temp | | X | X | |
| 70 | Illegal FC configuration | | | X | |
| 71 | PTC 1 Safe Stop | | | | |
| 72 | Dangerous failure | | | | |
| 73 | Safe Stop Auto Restart | (X) | (X) | | 5-19 Terminal 37 Safe Stop |
| 74 | PTC Thermistor | | | X | |
| 75 | Illegal Profile Sel. | | X | | |
| 76 | Power Unit Setup | X | | | |
| 77 | Reduced power mode | X | | | 14-59 Actual Number of Inverter Units |
| 78 | Tracking Error | (X) | (X) | | 4-34 Tracking Error Function |
| 79 | Illegal PS config | | X | X | |
| 80 | Drive Initialized to Default Value | | X | | |
| 81 | CSIV corrupt | | X | | |
| 82 | CSIV parameter error | | X | | |
| 83 | Illegal Option Combination | | | X | |
| 84 | No Safety Option | | X | | |
| 88 | Option Detection | | | X | |
| 89 | Mechanical Brake Sliding | X | | | |
| 90 | Feedback Monitor | (X) | (X) | | 17-61 Feedback Signal Monitoring |
| 91 | Analog input 54 wrong settings | | | X | S202 |
| 163 | ATEX ETR cur.lim.warning | X | | | |
| 164 | ATEX ETR cur.lim.alarm | | X | | |
| 165 | ATEX ETR freq.lim.warning | X | | | |
| 166 | ATEX ETR freq.lim.alarm | | X | | |
| 250 | New spare parts | | | X | |
| 251 | New Type Code | | X | X | |

Table 6.1 Alarm/Warning Code List
(X) Dependent on parameter
1) Can not be Auto reset via 14-20 Reset Mode

A trip is the action when an alarm has appeared. The trip coasts the motor and can be reset by pressing [Reset] or

make a reset by a digital input (parameter group 5-1* *Digital Inputs* [1]). The origin event that caused an alarm cannot damage the frequency converter or cause dangerous conditions. A trip lock is an action when an alarm occurs, which may damage the frequency converter

or connected parts. A Trip Lock situation can only be reset by a power cycling.

| LED indication | |
|----------------|----------------|
| Warning | yellow |
| Alarm | flashing red |
| Trip locked | yellow and red |

Table 6.2

| Bit | Hex | Dec | Alarm Word | Alarm Word 2 | Warning Word | Warning Word 2 | Extended Status Word |
|--|----------|-------|-----------------------|---------------------------------|----------------------|----------------|--|
| Alarm Word Extended Status Word | | | | | | | |
| 0 | 00000001 | 1 | Brake Check (A28) | ServiceTrip, Read/Write | Brake Check (W28) | reserved | Ramping |
| 1 | 00000002 | 2 | Heatsink temp. (A29) | ServiceTrip, (reserved) | Heatsink temp. (W29) | reserved | AMA Running |
| 2 | 00000004 | 4 | Earth Fault (A14) | ServiceTrip, Typecode/Sparepart | Earth Fault (W14) | reserved | Start CW/CCW start_possible is active, when the DI selections [12] OR [13] are active and the requested direction matches the reference sign |
| 3 | 00000008 | 8 | Ctrl.Card Temp (A65) | ServiceTrip, (reserved) | Ctrl.Card Temp (W65) | reserved | Slow Down slow down command active, e.g. via CTW bit 11 or DI |
| 4 | 00000010 | 16 | Ctrl. Word TO (A17) | ServiceTrip, (reserved) | Ctrl. Word TO (W17) | | Catch Up catch up command active, e.g. via CTW bit 12 or DI |
| 5 | 00000020 | 32 | Over Current (A13) | reserved | Over Current (W13) | reserved | Feedback High feedback > 4-57 |
| 6 | 00000040 | 64 | Torque Limit (A12) | reserved | Torque Limit (W12) | reserved | Feedback Low feedback < 4-56 |
| 7 | 00000080 | 128 | Motor Th Over (A11) | reserved | Motor Th Over (W11) | reserved | Output Current High current > 4-51 |
| 8 | 00000100 | 256 | Motor ETR Over (A10) | reserved | Motor ETR Over (W10) | reserved | Output Current Low current < 4-50 |
| 9 | 00000200 | 512 | Inverter Overld. (A9) | reserved | Inverter Overld (W9) | reserved | Output Freq High speed > 4-53 |
| 10 | 00000400 | 1024 | DC under Volt (A8) | reserved | DC under Volt (W8) | | Output Freq Low speed < 4-52 |
| 11 | 00000800 | 2048 | DC over Volt (A7) | reserved | DC over Volt (W7) | | Brake Check OK brake test NOT ok |
| 12 | 00001000 | 4096 | Short Circuit (A16) | reserved | DC Voltage Low (W6) | reserved | Braking Max BrakePower > BrakePowerLimit (2-12) |
| 13 | 00002000 | 8192 | Inrush Fault (A33) | reserved | DC Voltage High (W5) | | Braking |
| 14 | 00004000 | 16384 | Mains ph. Loss (A4) | reserved | Mains ph. Loss (W4) | | Out of Speed Range |
| 15 | 00008000 | 32768 | AMA Not OK | reserved | No Motor (W3) | | OVC Active |
| 16 | 00010000 | 65536 | Live Zero Error (A2) | reserved | Live Zero Error (W2) | | AC Brake |

| Bit | Hex | Dec | Alarm Word | Alarm Word 2 | Warning Word | Warning Word 2 | Extended Status Word |
|-----|----------|------------|------------------------|---------------------------|---------------------------|-----------------------|--|
| 17 | 00020000 | 131072 | Internal Fault (A38) | KTY error | 10V Low (W1) | KTY Warn | Password Timelock number of allowed password trials exceeded - timelock active |
| 18 | 00040000 | 262144 | Brake Overload (A26) | Fans error | Brake Overload (W26) | Fans Warn | Password Protection 0-61 = ALL_NO_ACCESS OR BUS_NO_ACCESS OR BUS_READONLY |
| 19 | 00080000 | 524288 | U phase Loss (A30) | ECB error | Brake Resistor (W25) | ECB Warn | Reference High reference > 4-55 |
| 20 | 00100000 | 1048576 | V phase Loss (A31) | reserved | Brake IGBT (W27) | reserved | Reference Low reference < 4-54 |
| 21 | 00200000 | 2097152 | W phase Loss (A32) | reserved | Speed Limit (W49) | reserved | Local Reference reference site = REMOTE -> auto on pressed & active |
| 22 | 00400000 | 4194304 | Fieldbus Fault (A34) | reserved | Fieldbus Fault (W34) | reserved | Protection Mode |
| 23 | 00800000 | 8388608 | 24 V Supply Low (A47) | reserved | 24V Supply Low (W47) | reserved | Unused |
| 24 | 01000000 | 16777216 | Mains Failure (A36) | reserved | Mains Failure (W36) | reserved | Unused |
| 25 | 02000000 | 33554432 | 1.8V Supply Low (A48) | reserved | Current Limit (W59) | reserved | Unused |
| 26 | 04000000 | 67108864 | Brake Resistor (A25) | reserved | Low Temp (W66) | reserved | Unused |
| 27 | 08000000 | 134217728 | Brake IGBT (A27) | reserved | Voltage Limit (W64) | reserved | Unused |
| 28 | 10000000 | 268435456 | Option Change (A67) | reserved | Encoder loss (W90) | reserved | Unused |
| 29 | 20000000 | 536870912 | Drive Initialized(A80) | Feedback Fault (A61, A90) | Feedback Fault (W61, W90) | | Unused |
| 30 | 40000000 | 1073741824 | Safe Stop (A68) | PTC 1 Safe Stop (A71) | Safe Stop (W68) | PTC 1 Safe Stop (W71) | Unused |
| 31 | 80000000 | 2147483648 | Mech. brake low (A63) | Dangerous Failure (A72) | Extended Status Word | | Unused |

Table 6.3 Description of Alarm Word, Warning Word and Extended Status Word

The alarm words, warning words and extended status words can be read out via serial bus or optional fieldbus for diagnose. See also 16-94 Ext. Status Word.

The warning/alarm information below defines each warning/alarm condition, provides the probable cause for the condition, and details a remedy or troubleshooting procedure.

WARNING 1, 10 Volts low

The control card voltage is below 10 V from terminal 50. Remove some of the load from terminal 50, as the 10 V supply is overloaded. Max. 15 mA or minimum 590 Ω .

This condition can be caused by a short in a connected potentiometer or improper wiring of the potentiometer.

Troubleshooting

- Remove the wiring from terminal 50
- If the warning clears, the problem is with the customer wiring
- If the warning does not clear, replace the control card

WARNING/ALARM 2, Live zero error

This warning or alarm only appears if programmed by the user in *6-01 Live Zero Timeout Function*. The signal on one of the analog inputs is less than 50% of the minimum value programmed for that input. Broken wiring or faulty device sending the signal can cause this condition.

Troubleshooting

- Check connections on all the analog input terminals. Control card terminals 53 and 54 for signals, terminal 55 common. MCB 101 terminals 11 and 12 for signals, terminal 10 common. MCB 109 terminals 1, 3, 5 for signals, terminals 2, 4, 6 common).
- Check that the frequency converter programming and switch settings match the analog signal type
- Perform Input Terminal Signal Test

WARNING 3, No motor

No motor has been connected to the output of the frequency converter.

WARNING/ALARM 4, Mains phase loss

A phase is missing on the supply side, or the mains voltage imbalance is too high. This message also appears for a fault in the input rectifier on the frequency converter. Options are programmed at *14-12 Function at Mains Imbalance*.

Troubleshooting

- Check the supply voltage and supply currents to the frequency converter

WARNING 5, DC link voltage high

The intermediate circuit voltage (DC) is higher than the high voltage warning limit. The limit is dependent on the frequency converter voltage rating. The unit is still active.

WARNING 6, DC link voltage low

The intermediate circuit voltage (DC) is lower than the low voltage warning limit. The limit is dependent on the frequency converter voltage rating. The unit is still active.

WARNING/ALARM 7, DC overvoltage

If the intermediate circuit voltage exceeds the limit, the frequency converter trips after a time.

Troubleshooting

- Connect a brake resistor
- Extend the ramp time
- Change the ramp type
- Activate the functions in *2-10 Brake Function*
- Increase *14-26 Trip Delay at Inverter Fault*

WARNING/ALARM 8, DC under voltage

If the intermediate circuit voltage (DC link) drops below the under voltage limit, the frequency converter checks if a 24 V DC back-up supply is connected. If no 24 V DC back-up supply is connected, the frequency converter trips after a fixed time delay. The time delay varies with unit size.

Troubleshooting

- Check that the supply voltage matches the frequency converter voltage.
- Perform input voltage test.
- Perform soft charge circuit test.

WARNING/ALARM 9, Inverter overload

The frequency converter is about to cut out because of an overload (too high current for too long). The counter for electronic, thermal inverter protection gives a warning at 98% and trips at 100%, while giving an alarm. The frequency converter *cannot* be reset until the counter is below 90%.

The fault is that the frequency converter is overloaded by more than 100% for too long.

Troubleshooting

- Compare the output current shown on the LCP with the frequency converter rated current
- Compare the output current shown on the LCP with measured motor current
- Display the Thermal Drive Load on the LCP and monitor the value. When running above the frequency converter continuous current rating, the counter should increase. When running below the frequency converter continuous current rating, the counter should decrease

WARNING/ALARM 10, Motor overload temperature

According to the electronic thermal protection (ETR), the motor is too hot. Select whether the frequency converter gives a warning or an alarm when the counter reaches 100% in *1-90 Motor Thermal Protection*. The fault occurs when the motor is overloaded by more than 100% for too long.

Troubleshooting

- Check for motor overheating
- Check if the motor is mechanically overloaded

- Check that the motor current set in *parameter 1-24 Motor Current* is correct
- Ensure that Motor data in parameters 1-20 through 1-25 are set correctly
- If an external fan is in use, check in *1-91 Motor External Fan* that it is selected
- Running AMA in *1-29 Automatic Motor Adaptation (AMA)* tunes the frequency converter to the motor more accurately and reduces thermal loading

WARNING/ALARM 11, Motor thermistor over temp

The thermistor might be disconnected. Select whether the frequency converter gives a warning or an alarm in *1-90 Motor Thermal Protection*.

Troubleshooting

- Check for motor overheating
- Check if the motor is mechanically overloaded
- Check that the thermistor is connected correctly between either terminal 53 or 54 (analog voltage input) and terminal 50 (+10 V supply) and that the terminal switch for 53 or 54 is set for voltage. Check *1-93 Thermistor Source* selects terminal 53 or 54
- When using digital inputs 18 or 19, check that the thermistor is connected correctly between either terminal 18 or 19 (digital input PNP only) and terminal 50
- If a KTY sensor is used, check for correct connection between terminals 54 and 55
- If using a thermal switch or thermistor, check that the programming in *1-93 Thermistor Resource* matches sensor wiring
- If using a KTY sensor, check the programming of *1-95 KTY Sensor Type*, *1-96 KTY Thermistor Resource*, and *1-97 KTY Threshold level* match sensor wiring

WARNING/ALARM 12, Torque limit

The torque has exceeded the value in *4-16 Torque Limit Motor Mode* or the value in *4-17 Torque Limit Generator Mode*. *14-25 Trip Delay at Torque Limit* can change this from a warning only condition to a warning followed by an alarm.

Troubleshooting

- If the motor torque limit is exceeded during ramp up, extend the ramp up time
- If the generator torque limit is exceeded during ramp down, extend the ramp down time
- If torque limit occurs while running, possibly increase the torque limit. Be sure the system can operate safely at a higher torque
- Check the application for excessive current draw on the motor

WARNING/ALARM 13, Over current

The inverter peak current limit (approximately 200% of the rated current) is exceeded. The warning lasts about 1.5 s, then the frequency converter trips and issues an alarm. This fault may be caused by shock loading or fast acceleration with high inertia loads. If extended mechanical brake control is selected, trip can be reset externally.

Troubleshooting

- Remove power and check if the motor shaft can be turned
- Check that the motor size matches the frequency converter
- Check parameters 1-20 to 1-25. for correct motor data

ALARM 14, Earth (ground) fault

There is current from the output phases to ground, either in the cable between the frequency converter and the motor or in the motor itself.

Troubleshooting:

- Remove power to the frequency converter and repair the earth fault
- Check for earth faults in the motor by measuring the resistance to ground of the motor leads and the motor with a megohmmeter
- Perform current sensor test

ALARM 15, Hardware mismatch

A fitted option is not operational with the present control board hardware or software.

Record the value of the following parameters and contact the Danfoss supplier:

- *15-40 FC Type*
- *15-41 Power Section*
- *15-42 Voltage*
- *15-43 Software Version*
- *15-45 Actual Typecode String*
- *15-49 SW ID Control Card*
- *15-50 SW ID Power Card*
- *15-60 Option Mounted*
- *15-61 Option SW Version* (for each option slot)

ALARM 16, Short circuit

There is short-circuiting in the motor or motor wiring.

- Remove power to the frequency converter and repair the short circuit

WARNING/ALARM 17, Control word timeout

There is no communication to the frequency converter. The warning is only active when *8-04 Control Word Timeout Function* is NOT set to OFF.

If 8-04 Control Word Timeout Function is set to Stop and Trip, a warning appears and the frequency converter ramps down until it trips then displays an alarm.

Troubleshooting:

- Check connections on the serial communication cable
- Increase 8-03 Control Word Timeout Time
- Check the operation of the communication equipment
- Verify a proper installation based on EMC requirements

WARNING 22, Hoist mechanical brake

The report value shows what kind it is.

0 = The torque reference was not reached before time-out.

1 = There was no brake feedback before the time-out.

WARNING 23, Internal fan fault

The fan warning function is an extra protective function that checks if the fan is running/mounted. The fan warning can be disabled in 14-53 Fan Monitor ([0] Disabled).

For D, E and F enclosures, the regulated voltage to the fan is monitored.

Troubleshooting

- Check fan resistance
- Check soft charge fuses

WARNING 24, External fan fault

The fan warning function is an extra protective function that checks if the fan is running/mounted. The fan warning can be disabled in 14-53 Fan Monitor ([0] Disabled).

For D, E and F enclosures, the regulated voltage to the fan is monitored.

Troubleshooting

- Check fan resistance
- Check soft charge fuses

WARNING 25, Brake resistor short circuit

The brake resistor is monitored during operation. If a short circuit occurs, the brake function is disabled and the warning appears. The frequency converter is still operational but without the brake function. Remove power to the frequency converter and replace the brake resistor (see 2-15 Brake Check).

WARNING/ALARM 26, Brake resistor power limit

The power transmitted to the brake resistor is calculated as a mean value over the last 120 s of run time. The calculation is based on the intermediate circuit voltage and the brake resistance value set in 2-16 AC brake Max.

Current. The warning is active when the dissipated braking is higher than 90% of the brake resistance power. If [2] Trip is selected in 2-13 Brake Power Monitoring, the frequency converter trips when the dissipated braking power reaches 100%.

WARNING

There is a risk of substantial power being transmitted to the brake resistor if the brake transistor is short-circuited.

WARNING/ALARM 27, Brake chopper fault

The brake transistor is monitored during operation and if a short circuit occurs, the brake function is disabled and a warning is issued. The frequency converter is still operational but, since the brake transistor has short-circuited, substantial power is transmitted to the brake resistor, even if it is inactive.

Remove power to the frequency converter and remove the brake resistor.

This alarm/warning could also occur should the brake resistor overheat. Terminals 104 and 106 are available as brake resistors Klixon ininputs, see *Brake Resistor Temperature Switch* in the *Design Guide*.

WARNING/ALARM 28, Brake check failed

The brake resistor is not connected or not working. Check 2-15 Brake Check.

ALARM 29, Heat sink temp

The maximum temperature of the heat sink has been exceeded. The temperature fault does not reset until the temperature drops below a defined heat sink temperature. The trip and reset points are different based on the frequency converter power size.

Troubleshooting

Check for the following conditions

- Ambient temperature too high
- Motor cable too long
- Incorrect airflow clearance above and below the frequency converter
- Blocked airflow around the frequency converter
- Damaged heat sink fan
- Dirty heat sink

For the D, E and F enclosures, this alarm is based on the temperature measured by the heat sink sensor mounted inside the IGBT modules. For the F enclosures, this alarm can also be caused by the thermal sensor in the rectifier module.

Troubleshooting

- Check fan resistance
- Check soft charge fuses
- IGBT thermal sensor

ALARM 30, Motor phase U missing

Motor phase U between the frequency converter and the motor is missing.

Troubleshooting

- Remove power from the frequency converter and check motor phase U

ALARM 31, Motor phase V missing

Motor phase V between the frequency converter and the motor is missing.

Remove power from the frequency converter and check motor phase V.

ALARM 32, Motor phase W missing

Motor phase W between the frequency converter and the motor is missing.

Remove power from the frequency converter and check motor phase W.

ALARM 33, Inrush fault

Too many power-ups have occurred within a short time period. Let the unit cool to operating temperature.

WARNING/ALARM 34, communication fault

The fieldbus on the communication option card is not working.

WARNING/ALARM 36, Mains failure

This warning/alarm is only active if the supply voltage to the frequency converter is lost and *14-10 Mains Failure* is NOT set to [0] *No Function*.

Troubleshooting

- Check the fuses to the frequency converter and mains power supply to the unit

ALARM 38, Internal fault

When an internal fault occurs, a code number defined in the *Table 6.4* is displayed.

Troubleshooting

- Cycle power
- Check that the option is properly installed
- Check for loose or missing wiring

Contact the Danfoss supplier or service department if required. Note the code number for further troubleshooting directions.

| No. | Text |
|-----------|--|
| 0 | Serial port cannot be initialised. Contact the Danfoss supplier or Danfoss Service Department. |
| 256-258 | Power EEPROM data is defective or too old. |
| 512 | Control board EEPROM data is defective or too old. |
| 513 | Communication time out reading EEPROM data. |
| 514 | Communication time out reading EEPROM data. |
| 515 | Application oriented control cannot recognize the EEPROM data. |
| 516 | Cannot write to the EEPROM because a write command is on progress. |
| 517 | Write command is under time out. |
| 518 | Failure in the EEPROM. |
| 519 | Missing or invalid barcode data in EEPROM. |
| 783 | Parameter value outside of min/max limits. |
| 1024-1279 | A centelegram that has to be sent couldn't be sent. |

| No. | Text |
|-----------|--|
| 1281 | Digital signal processor flash timeout. |
| 1282 | Power micro software version mismatch. |
| 1283 | Power EEPROM data version mismatch. |
| 1284 | Cannot read digital signal processor software version. |
| 1299 | Option SW in slot A is too old. |
| 1300 | Option SW in slot B is too old. |
| 1301 | Option SW in slot C0 is too old. |
| 1302 | Option SW in slot C1 is too old. |
| 1315 | Option SW in slot A is not supported (not allowed). |
| 1316 | Option SW in slot B is not supported (not allowed). |
| 1317 | Option SW in slot C0 is not supported (not allowed). |
| 1318 | Option SW in slot C1 is not supported (not allowed). |
| 1379 | Option A did not respond when calculating platform version. |
| 1380 | Option B did not respond when calculating platform version. |
| 1381 | Option C0 did not respond when calculating platform version. |
| 1382 | Option C1 did not respond when calculating platform version. |
| 1536 | An exception in the application oriented control is registered. Debug information written in LCP. |
| 1792 | DSP watchdog is active. Debugging of power part data, motor oriented control data not transferred correctly. |
| 2049 | Power data restarted. |
| 2064-2072 | H081x: option in slot x has restarted. |
| 2080-2088 | H082x: option in slot x has issued a powerup-wait. |
| 2096-2104 | H983x: option in slot x has issued a legal powerup-wait. |
| 2304 | Could not read any data from power EEPROM. |
| 2305 | Missing SW version from power unit. |
| 2314 | Missing power unit data from power unit. |
| 2315 | Missing SW version from power unit. |
| 2316 | Missint lo_statepage from power unit. |
| 2324 | Power card configuration is determined to be incorrect at power up. |
| 2325 | A power card has stopped communicating while main power is applied. |
| 2326 | Power card configuration is determined to be incorrect after the delay for power cards to register. |
| 2327 | Too many power card locations have been registered as present. |
| 2330 | Power size information between the power cards does not match. |
| 2561 | No communication from DSP to ATACD. |
| 2562 | No communication from ATACD to DSP (state running). |

| No. | Text |
|-----------|---|
| 2816 | Stack overflow control board module. |
| 2817 | Scheduler slow tasks. |
| 2818 | Fast tasks. |
| 2819 | Parameter thread. |
| 2820 | LCP stack overflow. |
| 2821 | Serial port overflow. |
| 2822 | USB port overflow. |
| 2836 | cfListMempool too small. |
| 3072-5122 | Parameter value is outside its limits. |
| 5123 | Option in slot A: Hardware incompatible with control board hardware. |
| 5124 | Option in slot B: Hardware incompatible with Control board hardware. |
| 5125 | Option in slot C0: Hardware incompatible with control board hardware. |
| 5126 | Option in slot C1: Hardware incompatible with control board hardware. |
| 5376-6231 | Out of memory. |

Table 6.4 Code Numbers for Internal Faults

ALARM 39, Heat sink sensor

No feedback from the heat sink temperature sensor.

The signal from the IGBT thermal sensor is not available on the power card. The problem could be on the power card, on the gate drive card, or the ribbon cable between the power card and gate drive card.

WARNING 40, Overload of digital output terminal 27

Check the load connected to terminal 27 or remove short-circuit connection. Check *5-00 Digital I/O Mode* and *5-01 Terminal 27 Mode*.

WARNING 41, Overload of digital output terminal 29

Check the load connected to terminal 29 or remove short-circuit connection. Check *5-00 Digital I/O Mode* and *5-02 Terminal 29 Mode*.

WARNING 42, Overload of digital output on X30/6 or overload of digital output on X30/7

For X30/6, check the load connected to X30/6 or remove the short-circuit connection. Check *5-32 Term X30/6 Digi Out (MCB 101)*.

For X30/7, check the load connected to X30/7 or remove the short-circuit connection. Check *5-33 Term X30/7 Digi Out (MCB 101)*.

ALARM 46, Power card supply

The supply on the power card is out of range.

There are 3 power supplies generated by the switch mode power supply (SMPS) on the power card: 24 V, 5 V, ±18 V. When powered with 24 V DC with the MCB 107 option, only the 24 V and 5 V supplies are monitored. When powered with 3 phase mains voltage, all 3 supplies are monitored.

WARNING 47, 24V supply low

The 24 V DC is measured on the control card. The external 24 V DC back-up power supply may be overloaded, otherwise contact the Danfoss supplier.

WARNING 48, 1.8V supply low

The 1.8 V DC supply used on the control card is outside of allowable limits. The power supply is measured on the control card. Check for a defective control card. If an option card is present, check for an overvoltage condition.

WARNING 49, Speed limit

When the speed is not within the specified range in *4-11 Motor Speed Low Limit [RPM]* and *4-13 Motor Speed High Limit [RPM]*, the frequency converter shows a warning. When the speed is below the specified limit in *1-86 Trip Speed Low [RPM]* (except when starting or stopping) the frequency converter trips.

ALARM 50, AMA calibration failed

Contact the Danfoss supplier or Danfoss Service Department.

ALARM 51, AMA check U_{nom} and I_{nom}

The settings for motor voltage, motor current, and motor power are wrong. Check the settings in parameters 1-20 to 1-25.

ALARM 52, AMA low I_{nom}

The motor current is too low. Check the settings.

ALARM 53, AMA motor too big

The motor is too big for the AMA to operate.

ALARM 54, AMA motor too small

The motor is too small for the AMA to operate.

ALARM 55, AMA parameter out of range

The parameter values of the motor are outside of the acceptable range. AMA does not run.

ALARM 56, AMA interrupted by user

The user has interrupted the AMA.

ALARM 57, AMA internal fault

Try to restart AMA again a number of times, until the AMA is carried out. Note that repeated runs may heat the motor to a level where the resistance R_s and R_r are increased. In most cases, however, this is not critical.

ALARM 58, AMA Internal fault

Contact the Danfoss supplier.

WARNING 59, Current limit

The current is higher than the value in *4-18 Current Limit*. Ensure that motor data in parameters 1-20 to 1-25 are set correctly. Possibly increase the current limit. Be sure that the system can operate safely at a higher limit.

WARNING 60, External interlock

External interlock has been activated. To resume normal operation, apply 24 V DC to the terminal programmed for external interlock and reset the frequency converter (via serial communication, digital I/O, or by pressing [Reset]).

WARNING 61, Tracking error

An error has been detected between the calculated motor speed and the speed measurement from the feedback device. The function for Warning/Alarm/ Disable is set in 4-30 *Motor Feedback Loss Function*, error setting in 4-31 *Motor Feedback Speed Error*, and the allowed error time in 4-32 *Motor Feedback Loss Timeout*. During a commissioning procedure the function may be effective.

WARNING 62, Output frequency at maximum limit

The output frequency is higher than the value set in 4-19 *Max Output Frequency*.

ALARM 64, Voltage Limit

The load and speed combination demands a motor voltage higher than the actual DC-link voltage.

WARNING/ALARM 65, Control card over temperature

The control card has reached its trip temperature of 80 °C.

WARNING 66, Heat sink temperature low

The frequency converter is too cold to operate. This warning is based on the temperature sensor in the IGBT module.

Increase the ambient temperature of the unit. Also, a trickle amount of current can be supplied to the frequency converter whenever the motor is stopped by setting 2-00 *DC Hold/Preheat Current* at 5% and 1-80 *Function at Stop*

Troubleshooting

The heatsink temperature measured as 0 °C could indicate that the temperature sensor is defective, causing the fan speed to increase to the maximum. If the sensor wire between the IGBT and the gate drive card is disconnected, this warning would result. Also, check the IGBT thermal sensor.

ALARM 67, Option module configuration has changed

One or more options have either been added or removed since the last power-down. Check that the configuration change is intentional and reset the unit.

ALARM 68, Safe stop activated

Safe stop has been activated. To resume normal operation, apply 24 V DC to terminal 37, then send a reset signal (via Bus, Digital I/O, or by pressing [Reset]).

ALARM 69, Power card temperaturePower card temperature

The temperature sensor on the power card is either too hot or too cold.

Troubleshooting

- Check the operation of the door fans
- Check that the filters for the door fans are not blocked
- Check that the gland plate is properly installed on IP21/IP54 (NEMA 1/12) frequency converters

ALARM 70, Illegal FC configuration

The control card and power card are incompatible. Contact the supplier with the type code of the unit from the nameplate and the part numbers of the cards to check compatibility.

WARNING/ALARM 71, PTC 1 safe stop

Safe Stop has been activated from the MCB 112 PTC thermistor card (motor too warm). Normal operation can be resumed when the MCB 112 applies 24 V DC to T-37 again (when the motor temperature reaches an acceptable level) and when the digital input from the MCB 112 is deactivated. When this happens, a reset signal is sent (via serial communication, digital I/O, or by pressing reset button on LCP). Note that if automatic restart is enabled, the motor may start when the fault is cleared.

ALARM 72, Dangerous failure

Safe Stop with Trip Lock. Unexpected signal levels on safe stop and digital input from the PTC thermistor card.

WARNING 73, Safe stop auto restart

Safe stopped. With automatic restart enabled, the motor may start when the fault is cleared.

WARNING 76, Power unit setup

The required number of power units does not match the detected number of active power units. When replacing an F-frame module, this occurs if the power specific data in the module power card does not match the rest of the frequency converter.

Troubleshooting

- Confirm the spare part and its power card are the correct part number

WARNING 77, Reduced power mode

This warning indicates that the frequency converter is operating in reduced power mode (i.e. less than the allowed number of inverter sections). This warning is generated on power cycle when the frequency converter is set to run with fewer inverters and remains on.

ALARM 79, Illegal power section configuration

The scaling card is the incorrect part number or not installed. Also MK102 connector on the power card could not be installed.

ALARM 80, Drive initialised to default value

Parameter settings are initialised to default settings after a manual reset. Reset the unit to clear the alarm.

ALARM 81, CSIV corrupt

CSIV file has syntax errors.

ALARM 82, CSIV parameter error

CSIV failed to initialise a parameter.

ALARM 85, Dang fail PB:

Profibus/Profisafe Error.

ALARM 91, Analog input 54 wrong settings

Switch S202 has to be set in position OFF (voltage input) when a KTY sensor is connected to analog input terminal 54.

ALARM 243, Brake IGBT

This alarm is only for F Frame frequency converters. It is equivalent to Alarm 27. The report value in the alarm log indicates which power module generated the alarm:

- 1 = left most inverter module.
- 2 = middle inverter module in F2 or F4 frequency converter.
- 2 = right inverter module in F1 or F3 frequency converter.
- 3 = right inverter module in F2 or F4 frequency converter.
- 5 = rectifier module.

ALARM 244, Heatsink temperature

This alarm is only for F Frame frequency converters. It is equivalent to Alarm 29. The report value in the alarm log indicates which power module generated the alarm:

- 1 = left most inverter module.
- 2 = middle inverter module in F2 or F4 frequency converter.
- 2 = right inverter module in F1 or F3 frequency converter.
- 3 = right inverter module in F2 or F4 frequency converter.
- 5 = rectifier module.

ALARM 245, Heatsink sensor

This alarm is only for F Frame frequency converters. It is equivalent to Alarm 39. The report value in the alarm log indicates which power module generated the alarm:

- 1 = left most inverter module.
- 2 = middle inverter module in F2 or F4 frequency converter.
- 2 = right inverter module in F1 or F3 frequency converter.
- 3 = right inverter module in F2 or F4 frequency converter.
- 5 = rectifier module.

ALARM 246, Power card supply

This alarm is only for F Frame frequency converters. It is equivalent to Alarm 46. The report value in the alarm log indicates which power module generated the alarm:

- 1 = left most inverter module.
- 2 = middle inverter module in F2 or F4 frequency converter.
- 2 = right inverter module in F1 or F3 frequency converter.
- 3 = right inverter module in F2 or F4 frequency converter.
- 5 = rectifier module.

ALARM 247, Power card temperature

This alarm is only for F Frame frequency converter. It is equivalent to Alarm 69. The report value in the alarm log indicates which power module generated the alarm:

- 1 = left most inverter module.
- 2 = middle inverter module in F2 or F4 frequency converter.
- 2 = right inverter module in F1 or F3 frequency converter.
- 3 = right inverter module in F2 or F4 frequency converter.
- 5 = rectifier module.

ALARM 248, Illegal power section configuration

This alarm is only for F Frame frequency converters. It is equivalent to Alarm 79. The report value in the alarm log indicates which power module generated the alarm:

- 1 = left most inverter module.
- 2 = middle inverter module in F2 or F4 frequency converter.
- 2 = right inverter module in F1 or F3 frequency converter.
- 3 = right inverter module in F2 or F4 frequency converter.
- 5 = rectifier module.

WARNING 250, New spare part

A component in the frequency converter has been replaced. Reset the frequency converter for normal operation.

WARNING 251, New typecode

The power card or other components have been replaced and the typecode changed. Reset to remove the warning and resume normal operation.

Index

A

Abbreviations..... 5

Access to Control Terminals..... 72

Airflow..... 32

Alarm

 log..... 116

 Messages..... 105

AMA..... 77, 111, 114

Analog

 inputs..... 110

 Inputs..... 91

 Output..... 92

 signal..... 110

Approvals..... 4

Automatic Motor Adaptation (AMA)..... 77, 84

B

Back cooling..... 32

Brake

 Cable..... 56

 Resistor Temperature Switch..... 70

Braking..... 112

Branch circuit protection..... 57

C

Cable

 Lengths and Cross Sections..... 93

 positions..... 22

Cable-length and cross-section..... 43

Cabling..... 43

Communication option..... 113

Control

 cables..... 75

 Cables..... 73

 card..... 110, 92

 Card Performance..... 93

 card, 24 V DC Output..... 92

 card, USB serial communication..... 93

 Characteristics..... 93

 Terminals..... 72

Conventions..... 5

Cooling..... 32

Current rating..... 110

D

DC link..... 110

DeviceNet..... 4

Digital

 input..... 111

 Inputs..... 90

 Output..... 92

Disposal..... 6

Drip Shield Installation..... 36

Duct

 cooling..... 32

 work cooling kits..... 36

E

Earth leakage current..... 6

ELCB relays..... 54

Electrical Installation..... 72, 73

Enclosure Type F Options..... 41

External

 Fan Supply..... 57

 Temperature Monitoring..... 43

F

Feedback..... 114

Fieldbus connection..... 70

Floor Mounting..... 40

Fuses..... 113, 57

Fusing..... 43

G

General

 Considerations..... 19

 Warning..... 7

Gland/Conduit Entry - IP21 (NEMA 1) and IP54 (NEMA12)
..... 34

Graphical display..... 80

Grounding..... 54

I

IEC Emergency Stop with Pilz Safety Relay..... 42

Input

 polarity of control terminals..... 75

 terminals..... 110

Installation

 of 24 V external DC Supply..... 72

 of Duct Cooling Kit in Rittal..... 36

 of Input Plate Options..... 40

 of Mains Shield for Frequency Converters..... 40

 on Pedestal..... 39

 on the Wall - IP21 (NEMA 1) and IP54 (NEMA 12) Units..... 34

Insulation Resistance Monitor (IRM)..... 42

IT mains..... 54

L

Language package..... 83

| | | | |
|--|----------|--|----------|
| LCP..... | 80 | Protection and Features..... | 94 |
| LEDs..... | 80, 81 | Pulse Start/Stop..... | 76 |
| Lifting..... | 8 | Pulse/Encoder Inputs..... | 92 |
| Load Sharing..... | 56 | | |
| Local Control Panel..... | 81 | | |
| | | R | |
| M | | Rated Power..... | 18 |
| Main reactance..... | 84 | RCD (Residual Current Device)..... | 42 |
| Mains | | Receiving the Frequency Converter..... | 8 |
| Connection..... | 56 | Relay Outputs..... | 93 |
| Supply (L1, L2, L3)..... | 90 | Repair Work..... | 7 |
| Manual Motor Starters | 42 | Reset..... | 110, 115 |
| Mechanical | | Residual Current Device..... | 7 |
| Brake Control..... | 78 | RFI Switch..... | 54 |
| dimensions..... | 17 | RS-485 serial communication..... | 92 |
| Dimensions..... | 11 | | |
| Installation..... | 19 | | |
| Motor | | S | |
| Cable..... | 55 | Safe | |
| current..... | 114 | Stop + Pilz Relay..... | 42 |
| data..... | 111, 114 | Torque Off..... | 7 |
| Insulation..... | 70 | Safety Instructions | 6 |
| name plate..... | 77 | Screened/armoured | 75 |
| output..... | 90 | Screening of cables | 43 |
| overload protection..... | 6 | Serial Communication | 93 |
| power..... | 114 | Shielded Cables | 55 |
| protection..... | 94 | Short circuit | 111 |
| Thermal Protection..... | 79 | Sine-wave filter | 44 |
| | | Smart Application Setup (SAS) | 83 |
| N | | Space | |
| NAMUR..... | 42 | Space..... | 19 |
| Non UL compliance..... | 57 | Heaters and Thermostat..... | 41 |
| Numerical display..... | 81 | Speed Up/Down | 76 |
| | | Start/Stop | 76 |
| O | | Stator leakage reactance | 84 |
| Ordering..... | 37 | Status messages | 80 |
| Output | | Supply voltage | 113 |
| current..... | 110 | Surroundings | 94 |
| Performance (U, V, W)..... | 90 | Switches S201, S202, and S801 | 75 |
| Outside Installation/NEMA 3R Kit for Rittal | 38 | Switching frequency | 43 |
| | | | |
| P | | T | |
| Parallel Connection of Motors..... | 78 | Terminal | |
| Parameter Menu Structure..... | 86 | 54..... | 115 |
| Pedestal Installation..... | 40 | Locations..... | 1, 23 |
| Phase loss..... | 110 | Thermal Protection | 4 |
| Planning the Installation Site..... | 8 | Thermistor | 111 |
| Potentiometer Reference..... | 77 | Torque | |
| Power Connections..... | 43 | Torque..... | 54 |
| Profibus..... | 4 | Characteristics..... | 90 |
| Programming | 110 | for Terminals..... | 55 |

U**Unintended Start**..... 7**Unpacking**..... 8**V****Voltage**

imbalance..... 110

level..... 90

reference via a potentiometer..... 77

VVCplus..... 5**W****Warnings**..... 105**Wire access**..... 19



www.danfoss.com/drives

.....
Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.
.....

