






Description	Zetor Tractor 2011,2511,3011,3523 & more	
Part No.	HP -902	
Displacement	14 CC	


Description	IH,Inter,Case Tractor 275,276,354,374,384,414,434,444	
Part No.	HP -903	
Displacement	11 CC	


Description	Ebro Tractor	
Part No.	HP -905	
Displacement	14 CC	


Description	Engine Mounted Pump for Ford	
Part No.	HP -906	
Displacement	11 CC	


Description	Deutz Fahr DX36V,DX50,DX55	
Part No.	HP -919	
Displacement	11 cc	

Description	Deutz Fahr DX36V,DX50,DX55	
Part No.	HP -920	
Displacement	14 cc	

Description	Deutz Fahr DX3.30SC, DX3.50SC	
Part No.	HP -921	
Displacement	19 cc	

Description	Steyr Tractor 650H,460H,768H,1100H,1200H, 8070H,8073H,8080H,8100H8120H,8140H	
Part No.	HP -922	
Displacement	16.80 cc	


Description	Steyr Tractor 1100H,870H,8080H,8120H	
Part No.	HP -923	
Displacement	16.80 cc	


Description	Steyr Tractor 8140S VE & 8160S	
Part No.	HP -924	
Displacement	16.80 cc	


Description	Steyr Tractor T.Z.D.K 8043	
Part No.	HP -925	
Displacement	11.90 cc	

Description	Same Tractor	
Part No.	HP -937	
Displacement	11 cc	


Description	Holder / Hurlimann	
Part No.	HP -938	
Displacement	16 cc	


Description	Fiat Tractor 88015,980,1180,1280	
Part No.	HP -939	
Displacement	19 cc	

Description	Fiat Tractor 480,556,766,980,670F	
Part No.	HP -940	
Displacement	11 cc	


Description	Tandem Pump for Bobard	
Part No.	HP -941	
Displacement	5.5 cc	


Description	Same Tractor	
Part No.	HP -942	
Displacement	22.50 cc	

Description	Fendt Tractor 103S,203P,200S,200V,203V	
Part No.	HP -943	
Displacement	14 cc	


Description	Fiat / New Holland Tractor 800,420,415,300	
Part No.	HP -944	
Displacement	8 cc	


Description	Fiat Tractor	
Part No.	HP -945	
Displacement	15 cc	


Description	Fiat Tractor	
Part No.	HP -946	
Displacement	9.50 cc	


Description	Fiat / New Holland Tractor 466,666,766,566	
Part No.	HP -947	
Displacement	14 cc	


Description	Fiat Tractor	
Part No.	HP -948	
Displacement	16.80 cc	


Description	Deutz Fahr DX330SC,DX380VC	
Part No.	HP -949	
Displacement	19 cc	

Description	Fiat Tractor 640,5540,60.66,615	
Part No.	HP -950	
Displacement	11 cc	


Description	Fiat Tractor 440,5005,70.66LP/F	
Part No.	HP -951	
Displacement	8 cc	


Description	Fiat Tractor 450,470,480,500,540	
Part No.	HP -952	
Displacement	15 cc	


Description	Steering Pump for MF165,168,175,178,185,188, 265, 275, 285, 290, 565, 575, 590	
Part No.	HP -953	
Displacement	6.10 cc	


Description	Steering Pump for MF 135,148,230,240,250,550	
Part No.	HP -954	
Displacement	6.30 cc	


Description	Steering Pump for Steyr	
Part No.	HP -955	
Displacement	8.20 cc	


Description	Steering Pump Tandem for MF 174F,184F,194F, 362, 372N, 374S, 374F, 382, 384S, 394S, 365, 375. 390. 398	
Part No.	HP -956	
Displacement	10 + 8 cc	

Description	John Deere 500,510,700,710	
Part No.	HP -957	
Displacement	8 cc	


Description	John Deere 500,510,700,710,with Power Steering	
Part No.	HP -958	
Displacement	11 cc	


Description	John Deere 500,510,700,710,with Power Steering	
Part No.	HP -959	
Displacement	16 cc	


Description	DUETZ AGR OXTRA 4.17	
BOSS Part No	HP - 960	
Displacement	19 cc	


Description	DUETZ -FAHR AGR OXTRA 4.57,6.07	
Part No.	HP-961	
Displacement	19+11 CC	


Description	MF 373,393	
Part No.	HP- 962	
Displacement	11 CC	


Description	MF 399 POWER STEERING PUMP	
Part No.	HP- 963	
Displacement	18+12.5 CC	


Description	MF/LANDINI 4500, 5000,5500,5830	
Part No.	HP- 964	
Displacement	11 CC	

Description	LANDINI 2500, 6830, 7830, 8830, 6840	
Part No.	HP- 965	
Displacement		

Description	LANDINI 6500,7500,8500,6830,7830	
Part No.	HP- 974	
Displacement	16 CC	


Description	MF 154F,154S,164S,174S,184S,194F	
Part No.	HP- 966	
Displacement	8 CC	


Description	JOHN DEERE 500,510,700,710	
Part No.	HP- 975	
Displacement	11 CC	

Description	JOHN DEERE 500,510,700,710	
Part No.	HP-976	
Displacement	16 CC	


Description	SAME-LAMBORGHINI H-6130	
Part No.	HP-977	
Displacement	16 CC	


Description	SAME-LAMBORGHINI H-6160	
BOSS Part No.	HP-978	
Displacement	19 CC	

Description	LAMBORGHINI H496,H5116,H6136,H6170	
Part No.	HP-979	
Displacement	22.5 CC	

Description	LAMBORGHINI H360,H470,H480	
BOSS Part No.	HP-980	
Displacement	11 CC	


Description	BOBARD M75	
Part No.	HP-81	
Displacement	5.5 CC	


Description	BOBARD 620,CC55,621,CC70,	
Part No.	HP-82	
Displacement	16 CC	

Description	BOBARD K30,K40,K35,K42	
Part No.	HP-83	
Displacement	8 CC	

Description	BOBARD K42, M55	
Part No.	HP-84	
Displacement	16 CC	

Description	BOBARD K53	
Part No.	HP-85	
Displacement	16 CC	

Description	FENDT 103S,200S,200V,203V,203P	
Part No.	HP- 86	
Displacement	14 CC	

Description	FENDT 610,611 LS,612	
Part No.	HP- 87	
Displacement	11 CC	