



Simulation Conference 2018

JANUARY 14-17, 2018

JW Marriott Houston Downtown, Houston, Texas



Education on nuclear fundamentals with iPWR Basic Principle Simulator

60 Years

providing


Solutions

to our Clients

Corporate Presentation

Company Milestones







Corporate Presentation

International Footprint
























Sertec







Corporate Presentation

Value proposition



Develop and implement integrated and innovative solutions that promote the safety, efficiency and reliability of your assets, processes and the performance of people












Digital Operation and Asset Management




Operation support







Monitoring








Asset management





Integral Pressurized Water Reactor (iPWR) Simulator





Scope:


Basic Principle Simulator – Generic behavior Small Modular Reactor, iPWR type Part of IAEA's collection of Basic Principle Simulators for Education Fully developed with Tecnatom's simulation technology

https://www.iaea.org/NuclearPower/Simulators/



Integral Pressurized Water Reactor (iPWR) Simulator





Main thermal-hydraulic parameters:

- Reactor termal power ~ 150 MW
- Electrical power ~ 45 Mwe
- PZR pressure ~ 15.5 Mpa
- Feedwater flow ~ 79 Kg/s


Passive safety:

- Automatic Depressurisation system (ADS)
- Pressure Injection system (PIS)
- Gravity Injection system (GIS)
- Passive decaay heat removal (PDHR)





Integral Pressurized Water Reactor (iPWR) Simulator







Configuration capabilities


⊘ tecnatom


Operating modes

- Reactor Leading Mode
- ✓ Turbine Leading Mode












Technological approach









Technological approach










Graphical User Interface








Human Factors Engineering principles & methods


NUREG-0700








Overview of the plant systems








Overview of the plant systems





Control loops











Simulator control and supervision



Malfunctions activation









Training material







Exercises for standard operations:

- Load maneuvering in turbine leading mode
- Reactor power decrease from 100% to 0%
- Reactor trip and restart
- ...

Exercises for malfunction transient Events

- Loss of feedwater Flow
- Turbine runback
- Large steam generator tube rupture
- ...

TABLE 11. STATION BLACKOUT (cont.)

MALFUNCTION:	SM-GEN-1 DESCRIPTION: PROCEDURE STEPS Verify turbine trip: (1) Verify there is no steam flow going to the turbine.		Station blackout (total loss of AC power)		
STEP ID.			GUI SHEET Systems	EXPECTED RESPONSE - MSS to TUR flow (MSSFT04_TR) goes to zero (MSSV08 is a 'fail close' valve); - MSS to CNR flow (MSSFT05_TR) is zero (MSSV09 is a 'fail close' valve); - Turbine trip and generator breaker open alarms.	STATE
5					
6	Verify power supply: (1) Offsite power light is off; (2) Emergency diesel light is off; (3) Battery light is on.				
7	Verify main steam safety valves are dumping steam to atmosphere.		Systems	MSSV03/4 open: Safety valve relief setpoint is 5.70 MPa.	131
NOTE	ADS valves are fail close valves. On a station blackout event, ADS valves close to avoid an unnecessary breach on t reactor coolant pressure boundary. These valves should be powered from its associated batteries before they are ful discharged.				


www.tecnatom.es


All rights reserved



Different operating systems and platforms










Conclusions







www.tecnatom.es



"@2017 Tecnatom, S.A

Todos los derechos reservados. El contenido de esta obra está protegido por la Ley y no podrá ser reproducida, ni en todo ni en parte, ni transmitida, ni registrada por ningún sistema de recuperación de información, en ninguna forma ni por ningún medio, sin el consentimiento previo y por escrito de Tecnatom, S.A. y de sus autores.

Tecnatom y el logotipo de Tecnatom son marcas registradas de Tecnatom, S.A."